


Configure Profiles

 For supported software information, click [here](#).


You use the Configure lifecycle to create all configuration objects for Secure SD-WAN deployments. The Concerto configuration objects are hierarchical and consist of master profiles, subprofiles, policies, and rules. A master profile contains one or more subprofiles, a subprofile contains one or more policies, and a policy contains one or more rules. For more information, see [Configuration Hierarchies](#).

To access the Configure lifecycle screen, select Configure in the left menu bar on the Concerto tenant's home screen. Then select Secure SD-WAN > Profiles.



The following figure shows a Configure lifecycle screen that displays the basic master profile (Default-Basic-MP), the default active-active HA profile (Default-Active-Active), and the basic subtenant master profile (Default-Basic-MP-Sub-

Tenant, for Releases 11.2.1 and later).



Profile Types

The Concerto orchestrator has two types of profiles: master profiles and subprofiles.

Master profiles are configuration templates that you can apply to one or more appliances. Each master profile consists of subprofiles. There are two types of master profiles:

- **Basic**—Includes a subset of the available configuration objects. You can build most configuration objects in the basic master profile in the same way that you build them in standard master profiles. For Releases 11.2.1 and later, the subtenant basic master profile allows you to configure security and application services. The basic master profile provides a simple user experience and eliminates the subprofiles hierarchy. Instead of creating subprofiles, you create policies and rules and then attach them directly to the basic master profile. For Releases 11.2.1 and later, a master profile can be for a single tenant or for multiple tenants.
- **Standard**—Includes all available configuration objects and provides more configuration options.

The following types of subprofiles are available:

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.













- Application—Use to create QoS and traffic-steering policies.
- Device—Use to create BGP peer, interface, and radio policies.
- Network Services—Use to create CGNAT, DHCP, and WLAN policies.
- Security—Use to create access control, antivirus, IP-filtering, IPS, and URL-filtering policies
- Topology—Use to create VPN policies, including branch and hub policies.


Default Master Profiles

When you install the Concerto software or create a new tenant, Concerto automatically builds three default basic master profiles for the tenant:


- Default-Basic-MP
- Default-Active-Active
- Default-Basic-MP-Sub-Tenant (for Releases 11.2.1 and later)

The default master profiles consist of preconfigured network, security, and application objects, as shown below. The default basic subtenant master profile consists of only application and security objects. Concerto creates these basic master profiles automatically for each tenant on Concerto. You can customize the Default-Basic-MP master profile and use it for single-appliance or multitenant site deployments. You can customize the Default-Active-Active master profile and use it for active–active appliance HA site and multitenant deployments.

Default-Basic-MP-Su... (Sub Tenant)	1		QoS 1 Policy 0 Rules Traffic Steering 1 Policy 0 Rules	Access Control 1 Policy 0 Rules Antivirus 1 Policy 0 Rules IP Filtering 1 Policy 0 Rules IPS 1 Policy 0 Rules URL Filtering 1 Policy 0 Rules	26/05/2022, 10:27:.... admin	   
Default-Active-Active	1	WAN 1 0 Wireless 1 Wired WLAN 1 Enterprise-WiFi LAN 2 Enterprise-LAN Enterprise-WiFi	QoS 1 Policy 0 Rules Traffic Steering 1 Policy 0 Rules	Access Control 1 Policy 0 Rules Antivirus 1 Policy 0 Rules IP Filtering 1 Policy 0 Rules IPS 1 Policy 0 Rules URL Filtering 1 Policy 0 Rules	• Interface IP 2 • Password8To63 1 09/09/2021, 02:44:.... admin	   
Default-Basic-MP	1	WAN 3 1 Wireless 2 Wired WLAN 2 Guest-WiFi ACME-WiFi LAN 3 Enterprise-LAN Enterprise-WiFi Guest-WiFi	QoS 1 Policy 0 Rules Traffic Steering 1 Policy 0 Rules	Access Control 1 Policy 0 Rules Antivirus 1 Policy 0 Rules IP Filtering 1 Policy 0 Rules IPS 1 Policy 0 Rules URL Filtering 1 Policy 0 Rules	• Interface IP 2 • Password8To63 2 09/09/2021, 02:44:.... admin	   

When you click the  Ellipses icon for a basic master profile or standard master profile, a popup window displays the following options:

- **Edit**—Click to configure a new version of the the basic master profile. Each version is assigned a new version number, and the original default master profile remains.
- **Clone**—Click to create a new master profile based on the basic master profile. After you make changes to the configuration objects, save it with a unique name.
- **References**—Click to view all the appliances using this master profile.
- **Propagate**—Click to view all the appliances using previous versions of this master profile, and select all appliances or a subset of them to which to apply this master profile version.
- **Delete**—Click to delete the master profile.




For HA, a default active–active HA basic master profile is provided. You can build active-active HA profiles directly in the default active–active HA basic master profile. The following figure below shows the network diagram for the default active–active HA master profile.

Note: Before using the built-in default basic master profiles, do the following:

- Set the connection names on each WAN interface under the Connection tab
- Set the Direct Internet Access connection names under VPN Instances under the Others tab.

If you do not set the connection names used on the appliances in the master profile, when you try to publish the master profile to an appliance, the publish process fails. For more information, see [Make Mandatory Updates to the Default Basic Master Profile](#).



To create an active–active HA deployment, you create a single profile and use it on both the primary and secondary HA appliances. All configuration changes and bind-variable values assignments are made on the primary appliance, even if they are meant for the secondary appliance. After you create the configuration for the primary appliance, Concerto uses

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT


Copyright © 2024, Versa Networks, Inc.

that configuration to build the configuration for the secondary appliance in the HA pair. After you configure both HA appliances, you publish each of the appliances separately to create the HA deployment.

The cross-connect interface shown in the figure above is optional. If the WAN interfaces on both the primary and secondary appliances are the same, that is, if the circuits are the same in each WAN interface, you do not need to add the cross-connect interface. If you do need the cross-connect, you configure it in the same way as any other interface type.

You can also convert any non-HA master profile to active-active mode by simply adding a redundant WAN interface to it. Redundant WAN interfaces are attached to the secondary appliance.

For Releases 11.2.1 and later, Concerto provides a default subtenant basic master profile at the subtenant level. You use a subtenant standard master profile to configure security and application services for a subtenant. The subtenant basic master profile does not support other services.



Make Mandatory Updates to the Default Basic Master Profile

When you create a new tenant in the Concerto orchestrator, several built-in configuration objects are created, and they are packaged with the Concerto software. One of the built-in objects is the default basic master profile, which is named

Default-Basic-MP.v1. You must update this profile before using it on an appliance. You can also clone this basic master profile and modify it before applying it to an appliance.

In the Default-Basic-MP.v1 object, the following interfaces are preconfigured:

- Three WAN interfaces
 - Two wired interfaces, named Private and Internet
 - One LTE interface
- Three LAN interfaces
 - One wired LAN interface
 - One enterprise WiFi interface
 - One guest WiFi interface

The following figure shows the default WAN and LAN interfaces in the default basic master profile. The Type field shows that the master profile is a basic master profile.

Edit Master Profile

Default-Basic-MPv1

General

Profile

Permissions

Name

Default-Basic-MP

Version 1

Type

Basic

Solution Tier

Select

Scope

Single Tenant

Summary

Variables | 3

• Password8To63 | 1 • Interface IP | 2

Network

WAN

Name	Type	Category
Internet	Wired	BROADBA...
Private	Wired	MPLS
LTE	Wireless	LTE

WLAN

Enterprise-WiFi

LAN

Name	Address	DHCP	VPN
Enterprise-LAN	\$Enterp...dress		SASE-SDWAN...
Enterprise-WiFi	\$Enterp...dress		SASE-SDWAN...

> Security

> Application

Tags

Press Enter to add

Close

Next

Before you use the default basic master profile on an appliance, you must disable the interfaces that are not required and then associate them with one of the WAN connections (the WAN networks defined on the Director node). You must also set the direct internet access connection names under VPN Instances.


https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT


Copyright © 2024, Versa Networks, Inc.

To make the mandatory updates to the default basic master profile:

1. In Tenant view, select the Configure lifecycle in the left menu bar.
2. Select Profiles > Master Profiles.
3. Select the Default-Basic-MP profile in the main pane. The Edit Master Profile screen displays.
4. Select the Profile tab. The Network subtab displays, showing a diagram of the network.



5. Click the WAN box in the network diagram. The WAN screen displays the three WAN interfaces. Because these interfaces are specific to each deployment, the default basic master profile is not preconfigured with connection names for the WAN interfaces.



6. Click an interface name. The Edit Interface screen displays.
7. Click the Connection tab, and then select a connection in the Connection Name field. The following screenshot shows that the Internet-1 connection is selected.

Internet.v1

General

Connection

QoS

Permissions

Connection Type

Broadband

Connection Name

Internet-1

Uplink Bandwidth (Kbps)

Internet-1

Internet-2

Address

IPv4 Interfaces

STATIC — DHCP

IPv4 Address automatically assigned

Add IPv6 Address

> Static Routes

> Monitor

8. Repeat Step 7 for the other two WAN interfaces.
9. To set the direct internet access connection names, click the Others tab in the Edit Master Profile screen.

Edit Master Profile
Default-Basic-MPv1

General

Profile


Network

Security

Application


Others

Permissions




DHCP

3 DHCP Servers




CGNAT

No Service Present




VPN Instance

2 VPN Instances



BGP Peer Policy

No BGP Peer Policies
[+ BGP Peer Policy](#)




Director Service Templates

1 Service Template


Close

Next

10. Click the VPN instances box. The VPN Instances screen displays.



11. Click a VPN instance. The Edit VPN Instance screen displays.



14. Click the Permissions tab, and then click Save. A message displays at the top of the Configuration screen confirming that the basic master profile has been updated successfully.

Make Optional Updates to the Default Basic Master Profile

Based on your site configuration requirements, you may need to create a new basic master profile. To do this, you clone the Default-Basic-MP.v1 master profile and then update it as needed. The following are some of the common changes you can make to the master profile:

- Configure a multitenant master profile.
- Disable the LTE interface.
- Enable or disable DIA.
- Update the authentication protocol for the WiFi interface.
- Add traffic steering, QoS, and security rules.
- Update or add services.

Configure a Multitenant Basic Master Profile

For Releases 11.2.1 and later.

You can edit a default active-active master profile or default basic master profile to allow multitenancy. With a multitenant basic master profile, you can create multitenant appliances for a provider organization. You can create new

subtenants, and you can attach existing subtenants while publishing the provider organization appliance that uses the multitenant master profile. Appliances are automatically created in the subtenants associated with a provider appliance that uses a multitenant master profile.

In a multitenant basic master profile, you create interfaces for subtenants in the provider tenant profile. Because interfaces, networks, and routing instances are common appliance resources, configuring them at the provider tenant level avoids overlapping of the configuration among tenants. For example, multiple tenants can use vni-0/0.1 independently on the same appliance. Having shared resources such as interfaces helps to avoid such misconfiguration and simplify the implementation. You configure interfaces and routing on a multitenant appliance at the provider tenant level. The provider user can mark each interface for the subtenant to which it belongs. The remainder of the service configuration, such as security, traffic steering, and application QoS, can be performed at the subtenant level by subtenant or provider tenant users.

To configure a multitenant basic master profile:

1. Configure the scope of the default active-active (Default-Active-Active) or default basic master profile (Default-Basic-MP) to multitenant.
 - a. Click the basic master profile.
 - b. In Edit Master Profile > General, select Multitenant in the Scope field.

Edit Master Profile
Default-Basic-MPv1

General Profile Permissions

Name
Default-Basic-MP Version 1

Type
Basic

Solution Tier
Select

Scope
Multi Tenant


Summary

Variables | 3


- Password8To63 | 1 • Interface IP | 2

Close Next

2. Configure subtenant LAN interfaces for subtenants that are associated with the provider organization. By default, the master profile contains a LAN interface. Note that you can create subtenant LAN interfaces only for basic master profiles of type Multitenant.
 - a. Select Edit Master Profile > Profile. The Network subtab displays, showing a diagram of the network.
 - b. Click LAN.



- c. In the LAN screen, click Add Interfaces > Create New. The LAN screen displays the default enterprise LAN interface.




- d. In Create Interface screen > General tab, enter a name for the subtenant LAN interface.

- h. Click Next. The Address and Routing tab displays.

The screenshot shows the 'Create Interface V1' configuration page with the 'Address and Routing' tab selected. The 'Address' section includes an 'IPv4 Address' field with the value '10.10.10.11/24' and radio buttons for 'STATIC' (selected) and 'DHCP'. Below this are 'DHCP Relay' and 'VRRP' toggle switches, both currently off. The 'Add IPv6 Address' section has a 'Guest Interface' toggle switch (off) and a 'VPN Name' dropdown menu with 'Tenant1-Enterprise' selected. Below these are expandable sections for 'Static Routes' and 'Routing Protocol'. The 'Routing Protocol' section has a 'Protocol' dropdown menu with 'Select' as the current value. At the bottom, there are 'Cancel', 'Next', and a menu icon button.

- i. Enter the IPv4 address for the LAN interface.
- j. In the VPN Name field, select the tenant's VPN. By default, the VPN of the tenant you selected in the General tab is displayed
- k. Enter information in the other fields, and the save the subtenant LAN interface. The interface that you add displays under Subtenant LAN. For example:



- I. Repeat this step for each subtenant.
3. Create VPN instances to associate subtenant VPNs with the master profile for the provider organization.
 - a. In Edit Master Profile > Profile, select the Others tab.

Edit Master Profile

Multi-Tenant_Default-Basic-MPv1

General

Profile

Network

Security

Application

Others

Permissions

DHCP

2 DHCP Servers

CGNAT

No Service Present

VPN Instance

2 VPN Instances

BGP Peer Policy


No BGP Peer Policies

+ BGP Peer Policy

Cancel


Next

- b. Click the VPN Instance field. In the VPN Instances screen, click Add VPN Instance, and then click Create New.



- c. In the Create VPN Instance screen, select the General tab.

- g. Enter information in the other fields.
- h. Click Next, and then save the VPN instance. The VPN instance displays in the VPN Instances screen.



- i. Repeat this step for all subtenant VPNs.
4. After you update the master profile, deploy the appliance associated with the master profile. When you publish, Concerto creates a subtenant appliance in each of the subtenants. For more information, see [Concerto Deploy Lifecycle Overview](#).

Edit the Subtenant Basic Master Profile

For Releases 11.2.1 and later.

You can use a subtenant standard master profile to configure security and application services for a provider organization.

To edit a subtenant basic master profile:

1. Click the basic subtenant master profile, which the GUI displays as Default-Basic-MP-subtenant. You cannot edit the Type and Scope fields.

Edit Master Profile

Configure > Profiles > ... > Basic : Default-Basic-MP-Sub-Tenant

General
Profile
Permissions

Name
Default-Basic-MP-Sub-Tenant
Version 1

Description

Type
Basic

No variables present

Security

Access Control
1 Policy | 0 Rules

IP Filtering
1 Policy | 0 Rules

URL Filtering
1 Policy | 0 Rules

Antivirus
1 Policy | 0 Rules

IPS
1 Policy | 0 Rules

Application

QoS
1 Policy | 0 Rules

Traffic Steering
1 Policy | 0 Rules

Tags
Press Enter to add

Close
Next

2. Click Next. The Profile > Security tab displays.

- Modify the security policies, if required. For more information, see [Update Security Policies and Rules](#), below.


https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

29

- (For Releases 12.1.1 and later.) To modify the security policy, on the Policies tab, click the policy name.
- (For Releases 11.4.3 and earlier.) To modify the security policy, click the policy name.



- b. (For Releases 12.1.1 and later.) Select the Profiles tab, and then modify the security profiles, if required. For more information, see [Update Security Policies and Rules](#), below.

Edit Master Profile
Configure > Profiles > ... > Basic : Default-Basic-MP-Sub-Tenant

General
Profile
Security
Application
Others
Permissions

Policies
Profiles

Antivirus
Default-AntiVirus.v1

IP Filtering
Default-IPFiltering.v1

IPS
Default-IPS.v1

URL Filtering
Default-URLFiltering.v1

Close
+ Policy
Next

3. Select the Application tab, and then modify the QoS and traffic-steering policies, if required. For more information, see [Configure QoS Policies and Rules](#) and [Configure Traffic-Steering Policies and Rules](#), below.

Edit Master Profile

Default-Basic-MP-Sub-Tenant.v1

General

Profile

Security

Application

Others

Permissions

Sort Policies

QoS

Default-QoS

0 Rules

Traffic Steering

Default-TrafficSteering

0 Rules


Close

+ Policy

Next

- Make other changes in the Others and Permissions tabs.
- Save the subtenant basic master profile.

Disable the LTE Interface

1. In Edit Master Profile > Profile > Network, click the  Ellipses icon in the LTE box, and then select Edit. The Edit Interface screen displays.

Edit Interface

LTE.v1

General

Connection

QoS

Permissions

Name

LTE

Version 1

Description

Type

Physical

Virtual

Enabled

Block ICMP

Category

WAN

Sub Category

Wireless

Standby

Location

Ite-0

APN

PIN

Username

Password

⋮

Close

Next

⋮

- Click the Enabled indicator so that it is grayed out. The LTE interface is disabled.



Enable or Disable DIA on a WAN Interface

1. In Edit Master Profile > Profile > Network, click the interface on which to enable or disable DIA. The Edit Interface screen displays.

Edit Interface
Internet.v1

General **Connection** QoS Permissions

Connection Type: Broadband

Connection Name: Select

Uplink Bandwidth (Kbps) Downlink Bandwidth (Kbps)

Address

IPv4 Interfaces

IPv4 Address automatically assigned

STATIC — ● DHCP

2. In the Connection Name field, configure a name for the interface. Configure the connection name before you change the connection type.
3. In Edit Master Profile > Profile > Network, click the VPN Only icon for the interface you are changing.
4. To enable DIA, click the Internet and VPN (Split Tunnel) icon. To disable DIA, click the VPN Only icon.
5. Select the Permissions tab, and then click Save.

Enable a Speed-Test Server on a WAN Interface

To troubleshoot link speed issues, you can configure a WAN interface to be a speed-test server.

To configure a WAN interface to be a speed-test server:

1. In Edit Master Profile > Profile > Network, click the interface on which to enable the speed-test server. The Edit Interface screen displays.

Edit Interface

Internet.v1

General

Connection

QoS

Permissions

Name

Internet

Version 1

Description

Type

Physical

Virtual

Enabled

Block ICMP

Speed Test Server

Category

WAN

Sub Category

Wired

Location

vni-0/0

VLAN ID

0-4094

Link

Speed

Auto

Mode

AUTO_DUPLEX

MTU

72-9000


Tags

Press Enter to add

Cancel


Next

2. Select the General tab.


3. In the Speed-Test Server field, click the  slider to enable a server.
4. Ensure that the interface category is WAN.
5. Select the Permissions tab, and then click Save.


Update the WiFi Interface Authentication Protocol

1. In Edit Master Profile > Profile > Network, click the WiFi box.



The WLAN screen displays.



2. Click the  Ellipses icon of the WLAN network that you want to update, and then click Edit. The Edit WLAN screen displays.
3. Select the Advanced tab. The following screen displays.

Edit WLAN

Guest-WLAN.v1

General

Advanced

Permissions

Authentication

Protocol

WEP Auto

Key Length

64 Bits

Key Type

HEX

ASCII

Key Text

Show

Encryption

Interface

Name

Guest-WiFi

4. For Wired Equivalent Privacy (WEP)-based authentication, enter information for the following fields.

Edit WLAN

Guest-WLAN.v1

General

Advanced

Permissions

Authentication

Protocol

WEP Auto

Key Length

64 Bits

Key Type

HEX

ASCII

Key Text


Show

Encryption

Interface

Name

Guest-WiFi

Field	Description
Authentication (Group of Fields)	
<ul style="list-style-type: none"> Protocol 	Select the protocol: <ul style="list-style-type: none"> WEP Auto WEP Open WEP Shared Key
<ul style="list-style-type: none"> Key Length 	Select the key length: <ul style="list-style-type: none"> 64 bits 128 bits
<ul style="list-style-type: none"> Key Type 	Use the  slider bar to select the key type: <ul style="list-style-type: none"> ASCII HEX
<ul style="list-style-type: none"> Key Text 	For the ASCII as the key type, enter 5 characters for the key text. For the HEX key type, enter 10 characters for the key text.
Interface Name	Click in the Name field, and then select an interface name.

5. For WiFi Protected Access (WPA)-based authentication, enter information for the following fields.

Enterprise-WLAN.v1

General

Advanced

Permissions

Authentication

Protocol

WPA/WPA2 Auto

Mode

Personal

Enterprise

Passphrase

Should be between 8 and 63 characters.

Hide


Encryption

Auto

Interface

Name

Guest-WiFi


Field	Description
Authentication (Group of Fields)	
<ul style="list-style-type: none"> Protocol 	<p>Select the protocol:</p> <ul style="list-style-type: none"> WPA WPA/WPA2 Auto WPA2
<ul style="list-style-type: none"> Mode 	<p>User the  slider bar to select the mode:</p> <ul style="list-style-type: none"> Enterprise Personal
<ul style="list-style-type: none"> Passphrase 	<p>Enter a passphrase (password), which can be from 8 to 63 characters.</p>

Field	Description
<ul style="list-style-type: none"> Encryption 	Select the encryption type: <ul style="list-style-type: none"> Auto CCMP Temporal Key Integrity Protocol (TKIT)
Interface Name	Click in the Name field and select an interface name.


6. Click Next, or select the Permissions tab, and then Click Save.

Update Security Policies and Rules

1. In the Edit Master Profile screen, select Profile > Security. The Policies tab displays the security policies, if any, that are associated with them.



2. (For Releases 12.1.1 and later.) Select the Profiles tab, and then click a profile name to display information about a profile.



3. To display information about a policy, click the policy name on the Policies tab. The Edit Policy screen displays. The following screenshot shows the Edit IP Filtering Policy screen.

Edit IP Filtering Policy
IPFiltering.v1

General

Rules

Permissions

Name

IPFiltering

Version 1

Type

IP Filtering

Default Action

Allow

Logging

☐

Variables | 0

No variables present

Rules | 0

No Rules Present

Tags

Press Enter to add

Close

Next

- To create a new rule or choose an existing rule for the policy, select the Rules tab. For more information, see [Create a New Rule](#), below.
- To display the inherited permissions for the default roles and change them, if desired, select the Permissions tab.

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

Edit IP Filtering Policy

IPFiltering.v1

General

Rules

Permissions

Enterprise Administrator (Inherited)	Edit
Service Provider Administrator (Inherited)	Edit
Service Provider Operator (Inherited)	Read
Enterprise Operator (Inherited)	Read

Close

Save

6. Click Save.

Configure QoS Policies and Rules

For information about configuring QoS policies and rules, see [Configure QoS Policies and Rules](#).

Configure Traffic-Steering Policies and Rules

For information about configuring traffic-steering policies and rules, see [Configure Traffic-Steering Policies and Rules](#).

Update or Add Services

You can update or add services, including those for BGP peer policy, CGNAT, DHCP, Director service templates, management server policies, user management policies, and VPN instances.

To update or add services:

1. In the Edit Master Profile screen, select Profile > Others. The following screen displays.

Edit Master Profile
Default-Basic-MPv1

General

Profile


Network

Security

Application


Others

Permissions




DHCP

2 DHCP Servers




CGNAT

No Service Present
[+ Add Service](#)




VPN Instance

1 VPN Instance




BGP Peer Policy

No BGP Peer Policies
[+ BGP Peer Policy](#)



Director Service Templates

1 Service Template



Management Servers


No Management Server Policies
[+ Management Servers](#)

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...


Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

48



2. To update an existing DHCP service or add a new DHCP service, click the DHCP box. The DHCP screen displays.



- a. To display or update information about the service, click an existing DHCP service, such as Enterprise-LAN-DHCP.v1 in the screenshot above.
 - b. To add a new DHCP service, click Add Service. You can create a new service or choose an existing service.
3. To update an existing CGNAT service or add a CGNAT service, click CGNAT. In the CGNAT screen, click Add Service to add a new service. You can create a new service or choose an existing service. The Create CGNAT screen displays. Enter information for the following fields.

<

Create CGNAT

V1

General

Criteria

Action

Permissions

Name

Version 1

Network Type

CGNAT

Enable

☐

NAT Mode

Basic NAT

Tenant

Summary

None


Tags

Press Enter to add

⋮ Close

Next ⋮

Field	Description
Name	Enter a name for the CGNAT service.

Field	Description
Enable	<p>The slider bar is in the Enabled position by default. To disable the CGNAT service, click the slider bar so that it is grayed out.</p> 
NAT Mode	<p>Select the NAT mode:</p> <ul style="list-style-type: none"> ◦ Basic NAT. This is the default. ◦ Destination NAT ◦ Dynamic NAT ◦ NAPT ◦ Twice Basic NAT ◦ No Translation <p><i>Default:</i> Basic NAT</p>
Tenant	<p>(For Releases 11.4.1 and later.) Select a tenant. The list displays the current tenant and all child tenants. If a tenant is not selected, the system displays the name of the current tenant only, not any child tenants.</p>

- a. Select the Criteria tab, and then enter information for the following fields.

<

Create CGNAT

V1

General

Criteria

Action

Permissions

Type

Source

▼

Zones

▼

No Zones found.

Add Another

Type

Destination

▼

Zones

▼

No Zones found.

Add Another

Protocols


e.g TCP, UDP, ICMP, AH, ESP or 0 to 255

⋮

Close

Next

⋮

Field	Description
Type (Source)	<p>The Source type is selected by default, and you cannot change it. Select the type of source to use:</p> <ul style="list-style-type: none"> IP Ranges—Enter an IP address range, such as 10.10.1.1-10.10.1.100, and then click the  Check mark icon or press Enter. You can enter multiple address ranges. Subnets—Enter an IP address subnet, such as 10.1.1.0/24. VPN Name—Select a VPN name. Zones—Select a zone.
Type (Destination)	<p>The Destination type is selected by default, and you cannot change it. Select the type of destination to use:</p> <p>Note: The IP Ranges and Subnets options are mutually exclusive; you can select one or the other, but you cannot select both of them.</p> <ul style="list-style-type: none"> IP Ranges—Enter an IP address range, such as 10.10.1.1- 10.10.1.100, then click the Check mark icon or press Enter. You can enter multiple address ranges. Port—Enter a destination port number. <i>Range:</i> 1 through 65535 <i>Default:</i> None Port Range—Enter a destination port range, such as 80-88. Subnets—Enter an IP address subnet, such as 10.1.1.0/24. Zones—Select a zone.
Protocols	<p>Select one or more protocols:</p> <ul style="list-style-type: none"> ESP ICMP UDP 0 through 255

b. Select the Action tab, and then enter information for the following fields.

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

<

Create CGNAT

V1

General

Criteria

Action

Permissions

Logging

Translated Sources

VPN Name

▼

Select VPN Name

IP Addresses

▼





IP Addresses e.g. 10.1.1.1

⋮

Close


Next

⋮

Field	Description
Logging	Click the  slider bar to enable logging to Versa Analytics.
Translated Sources	<p>Select the translated sources based on VPN names or WAN connections:</p> <ul style="list-style-type: none"> VPN Name—Select a VPN name. WAN Connection—Select a WAN connection. <p>Select the translated sources from IP addresses, subnets, or IP address ranges:</p> <ul style="list-style-type: none"> IP Addresses—Enter an IP address, and then click the  Check mark icon or press Enter. You can enter multiple IP addresses. IP Ranges—Enter an IP address range, and then click the  Check mark icon or press Enter. You can enter multiple IP address ranges. Subnets—Enter an IP subnet, and then the  Check mark icon or press Enter. You can enter multiple IP subnets.

- c. Select the Permissions tab, and revise the permissions, if needed.
- d. Click Save to create the CGNAT service.

4. To display existing VPN instances or add new VPN instances, click VPN. The VPN Instances screen displays.



- a. To display or update information about the instance, click an existing VPN instance.

- b. In the Type field, select Branch or Hub.

- c. To set or update the topology, click VPN and then select a topology. If you selected Hub in the Type field, the topology options are hidden.

- d. Under Paths, select Direct Internet, Underlay, or both:

Direct Internet—Enable or disable DIA for the VPN. If you enable Gateway, the appliance acts as an internet gateway for the enterprise and re-advertises default routes on the SD-WAN overlay to other appliances.

Paths

☒ Direct Internet ?

☐ Gateway

▼ Select WAN Connections ?

Circuit	Priority
Internet-1	1

[Add Another](#)

Underlay—Enable or disable underlay routing to non-SD-WAN appliances over the MPLS network without performing NAT on the traffic. If you enable Gateway, the appliance acts as a gateway to non-SD-WAN networks and re-advertises routes from the MPLS underlay to the SD-WAN overlay.

Paths

☐ Direct Internet ?

☒ Underlay ?

☐ Gateway

▼ Select WAN Connections ?

Circuit	Priority
	1

[Add Another](#)

- To update an existing BGP peer policy or add a new policy, click + BGP Peer Policy. If you refer to a BGP peer policy in the BGP neighbor configuration on a WAN or LAN interface, you should attach the peer policy to the BGP peer policies list. For more information, see [Configure SASE BGP Peer Policies](#).

Edit Master Profile
Default-Basic-MPv1

General

Profile

Network

Security

Application

Others

Permissions

DHCP

3 DHCP Servers

CGNAT

No Service Present

VPN Instance

2 VPN Instances


BGP Peer Policy

No BGP Peer Policies
[+ BGP Peer Policy](#)


Director Service Templates

1 Service Template

6. To add or move a Director service template, click Director Service Templates. The following screen displays.




- a. To move a service template up or down in the list, click Move. The following screen displays.



The dialog box is titled "Move Rule Master Profiles" with a double-headed vertical arrow icon. It contains two main input areas. The first area has a dropdown menu currently set to "Before" and a text input field labeled "Rule Number (1 to 1)". The second area has a text input field labeled "Search for Rule". A vertical line with the word "OR" in the center separates the two input areas. At the bottom, there are two buttons: "Cancel" and "Move".

- b. To choose which direction to move the rule, click Before or After.
- c. Enter the rule number.
- d. Click Move.
- e. To add a service template, click + Select Templates. The following screen displays the available templates.



- f. Select one or more service templates, and then click Add. The template is added to the Director Service Templates screen.

7. For Releases 11.1.1 and later, to update management server policies for NTP, SNMP, syslog, and TACACS+, or

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...


Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

to add a new management server policy, click + Management Servers. For more information, see [Configure Management Servers](#).



8. For Releases 11.3.1 and later, to create a user management policy or associate an existing user management policy with the master profile to add and manage VOS device users, click + User Management. For more information, see [Manage VOS Users](#).



9. For Releases 11.3.1 and later, to apply different services templates to the devices in a master profile for redundant devices:
 - a. Go to Configure > Profiles > Master Profiles, and select a master profile for redundant devices.
 - b. In the Edit Master Profile screen, click Profile > Others.
 - c. Under Director Service Templates, click the Service Template box. The Director Service Templates screen displays the tenant's current service templates.
 - d. Click + Service Templates in the lower right corner of the screen. The Choose Service Template screen displays the available service templates.
 - e. Select one or more service templates, and then click Add. The templates are added to the Director Service Templates screen. By default, the service templates are added to both the primary and secondary devices in the redundant configuration. Note that the Appliance Type column displays only when you are editing a master profile for redundant devices.

Director Service Templates			
Default-Active-Active.v1			
Sync Service Templates			
Name	Category	Appliance Type	
1 :: Master Profile	-	3 Variables	-
2 :: NGFW	NextGen Fir...	1 Variables	Both


- f. To apply the service template to only one of the redundant devices, click the drop-down list and then select either the Primary or Secondary device in the pair.

2 :: NGFW	NextGen Fir...	1 Variables	Both	New	
-----------	----------------	-------------	------	-----	--

Both
Primary
Secondary

Clone the Default Basic Master Profile

You can create a new basic master profile by cloning one of the default basic master profiles, changing the configuration objects as needed, and saving the new basic master profile with a unique name. For example, you could create a new master profile to apply to hub appliances, and a second new master profile to apply to spoke appliances.


Clone Basic Master Profile Default-Basic-MP

Copy_of_Default-Basic-MP


Cancel Submit

Enter a new name for the master profile, then click Submit. You can then edit the new basic master profile as needed. For information on the master profile screens, see [Add a Standard Master Profile](#), below.


Add a Standard Master Profile

To add a standard master profile:

1. In Tenants view, select the name of a tenant. If the default lifecycle is not the Configure lifecycle, select Configure in the left menu bar. The Configure screen displays.



2. To create a new master profile of type Standard, click Configure > Profiles > Master Profiles > Standard, and then click + Standard.



The New Master Profile screen displays.

New Master Profile

V1

General

Sub Profiles

Director Service Templates

Permissions

Name

Version 1

Type

Standard

Scope

Single Tenant

Solution Tier

Select

Variables | 0


No variables present

Profiles | 0

Close

Next

3. In the Name field, enter a name for the new master profile.
4. In the Solution Tier field, select a Versa licensing solution tier.
5. For Releases 11.2.1 and later, in the Scope field, select if the master profile is for single tenant, multitenant, or subtenant. By default, Single Tenant is selected.
6. Click Next. The Subprofiles tab displays.
7. Click + Profile to add a subprofile to the master profile. You can create a new subprofile or reuse an existing one.



Reuse an Existing Subprofile

To reuse an existing subprofile in a new master profile:

1. In New Master Profile > Subprofiles tab, click Choose Existing. The Choose Subprofiles screen displays.

Choose SubProfiles

Device | 6

Branch-Devices.v2

HQ.v1

Hub-Devices.v1

STORE.v1

SUPERSTORE.v1

WAREHOUSE.v1

Security | 6

Topology | 6

HQ.v1

HUB.v1

Hubs.v1

STORE.v1

STORE-SMALL.v1

WAREHOUSE.v1

Network Service | 7

HQ-SERVICES.v3

HQ-SERVICES.v2

STORE-SERVICES.v3

STORE-SERVICES.v2

SUPERSTORE-SERVICES.v2

SUPERSTORE-SERVICES.v1

WAREHOUSE-SERVICES.v2

Application | 3

⋮ Cancel


Add

2. Select one or more existing subprofiles to use in the new master profile.
3. Click Add.

Create a New Subprofile

To create a new subprofile to use in a new master profile:

1. In the New Master Profile > Subprofiles tab, click + Profile. The following popup window displays.



2. Click the down arrow, select a profile type. The profile types are Security, Application, Device, Network Services, Topology, and, for Releases 11.3.1 and later, System.
3. Click Create New Profile. The Create *Type* Subprofile screen displays. The following screenshot shows the Create Security Subprofile screen.

Create Security Sub Profile

General

Policy

Permissions

Name

Version 1

Type

Security

Variables | 0

No variables present

Policies | 0

No Policies present

Tags

⋮


Close

Next

⋮

4. Enter a name for the subprofile.
5. Select the Policy tab or click Next. The Policy screen displays.

6. Click + Policy to create a new policy or to reuse an existing one.



Reuse an Existing Policy

To reuse an existing policy:

1. Click Choose Existing. The Choose Policies screen displays.

Choose Policies

v1

☐ Access Control | 7

Select All

East-Security-Policy.v1

ACL-IPF-URLF-AV-IPS-P4.v5

ACL-IPF-URLF-AV-P3.v4

ACL-IPF-URLF-P2.v3

ACL-URLF-P1.v2

Test1.v2

Test1.v1

☐ IP Filtering | 1

Select All

IPF-P1.v1

☐ URL Filtering | 4

Select All

advanced.v4

URLF-P1.v1

low.v2

standard.v2

☐ IPS | 1

Select All

IPS-P1.v1

☐ Antivirus | 1

Select All

AV-P1.v1

Cancel


Add

2. Select one or more existing policies.
3. Click Add.

Create a New Policy

To create a new policy:

1. Select a policy type, and then click Create New Policy.



The Create Policy screen displays, and the General tab is selected. The following screenshot shows the Create IP Filtering Policy screen.

<

Create IP Filtering Policy

General

Rules

Permissions

Name

Version 1

Type

IP Filtering

Default Action

Allow

Logging

☐

Variables | 0

No variables present


Rules | 0

No Rules Present


Tags

Press Enter to add

2. Enter a name for the new policy.
3. Click Next. The Rules tab displays. You can create a new rule or reuse an existing one.




4. Click Add Rule.



Reuse an Existing Rule

To reuse an existing rule:

1. Click Choose Existing Rule. The Choose Rules screen displays.



2. Select one or more existing rules.

3. Click Add.

Create a New Rule

To create a new rule:

1. Click Create New. The Create Rule screen displays. The following screenshot shows the Create IP Filtering Rule screen.

< **Create IP Filtering Rule**
V1

General Criteria Action Permissions

Rule Name Version 1

Rule Type
IP Filtering

Summary
None

Tags
Press Enter to add

2. Enter a name for the rule.
3. Click Next. The Criteria tab displays. In the Criteria Type field, enter information for the following fields.

<

Create IP Filtering Rule

V1

General

Criteria

Action

Permissions

Rule: newIPfilteringRule

Criteria Type

Address Group

Field	Description
Address Group	Click in the field to the right of Address Group and select a group. You can select multiple address groups.
Location	<div><div>Criteria Type</div><div>Location</div><div>Match Type</div><div>Match Only Source</div></div> <div>Click in the field to the right of Location, and then select a location. Then, in the Match Type field, select a match type:<ul style="list-style-type: none">Match Only SourceMatch Only DestinationMatch Source or DestinationMatch Source and Destination</div>
Reputation	Click in the field to the right of Reputation, and then select one or more reputations.

4. Click Next. The Actions tab displays.

The screenshot shows the 'Create IP Filtering Rule V1' interface. At the top, there's a title bar with a back arrow and the title 'Create IP Filtering Rule V1'. Below this is a tabbed interface with four tabs: 'General', 'Criteria', 'Action' (which is selected and highlighted with a red box), and 'Permissions'. Under the 'Action' tab, there's a light blue box containing the text 'Rule: newIPfilteringRule'. Below this, there's a grey box with the label 'Action' on the left and 'Drop Session' in the center. To the right of 'Drop Session' is a dropdown arrow icon, which is also highlighted with a red box.

5. In the Action field, select an action:

- Drop Packet
- Drop Session
- Allow
- Alert
- Reject

6. Click Save.

Configure a Multitenant Standard Master Profile

For Releases 11.2.1 and later.

A multitenant master profile allows you to create multitenant appliances for a provider organization. You can create new subtenants and you can attach existing subtenants while publishing the provider organization appliance that uses the multitenant master profile. Appliances are automatically created in the subtenants associated with the provider appliance that uses a multitenant master profile.

To configure a multitenant standard master profile:

1. Configure a standard multitenant with the scope Multitenant. Go to
 - a. Go to New Master Profile > General.

New Master Profile
V1

General Sub Profiles Director Service Templates Permissions

Name
MultiTenant-Master-Profile-1 Version 1

Type
Standard

Solution Tier
Work-From-Home

Scope
Multi Tenant

Variables | 0
No variables present

Profiles | 0

Close Next ⋮

- b. Enter a name for the profile.
 - c. Select the solution tier.
 - d. In the Scope field, select Multitenant.
 - e. Click Next.
2. Configure a device subprofile to add LAN Interfaces for the subtenants you want to onboard.
 - a. Go to New Master Profile > Subprofiles, click + Profile, select Device, and then click Create New Profile.

New Master Profile

V1

General

Sub Profiles

Director Service Templates

Permissions

No Sub Profiles present

+ Profile

Device

OR

Create New Profile

Choose Existing

Close

Next

- b. In Create Device Subprofile > General, enter a name for the subprofile.

- c. Click Next.
- d. In the Policy tab, click + Policy, select Interface, and then click Create New Policy. The Create Interface Policy screen displays.

The screenshot shows the 'Create Device Sub Profile' configuration page with the 'Policy' tab selected. The page has a light blue header with a back arrow and the title 'Create Device Sub Profile'. Below the header are three tabs: 'General', 'Policy' (active), and 'Permissions'. The main content area shows 'No Policies present' in a grey box. Below this is a '+ Policy' button. A modal dialog is open, showing a dropdown menu with 'Interface' selected, followed by 'OR', and then two options: 'Create New Policy' and 'Choose Existing'. The bottom of the screen has a light blue bar with a 'Cancel' button, a 'Next' button, and a three-dot menu icon.

- e. In Create Interface Policy > General, enter a name for the interface policy.

Create Interface Policy

General

Interfaces

Permissions

Name

Interface1

Version 1

Type

Interface

Variables | 0

No variables present

Interfaces | 0

No Interfaces Present

Tags

Press Enter to add


⋮

Cancel

Next

⋮

- f. Click Next. The Interfaces tab displays.



- g. Click Add Interface and then click Create New. The Create Interface screen displays. You can also choose an existing interface.
- h. The Create Interface screen displays.

- iii. In the Subtenant field, select the subtenant for which you are creating the subtenant LAN interface.
- iv. Enter other required information.
- v. Click Next.
- i. The Address and Routing tab displays.

Create Interface
V1

General **Address and Routing** QoS Permissions

Address

IPv4 Address STATIC ☒ DHCP

10.10.10.12/24

DHCP Relay ☐ VRRP ☐

Add IPv6 Address

Guest Interface ☐ VPN Name
SF-Enterprise

> Static Routes

> Routing Protocol

Cancel Next

- i. Enter the IPv4 address for the LAN interface.
- ii. Select the VPN of the tenant in the VPN Name field. The VPN of the tenant you selected in the General tab is displayed by default.
- iii. Click Next
- j. Enter other information, if required.
- k. Save the subtenant LAN interface. The interface that you added is displayed under subtenant LAN. For example:

Create Interface Policy
Interface-1v1

General **Interfaces** Permissions

SUBTENANT LAN

LAN-Interface-1v1 Custom	0 Variables	New ⋮
----------------------------	-------------	-------

[Add Interfaces](#)

⋮ Cancel Next ⋮

- I. Repeat this step for other subtenant LANs.
3. Create a Topology subprofile to add a VPN policy and VPN instances to associate subtenant VPNs with the standard master profile.
 - a. In New Master Profile > Subprofiles, click + Profile. Then select Topology, and click Create New Profile. The Create Topology Subprofile screen displays.

New Master Profile

MultiTenant-Master-Profile-1.v1

General

Sub Profiles

Director Service Templates

Permissions

No Sub Profiles present

+ Profile

Topology

OR

Create New Profile

Choose Existing

Close

Next

- b. In Create Topology Subprofile > General, enter a name for the subprofile.

The screenshot shows a mobile application interface for creating a topology sub-profile. The title bar at the top says "Create Topology Sub Profile" with a back arrow on the left. Below the title bar are three tabs: "General", "Policy" (which is selected and highlighted with a blue underline), and "Permissions". The main content area has a light gray background with the text "No Policies present" in the center. Below this text is a red-outlined button labeled "+ Policy". A dropdown menu is open from this button, showing a light blue background. Inside the dropdown, the word "VPN" is displayed with a small checkmark to its right. Below "VPN" is a dashed line, and underneath that are two options: "Create New Policy" and "Choose Existing". The bottom of the screen features a light blue bar with a "Close" button on the left, a "Next" button in the center, and a menu icon (three dots) on the right.

- e. In Create VPN Policy > General, enter a name for the VPN policy.

<

Create VPN Policy

General

VPN Instances

Permissions

Name

VPN-Policy-1

Version 1

Type

VPN

Variables | 0

No variables present

VPN Instances | 0

No Rules Present

Tags

Press Enter to add


⋮

Cancel

Next

⋮

- f. Click Next.
- g. In the VPN Instances tab, click Add VPN Instance > Create New. To select existing VPN instances, click Choose VPN Instance.



h. Select Create VPN Instance > General.

Create VPN Instance

V1

General

Permissions

Element Name

VPN-SF-1

Version 1

Type ?

Branch

VPN

Tenant

SF

Name ?

SF-Enterprise

Topology

Full Mesh

Scope

Enterprise

Spoke Communities

Paths

☒ Direct Internet ?
 ☐ Gateway

Select WAN Connections ?

Circuit

Priority

1

Add Another

☐ Underlay ?

> Application Monitoring

Cancel

Next

- i. Enter a name for the VPN instance for the tenant.
- ii. Under VPN, select the subtenant for which to create VPN instance.
- iii. Select the name of the VPN connection. The VPN connection of the subtenant selected is displayed by

https://docs.versa-networks.com/Secure_SD-WAN/02_Configuration_from_Concerto/Secure_SD-WAN_Configuration/Config...

Updated: Wed, 23 Oct 2024 08:04:44 GMT

Copyright © 2024, Versa Networks, Inc.

92

default.

- iv. Enter other required information.
- v. Click Next and save the VPN instance. The VPN instance displays in the VPN Instances screen.

The screenshot shows the 'Create VPN Policy' interface for 'VPN-Policy-1.v1'. It has three tabs: 'General', 'VPN Instances' (selected), and 'Permissions'. Under 'Tenant: Tenant1', there is a table with one entry: 'VPN-SF-1.v1 | Custom' (highlighted with a red box), '0 Variables', and a 'New' button with a dropdown arrow. Below the table is a link 'Add VPN Instance'. At the bottom, there are 'Cancel' and 'Next' buttons with dropdown arrows.

Create VPN Policy		
VPN-Policy-1.v1		
General	VPN Instances	Permissions
Tenant: Tenant1		
<div>VPN-SF-1.v1 Custom</div> <div>0 Variables</div> <div>New ⋮</div>		
Add VPN Instance		
⋮ Cancel		Next ⋮

- vi. Repeat this step for all subtenant VPNs.
- i. Click Next. In the Permissions tab, set the permissions.
- j. Save the VPN Policy. The VPN policy displays in the Policy tab.

The screenshot shows a mobile application interface for creating a topology subprofile. The title bar at the top is light blue and contains a back arrow, the text 'Create Topology Sub Profile', and the identifier 'dafdas.v1'. Below the title bar are three tabs: 'General', 'Policy' (which is selected and highlighted with a blue underline), and 'Permissions'. The main content area is titled 'VPN Policy | 1' and contains a single policy entry. This entry is highlighted with a red rectangular box and consists of a blue square containing the number '1', followed by the text ':: VPN-Policy-1.v1 | Custom 1 VPN'. To the right of this entry is a grey button with a right-pointing chevron, the text 'Variables | 0', and a vertical ellipsis icon. At the bottom of the screen is a light blue bar containing a vertical ellipsis icon, the text 'Cancel', a blue button with a plus sign and the text '+ Policy', a blue button with the text 'Next', and another vertical ellipsis icon.

- k. Click Next. In the Permissions tab, set the permissions as required and then save the Topology subprofile.

New Master Profile

V1

General

Sub Profiles

Director Service Templates

Permissions

Name

Sub-Tenant-Master-Profile-1

Version 1

Type

Standard

Solution Tier

Work-From-Home

Scope

Sub Tenant

Variables | 0


No variables present

Profiles | 0

Close

Next

2. Enter a name for the profile.
3. Select the solution tier.
4. In the Scope field, select subtenant.
5. Click Next.
6. In the Subprofiles tab, click + Profile, select Application or Security, and then click Create New Profile. Application and Security are the only subprofile options available for a subtenant standard master profile.



7. Enter other required information.
8. Save the subtenant standard master profile.
9. Deploy the appliance associated to the standard master profile. For more information, see [Concerto Deploy Lifecycle Overview](#).

Supported Software Information

Releases 10.2.1 and later support all content described in this article, except:

- Release 11.2.1 adds support for a new default basic master subtenant profile, Default-Basic-MP-Sub-Tenant, and for multitenancy configuration in the Default-Active-Active and Default-Basic-MP basic master profiles.

Additional Information

[Configuration Hierarchies](#)

[Configure Profile Elements](#)

[Configure QoS Policies and Rules](#)

[Configure TCP Optimizations](#)

[Configure Traffic-Steering Policies and Rules](#)