

---

## Initial Software Configuration Overview



For supported software information, click [here](#).

To configure the Versa Operating System™ (VOS™) software for the first time on branch devices, you perform the following steps:

1. Configure basic features, including organizations, templates, devices, and device groups. See [Configure Basic Features](#).
2. Optionally, configure a public cloud device to be a virtual CPE router or an SD-WAN gateway. Normally, the VOS devices that you receive are preconfigured with this information. If they are not, perform this step. See [Configure a Public Cloud Device To Be a Virtual CPE Router or an SD-WAN Gateway](#).
3. Configure and activate branch VOS devices using ZTP. See [Activate VOS Devices](#).
4. Configure additional VOS software features on the VOS devices branch device. For more information, see [Versa VOS SD-WAN Configuration](#), [Versa VOS Network and System Configuration](#), and [Versa VOS Security Configuration](#).

The initial software configuration procedure is the same for software Releases 20.2 and later.

You can configure VOS devices from Concerto and from the Director GUI. For information, see [Concerto Home Screen Overview](#) and [Director GUI Overview](#).

---

## Supported Software Information

Releases 20.2 and later support all content described in this article.

---

## Additional Information

[Director GUI Overview](#)

[Licensing Overview](#)