



Figure 11-42 FlashCopy mapping preset selection

When selecting a preset, some options, such as Background Copy Rate, Incremental, and Delete mapping after completion, are automatically changed or selected. You can still change the automatic settings, but this is not recommended for the following reasons:

- For example, if you select the **Backup** preset but then clear **Incremental** or select **Delete mapping after completion**, you lose the benefits of the incremental FlashCopy. You must copy the entire source volume each time you start the mapping.
- As another example, if you select the **Snapshot** preset but then change the **Background Copy Rate**, you have with a full copy of your source volume.

For more information about the Background Copy Rate and Cleaning Rate options, see Table 11-1 on page 448 or see Table 11-5 on page 457.

5. When your FlashCopy mapping setup is ready, click **Finish**.

## 11.2.9 Showing related Volumes

To show related volumes for a specific FlashCopy mapping, complete the following steps:

1. Open the Copy Services FlashCopy Mappings window.
2. Right-click a FlashCopy mapping and select **Show Related Volumes**, as shown in Figure 11-43 on page 486. Also, depending on which window you are inside Copy Services, you can right-click the mappings and select **Show Related Volumes**.