



# **Netbooting and setting up ONTAP on the new controller module**

## **ONTAP MetroCluster**

Ivana Devine, Thom Illingworth  
August 27, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-metrocluster/upgrade/task\\_netboot\\_and\\_set\\_up\\_ontap\\_on\\_the\\_new\\_controller\\_module\\_mcc.html](https://docs.netapp.com/us-en/ontap-metrocluster/upgrade/task_netboot_and_set_up_ontap_on_the_new_controller_module_mcc.html) on September 24, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

Netbooting and setting up ONTAP on the new controller module ..... 1

# Netbooting and setting up ONTAP on the new controller module

You must perform a specific sequence of steps to netboot and install the ONTAP operating system on the new controller module when adding controller modules to an existing MetroCluster configuration.

### About this task

- This task starts at the LOADER prompt of the new controller module.
- This task includes initializing disks.


The amount of time you need to initialize the disks depends on the size of the disks.

- The system automatically assigns two disks to the new controller module.

[Disk and aggregate management](#)

### Steps

1. At the LOADER prompt, configure the IP address of the new controller module based on DHCP availability:

If DHCP is...	Then enter the following command...
Available	<code>ifconfig e0M -auto</code>
Not available	<div><pre>ifconfig e0M -addr=<i>filer_addr</i> - mask=<i>netmask</i> -gw=<i>gateway</i> -dns=<i>dns_addr</i> -domain=<i>dns_domain</i></pre><p><i>filer_addr</i> is the IP address of the storage system.</p><p><i>netmask</i> is the network mask of the storage system.</p><p><i>gateway</i> is the gateway for the storage system.</p><p><i>dns_addr</i> is the IP address of a name server on your network.</p><p><i>dns_domain</i> is the Domain Name System (DNS) domain name. If you use this optional parameter, you do not need a fully qualified domain name in the netboot server URL; you need only the server's host name.</p><div> Other parameters might be necessary for your interface. For details, use the <code>help ifconfig</code> command at the LOADER prompt.</div></div>

2. At the LOADER prompt, netboot the new node:

For...	Issue this command...
FAS2200, FAS2500, FAS3200, FAS6200, FAS/AFF8000 series systems	netboot <code>http://web_server_ip/path_to_web-accessible_directory/netboot/kernel</code>
All other systems	netboot <code>http://web_server_ip/path_to_web-accessible_directory/&lt;ontap_version&gt;_image.tgz</code>

The `path_to_the_web-accessible_directory` is the location of the downloaded `<ontap_version>_image.tgz` file.

3. Select the **Install new software first** option from the displayed menu.

This menu option downloads and installs the new ONTAP image to the boot device.

- You should enter **y** when prompted with the message that this procedure is not supported for nondisruptive upgrade on an HA pair.
- You should enter **y** when warned that this process replaces the existing ONTAP software with new software.
- You should enter the path as follows when prompted for the URL of the image.tgz file:

`http://path_to_the_web-accessible_directory/image.tgz`

4. Enter **y** when prompted regarding nondisruptive upgrade or replacement of the software.

5. Enter the path to the image.tgz file when prompted for the URL of the package.

```
What is the URL for the package? `http://path_to_web-  
accessible_directory/image.tgz`
```

6. Enter **n** to skip the backup recovery when prompted to restore the backup configuration.

```

*****
*               Restore Backup Configuration               *
* This procedure only applies to storage controllers that  *
* are configured as an HA pair.                            *
*                                                         *
* Choose Yes to restore the "varfs" backup configuration  *
* from the SSH server. Refer to the Boot Device Replacement *
* guide for more details.                                *
* Choose No to skip the backup recovery and return to the  *
* boot menu.                                              *
*****

Do you want to restore the backup configuration
now? {y|n} `n`

```

7. Enter **y** when prompted to reboot now.

```

The node must be rebooted to start using the newly installed software.
Do you want to
reboot now? {y|n} `y`

```

8. If necessary, select the option to **Clean configuration and initialize all disks** after the node has booted.

Because you are configuring a new controller module and the new controller module's disks are empty, you can respond **y** when the system warns you that this will erase all disks.



The amount of time needed to initialize disks depends on the size of your disks and configuration.

9. After the disks are initialized and the Cluster Setup wizard starts, set up the node:

Enter the node management LIF information on the console.

10. Log in to the node, and enter the `cluster setup` and then enter `join` when prompted to join the cluster.

```

Do you want to create a new cluster or join an existing cluster?
{create, join}: `join`

```

11. Respond to the remaining prompts as appropriate for your site.

The [Software Setup Guide](#) for your version of ONTAP contains additional details.

12. If the system is in a two-node switchless cluster configuration, create the cluster interfaces on the existing node using the network interface create command to create cluster LIFs on the cluster ports.

The following is an example command for creating a cluster LIF on one of the node's cluster ports. The

-auto parameter configures the LIF to use a link-local IP address.

```
cluster_A::> network interface create -vserver Cluster -lif clus1 -role
cluster -home-node node_A_1 -home-port el1 -auto true
```

13. After setup is complete, verify that the node is healthy and eligible to participate in the cluster:

```
cluster show
```

The following example shows a cluster after the second node (cluster1-02) has been joined to it:

```
cluster_A::> cluster show
Node                               Health  Eligibility
-----
node_A_1                           true    true
node_A_2                           true    true
```

You can access the Cluster Setup wizard to change any of the values you entered for the admin storage virtual machine (SVM) or node SVM by using the cluster setup command.

14. Confirm that you have four ports configured as cluster interconnects:

```
network port show
```

The following example shows output for two controller modules in cluster\_A:

```
cluster_A::> network port show
```

						Speed
(Mbps)						
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper
-----	-----	-----	-----	-----	-----	
-----						
node_A_1						
	**e0a	Cluster	Cluster	up	9000	
auto/1000						
	e0b	Cluster	Cluster	up	9000	
auto/1000**						
	e0c	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	e0f	Default	Default	up	1500	auto/1000
	e0g	Default	Default	up	1500	auto/1000
node_A_2						
	**e0a	Cluster	Cluster	up	9000	
auto/1000						
	e0b	Cluster	Cluster	up	9000	
auto/1000**						
	e0c	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	e0f	Default	Default	up	1500	auto/1000
	e0g	Default	Default	up	1500	auto/1000
14 entries were displayed.						

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.