



Replacing a Cisco FC switch

ONTAP MetroCluster

Ivana Devine
April 21, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task_replace_a_cisco_fc_switch_mcc.html on September 24, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Replacing a Cisco FC switch 1

Replacing a Cisco FC switch

You must use Cisco-specific steps to replace a failed Cisco FC switch.

You need the admin password and access to an FTP or SCP server.

This procedure is nondisruptive and takes approximately two hours to complete.

In the examples in this procedure, FC_switch_A_1 is the healthy switch and FC_switch_B_1 is the impaired switch. The switch port usage in the examples is shown in the following table:

Role	Ports
FC-VI connections	1, 4
HBA connections	2, 3, 5, 6
FC-to-SAS bridge connections	7, 8
ISL connections	36, 40

The examples show two FC-to-SAS bridges. If you have more, you must disable and subsequently enable the additional ports.

Your switch port usage should follow the recommended assignments.

- [Port assignments for FC switches when using ONTAP 9.0](#)
- [Port assignments for FC switches when using ONTAP 9.1 and later](#)

Steps

1. Disable the ISL ports on the healthy switch to fence off the impaired switch.

These steps are performed on the healthy switch.

- a. Enter configuration mode:

```
conf t
```

- b. Disable the ISL ports on the healthy switch with the `interface` and `shut` commands.

```
FC_switch_A_1# conf t
FC_switch_A_1(config)# interface fc1/36
FC_switch_A_1(config)# shut
FC_switch_A_1(config)# interface fc1/40
FC_switch_A_1(config)# shut
```

- c. Exit configuration mode and copy the configuration to the startup configuration.

```
FC_switch_A_1(config)# end
FC_switch_A_1# copy running-config startup-config
FC_switch_A_1#
```

2. Fence off the FC-VI and HBA ports on the impaired switch (if it is still running).

These steps are performed on the impaired switch.

a. Enter configuration mode:

conf t

b. If the impaired switch is still operational, disable the FC-VI and HBA ports on the impaired switch with the interface and shut commands.

```
FC_switch_B_1(config)# interface fc1/1
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/4
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/2-3
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/5-6
FC_switch_B_1(config)# shut
```

c. Exit configuration mode and copy the configuration to the startup configuration.

```
FC_switch_B_1(config)# end
FC_switch_B_1# copy running-config startup-config
FC_switch_B_1#
```

3. If the impaired switch is still operational, determine the WWN for the switch:

show wwn switch

```
FC_switch_B_1# show wwn switch
Switch WWN is 20:00:54:7f:ee:e3:86:50
FC_switch_B_1#
```

4. Boot and preconfigure the replacement switch, prior to physically installing it.

At this point the replacement switch is not cabled to the MetroCluster configuration. The ISL ports on the partner switch are disabled (in shut mode) and offline.

a. Power on the replacement switch and let it boot up.

b. Check the firmware version on the replacement switch to confirm that it matches the version of the other FC switches:

show version

- c. Configure the replacement switch as described in the *MetroCluster Installation and Configuration Guide*, skipping the “Configuring zoning on a Cisco FC switch” section.

Fabric-attached MetroCluster installation and configuration

You will configure zoning later in this procedure.

- d. Disable the FC-VI, HBA, and storage ports on the replacement switch.

```
FC_switch_B_1# conf t
FC_switch_B_1(config)# interface fc1/1
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/4
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/2-3
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/5-6
FC_switch_B_1(config)# shut
FC_switch_B_1(config)# interface fc1/7-8
FC_switch_B_1(config)# shut
FC_switch_B_1# copy running-config startup-config
FC_switch_B_1#
```

5. Physically replace the impaired switch:

- a. Power off the impaired switch.
- b. Power off the replacement switch.
- c. Uncable and remove the impaired switch, carefully noting which cables connected to which ports.
- d. Install the replacement switch in the rack.
- e. Cable the replacement switch exactly as the impaired switch was cabled.
- f. Power on the replacement switch.

6. Enable the ISL ports on the replacement switch.

```
FC_switch_B_1# conf t
FC_switch_B_1(config)# interface fc1/36
FC_switch_B_1(config)# no shut
FC_switch_B_1(config)# end
FC_switch_B_1# copy running-config startup-config
FC_switch_B_1(config)# interface fc1/40
FC_switch_B_1(config)# no shut
FC_switch_B_1(config)# end
FC_switch_B_1#
```

7. Verify that the ISL ports on the replacement switch are up:

show interface brief

8. Adjust the zoning on the replacement switch to match the MetroCluster configuration:

a. Distribute the zoning information from the healthy fabric.

In this example, FC_switch_B_1 has been replaced and the zoning information is retrieved from FC_switch_A_1:

```
FC_switch_A_1(config-zone)# zoneset distribute full vsan 10
FC_switch_A_1(config-zone)# zoneset distribute full vsan 20
FC_switch_A_1(config-zone)# end
```

b. On the replacement switch, verify that the zoning information was properly retrieved from the healthy switch:

show zone

```
FC_switch_B_1# show zone
zone name FC-VI_Zone_1_10 vsan 10
  interface fc1/1 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/4 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/1 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/4 swwn 20:00:54:7f:ee:b8:24:c0

zone name STOR_Zone_1_20_25A vsan 20
  interface fc1/2 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/3 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/5 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/6 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/2 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/3 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/5 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/6 swwn 20:00:54:7f:ee:b8:24:c0

zone name STOR_Zone_1_20_25B vsan 20
  interface fc1/2 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/3 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/5 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/6 swwn 20:00:54:7f:ee:e3:86:50
  interface fc1/2 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/3 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/5 swwn 20:00:54:7f:ee:b8:24:c0
  interface fc1/6 swwn 20:00:54:7f:ee:b8:24:c0
FC_switch_B_1#
```

c. Find the WWNs of the switches.

In this example, the two switch WWNs are as follows:

- FC_switch_A_1: 20:00:54:7f:ee:b8:24:c0
- FC_switch_B_1: 20:00:54:7f:ee:c6:80:78

```
FC_switch_B_1# show wwn switch
Switch WWN is 20:00:54:7f:ee:c6:80:78
FC_switch_B_1#

FC_switch_A_1# show wwn switch
Switch WWN is 20:00:54:7f:ee:b8:24:c0
FC_switch_A_1#
```

d. Remove zone members that do not belong to the switch WWNs of the two switches.

In this example, no member interface in the output shows that the following members are not associated with the switch WWN of either of the switches in the fabric and must be removed:

- zone name FC-VI_Zone_1_10 vsan 10
 - interface fc1/1 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/2 swwn 20:00:54:7f:ee:e3:86:50
 - zone name STOR_Zone_1_20_25A vsan 20
 - interface fc1/5 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/8 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/9 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/10 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/11 swwn 20:00:54:7f:ee:e3:86:50
 - zone name STOR_Zone_1_20_25B vsan 20
 - interface fc1/8 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/9 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/10 swwn 20:00:54:7f:ee:e3:86:50
 - interface fc1/11 swwn 20:00:54:7f:ee:e3:86:50
- The following example shows the removal of these interfaces:

```

FC_switch_B_1# conf t
FC_switch_B_1(config)# zone name FC-VI_Zone_1_10 vsan 10
FC_switch_B_1(config-zone)# no member interface fc1/1 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/2 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# zone name STOR_Zone_1_20_25A vsan 20
FC_switch_B_1(config-zone)# no member interface fc1/5 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/8 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/9 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/10 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/11 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# zone name STOR_Zone_1_20_25B vsan 20
FC_switch_B_1(config-zone)# no member interface fc1/8 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/9 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/10 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# no member interface fc1/11 swwn
20:00:54:7f:ee:e3:86:50
FC_switch_B_1(config-zone)# save running-config startup-config
FC_switch_B_1(config-zone)# zoneset distribute full 10
FC_switch_B_1(config-zone)# zoneset distribute full 20
FC_switch_B_1(config-zone)# end
FC_switch_B_1# copy running-config startup-config

```

- a. Add the ports of the replacement switch to the zones.

All the cabling on the replacement switch must be the same as on the impaired switch:


```

FC_switch_B_1# conf t
FC_switch_B_1(config)# zone name FC-VI_Zone_1_10 vsan 10
FC_switch_B_1(config-zone)# member interface fc1/1 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/2 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# zone name STOR_Zone_1_20_25A vsan 20
FC_switch_B_1(config-zone)# member interface fc1/5 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/8 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/9 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/10 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/11 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# zone name STOR_Zone_1_20_25B vsan 20
FC_switch_B_1(config-zone)# member interface fc1/8 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/9 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/10 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# member interface fc1/11 swwn
20:00:54:7f:ee:c6:80:78
FC_switch_B_1(config-zone)# save running-config startup-config
FC_switch_B_1(config-zone)# zoneset distribute full 10
FC_switch_B_1(config-zone)# zoneset distribute full 20
FC_switch_B_1(config-zone)# end
FC_switch_B_1# copy running-config startup-config

```

b. Verify that the zoning is properly configured:

show zone

The following example output shows the three zones:

```

FC_switch_B_1# show zone
  zone name FC-VI_Zone_1_10 vsan 10
    interface fc1/1 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/2 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/1 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/2 swwn 20:00:54:7f:ee:b8:24:c0

  zone name STOR_Zone_1_20_25A vsan 20
    interface fc1/5 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/8 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/9 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/10 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/11 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/8 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/9 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/10 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/11 swwn 20:00:54:7f:ee:b8:24:c0

  zone name STOR_Zone_1_20_25B vsan 20
    interface fc1/8 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/9 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/10 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/11 swwn 20:00:54:7f:ee:c6:80:78
    interface fc1/5 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/8 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/9 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/10 swwn 20:00:54:7f:ee:b8:24:c0
    interface fc1/11 swwn 20:00:54:7f:ee:b8:24:c0
FC_switch_B_1#

```

c. Enable the connectivity to storage and the controllers.

The following example shows the port usage:

```

FC_switch_A_1# conf t
FC_switch_A_1(config)# interface fc1/1
FC_switch_A_1(config)# no shut
FC_switch_A_1(config)# interface fc1/4
FC_switch_A_1(config)# shut
FC_switch_A_1(config)# interface fc1/2-3
FC_switch_A_1(config)# shut
FC_switch_A_1(config)# interface fc1/5-6
FC_switch_A_1(config)# shut
FC_switch_A_1(config)# interface fc1/7-8
FC_switch_A_1(config)# shut
FC_switch_A_1# copy running-config startup-config
FC_switch_A_1#

```

9. Verify the operation of the MetroCluster configuration in ONTAP:

- a. Check whether the system is multipathed:

```
node run -node node-name sysconfig -a
```

- b. Check for any health alerts on both clusters:

```
system health alert show
```

- c. Confirm the MetroCluster configuration and that the operational mode is normal:

```
metrocluster show
```

- d. Perform a MetroCluster check:

```
metrocluster check run
```

- e. Display the results of the MetroCluster check:

```
metrocluster check show
```

- f. Check for any health alerts on the switches (if present):

```
storage switch show
```

- g. Run Config Advisor.

[NetApp Downloads: Config Advisor](#)

- h. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.