

# **5075M, 5090M, 5100M, and 5115M (Stage V) Tractors Operator's Manual (European Edition)**



**JOHN DEERE**

## **OPERATOR'S MANUAL**

### **5M Series Tractors (European Edition)**

**OMTR116808 ISSUE G1 (ENGLISH)**

**John Deere India Pvt. Ltd**  
European Edition  
PRINTED IN U.S.A.

# Introduction

---

## Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I. N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate or statement which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.

If you are not the original owner of this machine, it is in your interest to contact your local John Deere dealer to inform them of this unit's serial number. This will help John Deere notify you of any issues or product improvements.

---

DX,IFC1-19-03APR09

with the instructions provided in this manual to maintain the emissions performance of the engine within the requirements applicable to the engine's category/certification.

## Tampering

No deliberate tampering with or misuse of the engine emissions control system shall take place; in particular with regard to deactivating or not maintaining an exhaust gas recirculation (EGR) or a DEF dosing system. Tampering with an engine's emissions control system will void the European Union (EU) type approval and applicable emissions-related warranties.

---

DX,EMISSIONS,PERFORM-19-12JAN18

## Emissions Performance and Tampering

### Operation and Maintenance

The engine, including the emissions control system, shall be operated, used, and maintained in accordance

---

# Contents

	Page		Page
<b>General Information</b>		Service Tires Safely .....	00A-16
Product View .....	00-1	Service Front-Wheel Drive Tractor Safely .....	00A-16
Trademarks .....	00-1	Tightening Wheel Retaining Bolts/Nuts .....	00A-16
Glossary of Terms .....	00-2	Avoid High-Pressure Fluids .....	00A-17
Machine Overview .....	00-4	Do Not Open High-Pressure Fuel System .....	00A-17
<b>Safety Precautions</b>		Store Attachments Safely .....	00A-17
Recognize Safety Information .....	00A-1	Decommissioning — Proper Recycling and Disposal of Fluids and Components .....	00A-17
Understand Signal Words .....	00A-1	<b>Safety Signs</b>	
Follow Safety Instructions .....	00A-1	Replace Safety Signs .....	00B-1
Prepare for Emergencies .....	00A-1	Operator's Manual .....	00B-1
Wear Protective Clothing .....	00A-2	Use Seat Belt .....	00B-1
Protect Against Noise .....	00A-2	Passenger Seat—Cab .....	00B-2
Handle Fuel Safely—Avoid Fires .....	00A-2	Riders—OOS .....	00B-2
Fire Prevention .....	00A-2	Hitch Remote Control .....	00B-2
In Case of Fire .....	00A-3	ROPS in Normal Position—OOS .....	00B-2
Avoid Static Electricity Risk When Refueling .....	00A-3	Hot Surface .....	00B-3
Use Foldable ROPS and Seat Belt Properly .....	00A-4	Pick-Up Hitch .....	00B-4
Stay Clear of Rotating Drivelines .....	00A-4	<b>Controls and Instruments (Cab)</b>	
Use Steps and Handholds Correctly .....	00A-5	Front Console Controls .....	10A-1
Read Operator's Manuals for ISOBUS Controllers .....	00A-5	Foot-Operated Controls .....	10A-1
Use Seat Belt Properly .....	00A-5	Right Console Controls .....	10A-1
Vibration .....	00A-5	Transmission Controls .....	10A-3
Operating the Tractor Safely .....	00A-6	Multi-Function Lever/Mid-SCV Controls .....	10A-4
Avoid Backover Accidents .....	00A-7	Rear SCV Controls .....	10A-4
Limited Use in Forestry Operation .....	00A-7	Rear Hitch Controls .....	10A-5
Operating the Loader Tractor Safely .....	00A-7	PTO Controls .....	10A-5
Keep Riders Off Machine .....	00A-8	Heat and Air Conditioning Controls .....	10A-6
Passenger Seat .....	00A-8	<b>Controls and Instruments (IOOS)</b>	
Use Safety Lights and Devices .....	00A-8	Front-Console Controls .....	10B-1
Towing Trailers/Implements Safely .....	00A-8	Foot Operated Controls .....	10B-1
Use Caution on Slopes, Uneven Terrain, and Rough Ground .....	00A-9	Console Controls .....	10B-2
Freeing a Mired Machine .....	00A-9	Transmission Controls .....	10B-4
Avoid Contact with Agricultural Chemicals .....	00A-10	Multi-Function Lever/Mid-SCV Controls .....	10B-5
Handle Agricultural Chemicals Safely .....	00A-10	Rear SCV Controls .....	10B-5
Handling Batteries Safely .....	00A-11	Rear Hitch Controls .....	10B-6
Avoid Heating Near Pressurized Fluid Lines .....	00A-12	Rear PTO Controls .....	10B-6
Remove Paint Before Welding or Heating .....	00A-12	<b>Engine Operation</b>	
Handle Electronic Components and Brackets Safely .....	00A-12	Required Machine Stop Warning .....	20-1
Practice Safe Maintenance .....	00A-13	Engine Fuel System and Power Rating .....	20-1
Avoid Hot Exhaust .....	00A-13	Check Engine Indicators and Gauges .....	20-2
Clean Exhaust Filter Safely .....	00A-13	Operate Key Switch .....	20-3
Work In Ventilated Area .....	00A-14	Start Engine .....	20-3
Support Machine Properly .....	00A-14	Cold-Weather Start .....	20-4
Prevent Machine Runaway .....	00A-15	Run Engine .....	20-5
Park Machine Safely .....	00A-15	Engine Speeds and Operational Procedures .....	20-6
Transport Tractor Safely .....	00A-15	Stop Engine .....	20-7
Service Cooling System Safely .....	00A-15	Restart Out of Fuel Engine .....	20-7
Service Accumulator Systems Safely .....	00A-16		

Continued on next page

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

	Page		Page
Engine Block Coolant Heater .....	20-7	<b>Transmission Operation</b>	
Engine Fuel Heater .....	20-8	Electrohydraulic Transmission System	
<b>Air Intake, Fuel, Coolant, and Exhaust Operation</b>		Indicator .....	50A-1
Aftertreatment Indicators Overview .....	30-1	16/16 Transmission .....	50A-1
Selective Catalytic Reduction (SCR) System		32/16 Transmission .....	50A-2
Overview .....	30-3	Reverser Modulation .....	50A-3
EU Qualified Emergency Use — SCR Derate		Creeper Gear Operation .....	50A-3
Override Option .....	30-4	Downhill Operation in Slippery Conditions .....	50A-4
Fuel and Diesel Exhaust Fluid (DEF) Level		16/16 Transmission Ground Speed Chart .....	50A-4
Gauges .....	30-5	32/16 Transmission Ground Speed Chart .....	50A-5
Fill Fuel Tank .....	30-5	16/16 Creeper Ground Speed Chart .....	50A-5
Fill Diesel Exhaust Fluid (DEF) Tank .....	30-6	32/16 Creeper Ground Speed Chart .....	50A-6
Reduce Fuel Consumption .....	30-6	Correction Factors for Other Tire Sizes .....	50A-6
Exhaust Filter Cleaning .....	30-7	<b>MFWD and Front Axle Operation</b>	
Exhaust Filter System Overview .....	30-7	Mechanical Front-Wheel Drive (MFWD On/ Brake Assist) .....	50B-1
Automatic (AUTO) Exhaust Filter Cleaning .....	30-9	<b>Differential and Rear Axle Operation</b>	
Disabled Exhaust Filter Cleaning .....	30-9	Differential Lock .....	50C-1
Parked Exhaust Filter Cleaning .....	30-10	<b>Power Take Off (PTO) Operation</b>	
Service Exhaust Filter Cleaning .....	30-11	Match Machine Power to Implement .....	50D-1
<b>Electrical and Lighting Operation</b>		PTO Guard .....	50D-1
Disconnect Battery Connection Cab (Pre- Installed) .....	40-1	PTO Shield .....	50D-1
Disconnect Battery Connection (Cab and IOOS) .....	40-1	PTO Drive Shaft Shield .....	50D-2
Light Switch .....	40-2	Select PTO Drawbar Position .....	50D-2
Headlights .....	40-2	Attach PTO Driven Implement .....	50D-3
Loader Lights .....	40-3	Ground Drive PTO .....	50D-3
Bucket Lights .....	40-3	Select Correct PTO Speed .....	50D-4
Tail and Brake Lights .....	40-4	Operate Rear PTO .....	50D-5
Turn Signals .....	40-5	Operate Rear Remote PTO .....	50D-6
Hazard Lights .....	40-5	Operate Front PTO .....	50D-7
Beacon Lights .....	40-7	PTO Alarm .....	50D-7
Front Worklights .....	40-8	<b>Steering and Brake Operation</b>	
Rear Worklights .....	40-9	Trailer Brake Test .....	60-1
License Plate Lights .....	40-9	Service Brakes .....	60-1
Dome Light .....	40-10	Secondary Brakes .....	60-2
Right-Hand Console Light .....	40-10	Hydraulic Trailer Brakes .....	60-2
Horn .....	40-11	Air Trailer Brakes .....	60-3
Backup Alarm (If Equipped) .....	40-11	<b>Hydraulics Operation</b>	
Front Wiper and Washer .....	40-11	Warm Transmission/Hydraulic Oil .....	70-1
Rear Wiper and Washer .....	40-12	Open Center Hydraulics .....	70-1
Auxiliary Input and USB Port .....	40-12	<b>Hitch and Drawbar Operation</b>	
Bluetooth® Microphone .....	40-12	Match Machine Power to Implement .....	70A-1
Speakers .....	40-13	Rear Hitch Controls .....	70A-1
Radio Antenna .....	40-13	Rear Hitch Components .....	70A-2
Satellite Module and Antenna .....	40-13	Operate Mechanical Position and Draft Control .....	70A-6
Implement Connector .....	40-13	Operate Mechanical Rate-of-Drop Knob .....	70A-8
Power Outlet .....	40-14	Electrohydraulic Hitch System .....	70A-8
Convenience Outlets .....	40-14	Prepare Implement .....	70A-12
Service ADVISOR™ Connector .....	40-15	Hitch Conversion - Category II to I .....	70A-13
Operator Presence .....	40-15	Position Center Link .....	70A-13
JDLink™ .....	40-15	Adjust Lateral Float .....	70A-14
<b>Displays, Software, and Electronics Operation</b>		Height-Adjustable Trailer Hitch .....	70A-14
Primary Display .....	41-1	Operate Wagon Hitch .....	70A-15
<b>Drivetrain Operation</b>		Operate Pickup Hitch .....	70A-17
Drivetrain Information .....	50-1	Attach Implement to Ball-End Rear Hitch .....	70A-18
Off-Level Operation .....	50-1	Level Ball-End Hitch .....	70A-20

	Page		Page
Attach Implement to Hook-End Rear Hitch .....	70A-20	Monitor Mounts .....	90-16
Level Hook-End Hitch .....	70A-23	Rear Window Cable Routing .....	90-16
Adjust Hitch Side Sway .....	70A-23	Coat Hook .....	90-16
Stabilizing System .....	70A-24	Ash Tray and Cigarette Lighter .....	90-17
Adjusting Spreading Dimensions .....	70A-24	Operate Premium Radio .....	90-17
Quick Coupler .....	70A-25	Set Radio Clock .....	90-18
Front Hitch Components .....	70A-27	Set Radio Alarm .....	90-19
Front Implement Connection .....	70A-28	Compact Disc (CD) Mode .....	90-20
Front Hitch and Coupler Operation .....	70A-29	iPod Mode .....	90-21
Drawbar Settings .....	70A-30	USB Mode .....	90-22
Clevis Drawbar .....	70A-31	Weather Band .....	90-22
Drawn Implement Connection .....	70A-31		
<b>Selective Control Valve Operation</b>		<b>Transport and Storage</b>	
Rear SCV Controls and Components .....	70B-1	Keep Machines Secure .....	100-1
Mid-SCV Controls and Components .....	70B-2	Deliver Safely .....	100-1
Front Hitch and SCV .....	70B-3	Road Transportation .....	100-2
Connect Hydraulic Hoses .....	70B-3	Towing Loads .....	100-2
Connect to Rear SCVs .....	70B-4	Tow Machine .....	100-3
Connect to Mid-SCVs .....	70B-4	Front Tow Points .....	100-4
Correct Reversed Cylinder Response .....	70B-5	Rear Tow Points .....	100-5
Single-Acting Cylinders .....	70B-5	Machine Storage .....	100-5
Implements Requiring Large Volumes of Oil .....	70B-5	Remove Machine from Storage .....	100-6
Set SCV Detents .....	70B-5		
Operate Hydraulic Motor with Rear SCV .....	70B-6	<b>Maintenance Intervals</b>	
Operate Power Beyond with Rear SCV .....	70B-7	Maintain Daily Before Start-Up .....	200-1
Operate Loader with Rear SCV .....	70B-8	Maintenance Interval Chart .....	200-2
Adjust Flow Control .....	70B-8		
Power Beyond .....	70B-9	<b>Fuels, Lubricants, and Coolants</b>	
Case Drain .....	70B-9	Alternative and Synthetic Lubricants .....	200A-1
Motor Return .....	70B-9	Diesel Engine Coolant (engine with wet sleeve cylinder liners) .....	200A-1
Fast Return-to-Sump .....	70B-10	Operating in Warm Temperature Climates .....	200A-2
Rear SCV Oil Collection .....	70B-10	John Deere COOL-GARD™ II Coolant Extender .....	200A-2
<b>Additional Equipment</b>		Water Quality for Mixing with Coolant Concentrate .....	200A-2
Toolbox .....	80B-1	Testing Coolant Freeze Point .....	200A-3
Front Loader .....	80B-1	Diesel Exhaust Fluid (DEF) — Use in Selective Catalytic Reduction (SCR) Equipped Engines .....	200A-3
Lockable Fuel Fill Cap .....	80B-2	Disposal of Diesel Exhaust Fluid (DEF) .....	200A-4
Chock Block .....	80B-2	Refilling Diesel Exhaust Fluid (DEF) Tank .....	200A-4
Hood .....	80B-2	Storing Diesel Exhaust Fluid (DEF) .....	200A-4
<b>Operator Station Operation</b>		Testing Diesel Exhaust Fluid (DEF) .....	200A-5
Cab Classification .....	90-1	Diesel Engine Oil Service Interval for Operation at High Altitude .....	200A-5
Avoid Contact with Agricultural Chemicals - Cab Category 1, 2, 3, and 4 According to EN 15695-1 .....	90-1	Diesel Engine Oil — Interim Tier 4, Final Tier 4, Stage IIIB, Stage IV, and Stage V .....	200A-6
Clean Vehicle of Hazardous Pesticides .....	90-2	Engine Oil and Filter Service Intervals — Interim Tier 4, Final Tier 4, Stage IIIB, Stage IV, and Stage V Engines .....	200A-6
Emergency Exit .....	90-2	John Deere Break-In Plus™ Engine Oil — Interim Tier 4, Final Tier 4, Stage IIIB, Stage IV, and Stage V .....	200A-7
Doors .....	90-3	Oil Filters .....	200A-7
Grab Handles .....	90-4	Fuel Filters .....	200A-7
Windows .....	90-4	Diesel Fuel .....	200A-8
Window Shades .....	90-5	Handling and Storing Diesel Fuel .....	200A-8
Mirrors .....	90-5	Lubricity of Diesel Fuel .....	200A-9
Roll Over Protective System (ROPS) .....	90-6	Testing Diesel Fuel .....	200A-9
Cab Seats .....	90-6	Biodiesel Fuel .....	200A-9
OOS Seats .....	90-9	Minimizing the Effect of Cold Weather on Diesel Engines .....	200A-10
Adjust Seat Armrests .....	90-11	Supplemental Diesel Fuel Additives .....	200A-11
Passenger Seat .....	90-11		
Steering Wheel .....	90-12		
Heat, Defrost, and Air Conditioning .....	90-12		
Heat, Defrost, and Air Conditioning .....	90-13		
Storage Drawer (If Equipped) .....	90-15		
General Storage .....	90-15		
Field Office™ .....	90-15		

Multipurpose Extreme Pressure (EP) Grease	200A-12
Mixing of Lubricants	200A-12
Lubricant Storage	200A-12
OilScan™ and CoolScan™	200A-12
Transmission, Steering, Brake, Hydraulic, and Gear Case Oil	200A-13

### As Required Maintenance

Maintain As Required	200B-1
Paint and Finish Care	200B-2
Wash Machine	200B-2

### Controls and Instruments Maintenance

General Controls and Instruments Maintenance	210-1
---	-------

### Engine Maintenance

Break-In Maintenance	220-1
Break-In Checks	220-1
Check Engine Oil Level	220-1
Change Engine Oil and Filter (4.5 Liter 4 Cylinder Engine)	220-2
Change Engine Oil and Filter (2.9 Liter 3 Cylinder Engine)	220-3
Clean Open Crankcase Vent (OCV)	220-4
Change Open Crankcase Vent Filter (OCV)	220-4
Check Fan Belt Tensioner (4.5 Liter 4 Cylinder Engine)	220-5
Replace Fan Belt (4.5 Liter 4 Cylinder Engine)	220-5
Inspect and Adjust Alternator Belt (2.9 Liter 3 Cylinder Engine)	220-6
Replace Alternator Belt (2.9 Liter 3 Cylinder Engine)	220-7
Inspect and Adjust Air Conditioner Compressor Belt (2.9 Liter 3 Cylinder Engine)	220-8
Replace Air Conditioner Compressor Belt (2.9 Liter 3 Cylinder Engine)	220-8
Adjust Engine Valve Clearance	220-9

### Air, Fuel, Coolant, and Exhaust Maintenance

Required Emission-Related Information	230-1
Recommended Dealer Performed Service	230-1
Check Engine and Exhaust Compartments for Debris	230-1
Clean Diesel Particulate Filter (DPF)	230-1
Change Diesel Exhaust Fluid (DEF) Dosing Unit Filter	230-1
Replace Diesel Exhaust Fluid (DEF) Tank Header Suction Screen	230-2
Clean Diesel Exhaust Fluid (DEF) Tank	230-6
Drain Diesel Exhaust Fluid (DEF) Tank	230-7
Service Air Cleaner Elements	230-8
Tighten Air Intake and Engine Cooling Hose Clamps	230-8
Clean Air Filter Dust Unloading Valve	230-10
Clean Grille Screens and Cooling Package	230-10
Do Not Modify Fuel System	230-12
Drain Water and Sediment from Fuel Filter	230-12
Bleed Fuel System	230-13
Replace Fuel Filters	230-14
Clean Fuel Tank Vent Filter (If Equipped)	230-15
Check Coolant Level	230-15

### Electrical and Lighting Maintenance

Use Booster Battery or Charger	240-1
Battery Maintenance	240-1
Replace Battery	240-2
Replace Fusible Link	240-2
Replace Cab Fuses	240-2
Replace OOS Fuses	240-5
Handle Halogen Light Bulbs Safely	240-7
Replace Halogen Headlight Bulb	240-7
Replace LED Headlight	240-9
Replace Auxiliary Drive Light Bulb	240-9
Replace Loader Light Bulb	240-9
Replace Bucket Light	240-10
Replace Fender Tail/Turn/Brake Light Bulb	240-10
Replace Turn Signal/Hazard and Clearance Light Bulb—Open Operator's Station	240-10
Replace Park Hazard Light Bulb—Cab	240-11
Replace Canopy Hazard Light Bulb	240-11
Replace Cab Halogen Worklight Bulb	240-11
Replace Cab LED Worklight	240-12
Replace OOS Worklight Bulb	240-12
Replace OOS Fender Light Bulb	240-13
Replace Beacon Light Bulb	240-13
Replace Dome Light Bulb	240-14
Replace Right-Hand Console Light Bulb	240-14
Replace License Plate Light Bulb	240-14

### Drivetrain Maintenance

Drivetrain Information	250-1
------------------------	-------

### Transmission Maintenance

Change Transmission/Hydraulic Oil and Filter	250A-1
Check Neutral Start System	250A-1
Check Transmission Park System	250A-2
Replace Transmission Dampener	250A-2

### MFWD and Front Axle Maintenance

Check Axle Pivot Pin End Play	250B-1
Lubricate 2WD Axle Pivot Point	250B-1
Lubricate 2WD Steering Spindles and Cylinders	250B-1
Pack 2WD Front Wheel Bearings	250B-1
Check MFWD Axle for Oil Leaks	250B-2
Lubricate MFWD Axle Trunnion	250B-2
Change MFWD Axle Wheel Hub Oil	250B-3
Change MFWD Axle Housing Oil	250B-3

### Differential and Rear Axle Maintenance

Lubricate Rear Axle Bearings	250C-1
------------------------------	--------

### Power Take-Off (PTO) Maintenance

Adjust PTO Speed Selector Lever	250D-1
Lubricate Exchangeable 540/1000 rpm PTO Shaft	250D-1
Change Front PTO Oil	250D-1

### Steering and Brake Maintenance

Check Manual Brakes	260-1
---------------------	-------

### Hydraulics Maintenance

Check Transmission/Hydraulic System Oil Level	270-1
--	-------

	Page		Page
Change Transmission/Hydraulic Filter .....	270-1	<b>Operator's Station Maintenance</b>	
Change Transmission/Hydraulic Oil and Filter .....	270-2	Clean Cab Air Filters .....	290-1
<b>Hitch and Drawbar Maintenance</b>		Check Air Conditioning System .....	290-1
Lubricate Draft Sensing Shaft Seal .....	270A-1	Replace Wiper Blade .....	290-2
Lubricate Rear Hitch .....	270A-1	Inspect Seat Belts .....	290-2
Lubricate Front Hitch .....	270A-2	Adjust Rear Fender—Open Operator's Station .....	290-2
Inspect Hitch and Drawbar for Excessive Wear .....	270A-2	Keep ROPS Installed Properly .....	290-3
<b>Selective Control Valve Maintenance</b>		Keep Cab Protection System Installed Properly .....	290-3
Adjust Mechanical SCV Cables .....	270B-1	<b>Troubleshooting</b>	
Empty Rear SCV Oil Collection Bottle .....	270B-1	Engine .....	300-1
<b>Wheels and Tires Maintenance</b>		Heat and Air Conditioning .....	300-5
Inspect Tires .....	280-1	Electrical .....	300-8
Adjust and Check Clearance .....	280-1	Transmission .....	300-9
Check Tire Inflation Pressure .....	280-1	Brakes .....	300-10
Tire Pressures .....	280-1	Hydraulics .....	300-10
Tire Inflation Pressure Guidelines .....	280-2	Hitch .....	300-11
Tire Sidewall Information .....	280-2	Selective Control Valves (SCV) .....	300-12
Use Correct Tire Combinations .....	280-3	<b>On-Board Diagnostics</b>	
Tire Combination Chart - 2WD .....	280-3	STOP, Service, Information Alert Indicators, and Alarms .....	300A-1
Tire Combination Chart - MFWD .....	280-4	On-Board Diagnostic Tool .....	300A-1
Correct Tire Selection .....	280-6	<b>Specifications</b>	
Changing Tire Sizes .....	280-7	Metric Bolt and Screw Torque Values .....	400-1
Select Front Tire Rolling Direction .....	280-8	Unified Inch Bolt and Screw Torque Values .....	400-2
Rear Wheel Tread Width Limitations .....	280-8	Fluid Capacities .....	400-3
Adjust Front Axle Width—2WD Front Axle .....	280-8	Machine Dimensions .....	400-3
Set Tread—2WD Front Axle .....	280-9	Machine Weight .....	400-5
Set Tread—Two-Position MFWD Wheels .....	280-10	Engine Specifications and PTO Power .....	400-5
Set Tread—Multi-Position MFWD Wheels .....	280-11	Electrical Specifications .....	400-6
Set Tread—Two-Position Rear Wheels .....	280-13	PTO Engine Speeds .....	400-6
Set Tread—Multi-Position Rear Wheels .....	280-14	Hydraulic Specifications .....	400-6
Tighten Wheel Bolts Correctly .....	280-17	Rear Hitch Lift Capacities .....	400-6
Install Wheel Spacer .....	280-17	Front Hitch Lift Capacities .....	400-7
Tighten Wheel Bolts—2WD Front Axle .....	280-18	Wagon Hitch and Pick-Up Hitch Capacities .....	400-7
Tighten Wheel Bolts—MFWD Axle .....	280-18	Drawbar Capacities .....	400-7
Tighten Wheel Bolts—Rear Axle .....	280-19	Weight Distribution .....	400-7
Jacking Up Machine .....	280-19	Maximum Permissible Load .....	400-8
Check Toe-In—2WD Axle .....	280-20	Maximum Permissible Towable Mass .....	400-9
Adjust Toe-In—2WD Axle .....	280-21	Ballast Capacities .....	400-9
Check Toe-In—MFWD Axle .....	280-21	Sound Level .....	400-10
Adjust Toe-In—MFWD Axle .....	280-21	Calculate Maximum Permissible Download on Trailer Hitch .....	400-10
Set Steering Stops .....	280-22	Calculate Permissible Mass .....	400-11
<b>Ballasting Maintenance</b>		Fluorinated Greenhouse Gas .....	400-11
General Ballast Information .....	280A-1	<b>Identification Numbers</b>	
Select Ballast Carefully .....	280A-1	Record Product Identification Number .....	400A-1
Front-End Ballast .....	280A-2	Record Front Axle Serial Number .....	400A-1
Rear Wheel Ballast .....	280A-3	Record Engine Serial Number (4.5 Liter 4 Cylinder Engine) .....	400A-1
Control Power Hop—MFWD .....	280A-3	Record Engine Serial Number (2.9 Liter 3 Cylinder Engine) .....	400A-2
Add Liquid Ballast to Tires .....	280A-4	Record Transmission Serial Number .....	400A-2
Remove Liquid Ballast from Tires .....	280A-4	Record Cab Serial Number .....	400A-2
Measure Wheel Slip .....	280A-5	Keep Proof of Ownership .....	400A-3
<b>Additional Equipment Maintenance</b>		<b>Certification and Warranty</b>	
Front Loader Bracket Installation .....	280B-1	Cab ROPS Certificate .....	400B-1
Adjust Front Fender .....	280B-2		
Set Pivoting Fender Brackets .....	280B-2		
Set Fender Position .....	280B-3		

Page

OOS ROPS Certificate .....	400B-1
Carbon Dioxide Emissions (CO <sub>2</sub> ) .....	400B-2
Emissions Control System Certification Label ..	400B-3

**Maintenance Records**

Daily or 10 Hours .....	500-1
Weekly or 50 Hours .....	500-1
First 100 Hours .....	500-2
Every 250 Hours .....	500-2
Every 300 Hours .....	500-3
Every 500 Hours .....	500-5
Every 600 Hours .....	500-7
Every 1200 Hours .....	500-8
Every 1500 Hours .....	500-9
Annual Maintenance .....	500-10
Every 3000 Hours .....	500-11
Every 4500 Hours .....	500-11
Change of Ownership .....	500-12
Change of Ownership .....	500-12
Change of Ownership .....	500-12