

# Index

## A

Add Liquid Ballast to Tires.....	280A-4
Adjust and Check Clearance.....	280-1
Adjust Engine Valve Clearance.....	220-9
Adjust Flow Control.....	70B-8
Adjust Front Axle Width—2WD Front Axle.....	280-8
Adjust Hitch Side Sway.....	70A-23
Adjust Lateral Float.....	70A-14
Adjust Mechanical SCV Cables.....	270B-1
Adjust PTO Speed Shift Lever.....	250D-1
Adjust Rear Fender—Open Operator Station.....	290-2
Adjust Seat Armrests.....	90-11
Adjust Toe-In—2WD Axle.....	280-21
Adjust Toe-In—MFWD Axle.....	280-21
Adjusting Spreading Dimension.....	70A-24
Aftertreatment indicators overview.....	30-1
Aftertreatment system	
Emergency SCR derate override.....	30-4
Air brakes on trailer.....	60-3
Ash Tray and Cigarette Lighter.....	90-17
Attach Implement to Rear Hitch - Ball-End.....	70A-18
Attach Implement to Rear Hitch - Hook-End.....	70A-20
Attach PTO Driven Implement.....	50D-3
Automatic (AUTO) Exhaust Filter Cleaning.....	30-9
Auxiliary Input and USB Port.....	40-12
Avoid static electricity risk when fueling.....	00A-3

## B

Backup Alarm.....	40-11
Ballast Capacities.....	400-9
Battery Handling, Safety	
Safety, Battery Handling.....	00A-11
Battery Maintenance.....	240-1
Beacon Lights.....	40-7
Biodiesel fuel.....	200A-9
Bleed Fuel System.....	230-13
Bluetooth Microphone.....	40-12
Bolt and screw torque values	
Metric.....	400-1
Unified inch.....	400-2
Break-in Checks.....	220-1
Break-in engine oil	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V.....	200A-7
Break-In Maintenance.....	220-1
Bucket Lights.....	40-3

## C

Cab Classification.....	90-1
Cab ROPS Certificate.....	400B-1
Cab Seats.....	90-6
Calculate Maximum Permissible Download on Trailer	
Hitch.....	400-10
Calculate Permissible Mass.....	400-11
Carbon Dioxide Emissions.....	400B-2

Case Drain.....	70B-9
Change Diesel Exhaust Fluid (DEF) Dosing Unit Filter.....	230-1
Change Engine Oil and Filter (2.9 Liter 3 Cylinder Engine).....	220-3
Change Engine Oil and Filter (4.5 Liter 4 Cylinder Engine).....	220-2
Change Front PTO Oil.....	250D-1
Change MFWD Axle Housing Oil.....	250B-3
Change MFWD Axle Wheel Hub Oil.....	250B-3
Change of Ownership.....	500-12
Change Open Crankcase Vent Filter (OCV).....	220-4
Change Transmission/Hydraulic Filter.....	270-1
Change Transmission/Hydraulic Oil and Filter.....	250A-1, 270-2
Changing Tire Sizes.....	280-7
Check Air Conditioning System.....	290-1
Check Axle Pivot Pin End Play.....	250B-1
Check Coolant Level.....	230-15
Check Engine and Exhaust Compartments for Debris.....	230-1
Check Engine Oil Level.....	220-1
Check Fan Belt Tensioner (4.5 Liter 4 Cylinder Engine).....	220-5
Check Manual Brakes.....	260-1
Check MFWD Axle for Oil Leaks.....	250B-2
Check Neutral Start System.....	250A-1
Check Tire Inflation Pressure.....	280-1
Check Toe-In—2WD Axle.....	280-20
Check Toe-In—MFWD Axle.....	280-21
Check Transmission Park System.....	250A-2
Check Transmission/Hydraulic System Oil Level.....	270-1
Chock block.....	80B-2
Clean Air Filter Dust Unloading Valve.....	230-10
Clean Cab Air Filters.....	290-1
Clean Diesel Exhaust Fluid (DEF) Tank.....	230-6
Clean Diesel Particulate Filter (DPF).....	230-1
Clean Fuel Tank Vent Filter.....	230-15
Clean Grille Screens and Cooling Package.....	230-10
Clean Open Crankcase Vent (OCV).....	220-4
Cleaning Exhaust Filter	
Filter, Exhaust.....	30-7
Clevis Drawbar.....	70A-31
Coat Hook.....	90-16
Cold Weather Start.....	20-4
Compact Disc (CD) Mode.....	90-20
Connect Hydraulic Hoses.....	70B-3
Connect to Mid-SCVs.....	70B-4
Connect to Rear SCVs.....	70B-4
Control Power Hop - MFWD.....	280A-3
Controls	
Console	
Cab.....	10A-1
Open Operator Station.....	10B-2
Foot Operated.....	10A-1, 10B-1
Front Console.....	10A-1, 10B-1

Heat	
Air Conditioning .....	10A-6
Multifunction Lever	
Joystick	
Mid-SCVs .....	10A-4, 10B-5
Rear Hitch .....	10A-5, 10B-6
Rear PTO .....	10A-5, 10B-6
Rear SCVs .....	10A-4, 10B-5
Transmission .....	10A-3, 10B-4
Convenience Outlets .....	40-14
Coolant	
Diesel engine	
Engine with wet sleeve cylinder liners .....	200A-1
John deere COOL-GARD II coolant extender .....	200A-2
Mixing with concentrate, water quality .....	200A-2
Testing freeze point .....	200A-3
Warm temperature climates .....	200A-2
CoolScan .....	200A-12
Correct Reversed Cylinder Response .....	70B-5
Correct Tire Selection	
MFWD Ratio .....	280-6
Correction Factors for Other Tire Sizes .....	50A-6
Creeper Gear Operation .....	50A-3

**D**

DEF	
Disposal .....	200A-4
Storing .....	200A-4
Tank, refilling .....	200A-4
Testing .....	200A-5
Use in SCR equipped engines .....	200A-3
Diesel engine oil	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V .....	200A-6
Service interval for operation at high altitude .....	200A-5
Diesel engines, cold weather effect .....	200A-10
Diesel fuel .....	200A-8
Supplemental additives .....	200A-11
Diesel fuel, testing .....	200A-9
Differential Lock .....	50C-1
Disabled Exhaust Filter Cleaning .....	30-9
Do Not Modify Fuel System .....	230-12
Dome Light .....	40-10
Doors .....	90-3
Downhill Operation in Slippery Conditions .....	50A-4
Drain Diesel Exhaust Fluid (DEF) Tank .....	230-7
Drain Water and Sediment from Fuel Filter .....	230-12
Drawbar Capacities .....	400-7
Drawbar Settings .....	70A-30
Drawn Implement Connection .....	70A-31
Drivetrain Maintenance .....	250-1
Drivetrain Operation .....	50-1

**E**

Effect of cold weather on diesel engines .....	200A-10
Electrical Specifications .....	400-6
Electrohydraulic Hitch System Indicator .....	70A-8
Electrohydraulic Transmission System Indicator .....	50A-1
Emission system	
Certification label .....	400B-3
Emissions	
Required language	
EPA .....	230-1
Emissions Performance	
Tampering .....	2
Empty Rear SCV Oil Collection Bottle .....	270B-1
Engine and PTO Power .....	400-5
Engine Block Coolant Heater .....	20-7
Engine Fuel System and Power Rating .....	20-1
Engine Indicator and Gauges .....	20-2
Engine oil	
Break-In	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V .....	200A-7
Diesel	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V .....	200A-6
Service interval for operation at high altitude .....	200A-5
Engine oil and filter service intervals	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V	
0.12 L/kW or greater oil pan .....	200A-6
Operation at high altitude .....	200A-5
Engine Speeds and Operational Procedures .....	20-6
Exhaust Filter System Overview .....	30-7
Exhaust Filter, Safety	
Safety, Exhaust Filter .....	00A-13

**F**

Fast Return-to-Sump .....	70B-10
Field Office .....	90-15
Fill Diesel Exhaust Fluid (DEF) Tank .....	30-6
Fill Fuel Tank .....	30-5
Filters, Oil	
Oil Filters .....	200A-7
Fluid Capacities .....	400-3
Fluorinated greenhouse gas, specifications .....	400-11
Front End Ballast .....	280A-2
Front Hitch and Coupler Operation .....	70A-29
Front Hitch Components .....	70A-27
Front Hitch Lift Capacities .....	400-7
Front Implement Connection .....	70A-28
Front Loader .....	80B-1
Front Loader Bracket Installation .....	280B-1
Front Tow Points .....	100-4
Front Wiper and Washer .....	40-11
Front Worklights .....	40-8

<b>Fuel</b>		<b>K</b>	
Biodiesel .....	200A-9	Keep Cab Protection System Installed Properly .....	290-3
Diesel .....	200A-8	Keep ROPS Installed Properly .....	290-3
Handling and storing .....	200A-8	<b>L</b>	
Lubricity .....	200A-9	Level Hitch - Ball-End .....	70A-20
Fuel and Diesel Exhaust Fluid (DEF) Level Gauges ..	30-5	Level Hitch - Hook-End .....	70A-23
<b>Fuel Filters</b>		Light Switch .....	40-2
Filters, Fuel .....	200A-7	Loader Lights .....	40-3
<b>G</b>		Lockable Fuel Fill Cap .....	80B-2
Gear case oil .....	200A-13	Lubricant	
General Ballast Information .....	280A-1	Mixing .....	200A-12
General Controls and Instruments Maintenance .....	210-1	Lubricant Storage	
General Storage .....	90-15	Storage, Lubricant .....	200A-12
Glossary of Terms .....	00-2	Lubricants, safety .....	200A-1
Grab Handles .....	90-4	Lubricate 2WD Axle Pivot Point .....	250B-1
Grease		Lubricate 2WD Steering Spindles and Cylinders .....	250B-1
Multipurpose Extreme Pressure (EP) .....	200A-12	Lubricate Draft Sensing Shaft Seal .....	270A-1
Ground Speed PTO .....	50D-3	Lubricate Exchangeable 540/1000 rpm PTO Shaft .....	250D-1
<b>H</b>		Lubricate Front Hitch .....	270A-2
Handle Halogen Light Bulbs Safely .....	240-7	Lubricate MFWD Axle Trunnion .....	250B-2
Hardware torque values		Lubricate Rear Axle Bearings .....	250C-1
Metric .....	400-1	Lubricate Rear Hitch .....	270A-1
Unified inch .....	400-2	Lubricity of diesel fuel .....	200A-9
Headlights .....	40-2	<b>M</b>	
Heat, Defrost, and Air Conditioning .....	90-12, 90-13	Machine Dimensions .....	400-3
Height Adjustable Trailer Hitch .....	70A-14	Machine Overview .....	00-4
Hitch		Machine stop warning, required .....	20-1
Pick-Up Hitch		Machine Storage .....	100-5
Operating .....	70A-17	Machine Weight .....	400-5
Wagon .....	70A-15	Maintain as Required .....	200B-1
Hitch Conversion - Category II to I .....	70A-13	Maintain Daily Before Start-Up .....	200-1
Horn .....	40-11	Maintenance Record	
Hydraulic oil .....	200A-13	Annual .....	500-9, 500-10
Hydraulic Trailer Brakes .....	60-2	Daily or 10 Hours .....	500-1
<b>I</b>		Every 300 Hours .....	500-3
Implement Connector .....	40-13	Every 500 Hours .....	500-5
Implements Requiring Large Volumes of Oil .....	70B-5	Every 600 Hours .....	500-7
Indicators overview .....	30-1	Every 1200 Hours .....	500-8
Inspect and Adjust Air Conditioning Compressor Belt		Every 3000 Hours .....	500-11
(2.9 Liter 3 Cylinder Engine) .....	220-8	Every 4500 Hours .....	500-11
Inspect and Adjust Alternator Belt (2.9 Liter 3 Cylinder		First 100 Hours .....	500-2
Engine) .....	220-6	Weekly or 50 Hours .....	500-1
Inspect Hitch and Drawbar for Excessive Wear .....	270A-2	Match Machine Power to Implement .....	50D-1, 70A-1
Inspect Seat Belts .....	290-2	Measure Wheel Slip .....	280A-5
Inspect Tires .....	280-1	Mechanical Front-Wheel Drive (MFWD On/Brake	
Install Wheel Spacer .....	280-17	Assist) .....	50B-1
iPod Mode .....	90-21	Metric bolt and screw torque values .....	400-1
<b>J</b>		MFWD Ratio	
Jacking Up Machine .....	280-19	Tire Selection .....	280-6
JDLINK .....	40-15	Mid-SCV Controls and Components .....	70B-2
		Mirrors .....	90-5

Mixing lubricants .....	200A-12
Monitor Mounts .....	90-16
Motor Return .....	70B-9
Multipurpose Extreme Pressure (EP) grease .....	200A-12

**O**

Off Level Operation .....	50-1
Oil	
Engine	
Interim tier 4, final tier 4, stage IIIB, stage IV, and stage V .....	200A-6
Gear case .....	200A-13
Hydraulic .....	200A-13
Steering .....	200A-13
Transmission .....	200A-13
Oilscan .....	200A-12
On-Board Diagnostic Tool .....	300A-1
OOS ROPS Certificate .....	400B-1
OOS Seats .....	90-9
Open Center Hydraulic Specifications .....	400-6
Open Center Hydraulics .....	70-1
Operate Front PTO .....	50D-7
Operate Hydraulic Motor with Rear SCV .....	70B-6
Operate Key Switch .....	20-3
Operate Loader with Rear SCV .....	70B-8
Operate Mechanical Position Control .....	70A-6
Operate Mechanical Rate-of-Drop Control .....	70A-8
Operate Power Beyond With Rear SCV .....	70B-7
Operate Premium Radio .....	90-17
Operate Rear PTO .....	50D-5
Operate Rear Remote PTO .....	50D-6
Operator Presence .....	40-15

**P**

Pack 2WD Front Wheel Bearings .....	250B-1
Paint and Finish Care .....	200B-2
Parked Exhaust Filter Cleaning .....	30-10
Passenger Seat .....	90-11
Permissible Load .....	400-8
Permissible Towable Mass .....	400-9
Position Center Link .....	70A-13
Power Beyond .....	70B-9
Power Outlet .....	40-14
PowrReverser Plus Transmission .....	50A-2
PowrReverser Plus Transmission Ground Speed Chart .....	50A-5
PowrReverser Transmission .....	50A-1
PowrReverser Transmission Ground Speed Chart .....	50A-4
Prepare Implement .....	70A-12
Primary Display .....	41-1
Product View .....	00-1
PTO	
Ground Speed .....	50D-3
PTO Alarm .....	50D-7

PTO Drive Shaft Shield .....	50D-2
PTO Engine Speeds .....	400-6
PTO Guard .....	50D-1
PTO Shield .....	50D-1

**Q**

Qualified emergency use	
SCR derate override option .....	30-4
Quick Coupler .....	70A-25

**R**

Radio Antenna .....	40-13
Rear Hitch Components .....	70A-2
Rear Hitch Controls .....	70A-1
Rear Hitch Lift Capacities .....	400-6
Rear SCV Controls and Components .....	70B-1
Rear SCV Oil Collection .....	70B-10
Rear Tow Points .....	100-5
Rear Wheel Ballast .....	280A-3
Rear Wheel Tread Width Limitations .....	280-8
Rear Window Cable Routing .....	90-16
Rear Wiper and Washer .....	40-12
Rear Worklights .....	40-9
Recommended Dealer Performed Service .....	230-1
Record Cab Serial Number .....	400A-2
Record Engine Serial Number (2.9 Liter 3 Cylinder Engine) .....	400A-2
Record Engine Serial Number (4.5 Liter 4 Cylinder Engine) .....	400A-1
Record Front Axle Serial Number .....	400A-1
Record Product Identification Number .....	400A-1
Record Transmission Serial Number .....	400A-2
Reduce Fuel Consumption .....	30-6
Refueling, avoid static electricity risk .....	00A-3
Remove Liquid Ballast from Tires .....	280A-4
Remove Machine from Storage .....	100-6
Replace Air Conditioner Compressor Belt (2.9 Liter 3 Cylinder Engine) .....	220-8
Replace Alternator Belt (2.9 Liter 3 Cylinder Engine) .....	220-7
Replace Auxiliary Drive Light Bulb .....	240-9
Replace Battery .....	240-2
Replace Beacon Light Bulb .....	240-13
Replace Bucket Light .....	240-10
Replace Cab Fuses .....	240-2
Replace Cab Halogen Worklight Bulb .....	240-11
Replace Cab LED Worklight .....	240-12
Replace Canopy Warning Light Bulb .....	240-11
Replace Diesel Exhaust Fluid (DEF) Tank Header Suction Screen .....	230-2
Replace Directional/Hazard and Clearance Light Bulb—Open Operator's Station .....	240-10
Replace Dome Light Bulb .....	240-14
Replace Fan Belt (4.5 Liter 4 Cylinder Engine) .....	220-5
Replace Fender Tail/Turn/Brake Light Bulb .....	240-10

Replace Fuel Filters .....	230-14
Replace Fusible Link .....	240-2
Replace Halogen Headlight Bulb .....	240-7
Replace LED Headlight .....	240-9
Replace License Plate Light Bulb .....	240-14
Replace Loader Light Bulb .....	240-9
Replace OOS Fender Light Bulb .....	240-13
Replace OOS Fuses .....	240-5
Replace OOS Worklight Bulb .....	240-12
Replace Park Hazard Light Bulb—Cab .....	240-11
Replace Right-Hand Console Light Bulb .....	240-14
Replace Transmission Dampener .....	250A-2
Replace Wiper Blade .....	290-2
Required machine stop warning .....	20-1
Restart Engine That Has Run Out of Fuel .....	20-7
Reverser Modulation .....	50A-3
Right-Hand Console Light .....	40-10
Road Transportation .....	100-2
Roll Over Protective System (ROPS) .....	90-6
Run Engine .....	20-5

## S

### Safety

Passenger seat .....	00A-8
Protect against noise .....	00A-2
Rotating drivelines, stay clear .....	00A-4
Safe maintenance, practice .....	00A-13
Tires, service safely .....	00A-16
Tractor, operating safely .....	00A-6
Trailers/implements, towing safely .....	00A-8
Use caution on slopes, uneven terrain, and rough ground .....	00A-9
Vibration .....	00A-5
Safety, Avoid High-Pressure Fluids	
Avoid High-Pressure Fluids .....	00A-17
Safety, Fire Prevention	
Fire Prevention .....	00A-2
Safety, Forestry Operations	
Limited Use in Forestry Operation .....	00A-7
Safety, Handle Fuel Safely, Avoid Fires	
Avoid Fires, Handle Fuel Safely .....	00A-2
Safety, lubricants .....	200A-1
Safety, Steps and Handholds	
Use Steps and Handholds Correctly .....	00A-5
Safety, Tightening Wheel Retaining Bolts/Nuts	
Tightening Wheel Retaining Bolts/Nuts .....	00A-16
Satellite Module and Antenna .....	40-13
SCR	
System overview .....	30-3
Secondary Brakes .....	60-2
Select Ballast Carefully .....	280A-1
Select Correct PTO Speed .....	50D-4
Select Front Tire Rolling Direction .....	280-8
Select PTO Drawbar Position .....	50D-2
Service ADVISOR Connector .....	40-15
Service Air Cleaner Elements .....	230-8

Service Brakes .....	60-1
Service Exhaust Filter Cleaning .....	30-11
Service Interval Chart .....	200-2
Set Fender Position .....	280B-3
Set Pivoting Fender Bracket .....	280B-2
Set Radio Alarm .....	90-19
Set Radio Clock .....	90-18
Set SCV Detents .....	70B-5
Set Steering Stops .....	280-22
Set Tread—2WD Front Axle .....	280-9
Set Tread—Multi-Position MFWD Wheels .....	280-11
Set Tread—Multi-Position Rear Wheels .....	280-14
Set Tread—Two-Position MFWD Wheels .....	280-10
Set Tread—Two-Position Rear Wheels .....	280-13
Signal words, understand .....	00A-1
Single-Acting Cylinders .....	70B-5
Sound Level .....	400-10
Speakers .....	40-13
Start Engine .....	20-3
Steering oil .....	200A-13
Steering Wheel .....	90-12
Stop Engine .....	20-7
STOP, Service, Information Alert Indicators, and Alarms .....	300A-1
Storage Drawer .....	90-15
Storing fuel .....	200A-8

## T

Tail and Brake Lights .....	40-4
Testing diesel fuel .....	200A-9
Three Point Hitch	
Stabilizing System	
Spreading Dimension, Adjusting .....	70A-24
Tighten Air Intake and Engine Cooling Hose Clamps ..	
.....	230-8
Tighten Wheel Bolts Correctly .....	280-17
Tighten Wheel Bolts—2WD Front Axle .....	280-18
Tighten Wheel Bolts—MFWD Axle .....	280-18
Tighten Wheel Bolts—Rear Axle .....	280-19
Tire Inflation Pressure Guidelines .....	280-2
Tire Pressures .....	280-1
Tire Sidewall Information .....	280-2
Tires, service safely .....	00A-16
Tool Box .....	80B-1
Torque charts	
Metric .....	400-1
Unified inch .....	400-2
Tow Machine .....	100-3
Towing Loads .....	100-2
Tractor, operating safely .....	00A-6
Trademarks .....	00-1
Trailer Brake Test .....	60-1
Transmission oil .....	200A-13
Troubleshooting	
Brakes .....	300-10
Electrical .....	300-8

Engine .....	300-1
Heat and Air Conditioning .....	300-5
Hitch.....	300-11
Hydraulics .....	300-10
Selective Control Valves.....	300-12
Transmission .....	300-9
Turn Signals.....	40-5

## **U**

Unified inch bolt and screw torque values.....	400-2
USB Mode.....	90-22
Use Booster Battery or Charger .....	240-1
Use Correct Tire Combinations .....	280-3

## **W**

Wagon Hitch and Pick-Up Hitch Capacities .....	400-7
Warm Transmission/Hydraulic Oil .....	70-1
Warning Lights .....	40-5
Wash Machine .....	200B-2
Weather Band.....	90-22
Weight Distribution .....	400-7
Window Shades.....	90-5
Windows .....	90-4