

DTC	P0771	Shift Solenoid "E" Performance (Shift Solenoid Valve SR)
------------	--------------	---

DESCRIPTION

The ECM uses signals from the output shaft speed sensor and input speed sensor to detect the actual gear position (1st, 2nd, 3rd, 4th or 5th gear).

Then the ECM compares the actual gear with the shift schedule in the ECM memory to detect mechanical problems of the shift solenoid valves, valve body or automatic transmission (clutch, brake or gear, etc.).

DTC No.	DTC Detection Conditions	Trouble Areas
P0771	SR stuck ON malfunction*1: The ECM determines that there is a malfunction when the following condition is met (2-trip detection logic): (a) When the ECM directs the gearshift to switch to 2nd gear, the engine overruns (clutch slips)	<ul style="list-style-type: none"> Shift solenoid valve SR remains open Shift solenoid valve SL1 remains open Shift solenoid valve SLT remains open or closed Valve body is blocked Automatic transmission (clutch, brake or gear, etc.)
	SR stuck OFF malfunction*2: The ECM determines that there is a malfunction when the following condition is met (2-trip detection logic): (a) When the ECM directs the gearshift to switch to 5th gear, the actual gear is shifted to 4th.	<ul style="list-style-type: none"> Shift solenoid valve SR remains closed Shift solenoid valve SL1 remains closed Shift solenoid valve SLT remains open or closed Valve body is blocked Automatic transmission (clutch, brake or gear, etc.)

HINT:

Gear positions in the event of a solenoid valve mechanical problem:

Gearshift controlled by ECM	1st	2nd	3rd	4th	5th
1: Actual gear position under SR stuck ON malfunction	1st	N	3rd	4th	5th
*2: Actual gear position under SR stuck OFF malfunction	1st	2nd	3rd	4th	4th

N*: Neutral

MONITOR DESCRIPTION

This DTC indicates "stuck ON malfunction" or "stuck OFF malfunction" of the shift solenoid valve SR or SL1. The ECM controls the gearshifts by turning the shift solenoid valves "ON/OFF". When the gear position directed by the ECM and the actual gear position do not match, the ECM illuminates the MIL and stores the DTC.

MONITOR STRATEGY

Related DTCs	P0771: Shift solenoid valve SR/OFF malfunction Shift solenoid valve SR/ON malfunction
Required sensors/Components (Main)	Shift solenoid valve SR
Required sensors/Components (Related)	Speed sensor (NT), Speed sensor (SP2), Crankshaft position sensor (NE)
Frequency of operation	Continuous
Duration	OFF malfunction (A): 0.4 seconds OFF malfunctions (B) and (C): Immediate ON malfunction: 0.15 seconds
MIL operation	2 driving cycles
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The following conditions are common to all OFF malfunctions (A), (B), (C) and ON malfunction.

The monitor will run whenever the following DTCs are not present.	P0115 - P0118: ECT sensor P0125: Insufficient ECT for Closed Loop P0500: VSS P0748 - P0799: Trans solenoid (range)
Turbine speed sensor (NT) circuit	Functioning normally
Output speed sensor (SP2) circuit	Functioning normally
Shift solenoid "A" (S1) circuit	Functioning normally
Shift solenoid "B" (S2) circuit	Functioning normally
Shift solenoid "E" (SR) circuit	Functioning normally
Pressure control solenoid "A" (SL1) circuit	Functioning normally
Pressure control solenoid "B" (SL2) circuit	Functioning normally
ECT (Engine coolant temperature) sensor circuit	Functioning normally
Knock sensor circuit	Functioning normally
ETCS (Electronic throttle control system)	System not down
Transmission shift position	"D"
ECT	40°C (104°F) or more
Spark advance from max. retard timing by knock sensor control	0° CA or more
Engine	Starting

OFF malfunction (A)

ECM selected gear	5th
Vehicle speed	1.2 mph (2 km/h) or more
Throttle valve opening angle	6.5 % or more at engine speed of 2,000 rpm (Conditions vary with engine speed)

OFF malfunction (B)

Current ECM selected gear	5th
Last ECM selected gear	4th
Continuous time of ECM selecting 4th gear	2 seconds or more

OFF malfunction (C)

Current ECM selected gear	5th
Last ECM selected gear	4th

ON malfunction

Current ECM selected gear	2nd
Last ECM selected gear	1st
Throttle valve opening angle (During transition from 1st to 2nd gear)	5.5 % or more at engine speed of 3,000 rpm (Conditions vary with engine speed)

TYPICAL MALFUNCTION THRESHOLDS

[OFF malfunction]

All of the following conditions are met: OFF malfunctions (A), (B) and (C)

2 detections are necessary in 1 driving cycle.

1st detection; temporary flag ON

2nd detection; pending fault code ON

OFF malfunction (A)

Turbine speed/Output speed	0.93 to 1.07 (Actual gear is 4th)
----------------------------	--------------------------------------

OFF malfunction (B)

Turbine speed/Output speed	No change as follow: 0.93 to 1.07 (Actual gear is 4th) ↓ 0.65 to 0.79 (Actual gear is 5th)
----------------------------	---

OFF malfunction (C)

Output record from ECM for 4th → 5th upshifting	Recorded
---	----------

[ON malfunction]

2 detections are necessary in 1 driving cycle.

1st detection; temporary flag ON

2nd detection; pending fault code ON

Turbine speed - Output speed x 1st gear ratio	150 rpm or more
---	-----------------

HINT:

Performing the ACTIVE TEST using the intelligent tester allows components, such as the relay, VSV, and actuator, to be operated without removing any parts. Performing the ACTIVE TEST as a first step of troubleshooting is one method of shortening labor time.

It is possible to display the DATA LIST during the ACTIVE TEST.

1. Warm up the engine.
2. Turn the ignition switch off.
3. Connect the intelligent tester together with the CAN VIM (controller area network vehicle interface module) to the DLC3.
4. Turn the ignition switch to the ON position.
5. Push the "ON" button of the tester.
6. Clear the DTC.
7. Select the items "DIAGNOSIS/ ENHANCED OBD II/ ACTIVE TEST/ SHIFT".
8. According to the display on the tester, perform the "ACTIVE TEST".

HINT:

While driving, the shift position can be changed with the intelligent tester.

Comparing the shift position directed by the ACTIVE TEST with the actual shift position enables the problem to be confirmed (See page [AT-32](#)).

Item	Test Details	Diagnostic Note
SHIFT	[Test Details] Operate the shift solenoid valve and set each shift position manually. [Vehicle Condition] Vehicle Speed: Less than 30 mph (50 km/h) [Others] <ul style="list-style-type: none"> • Press → button: Shift up • Press ← button: Shift down 	Possible to check the operation of the shift solenoid valves. HINT: Shifting to the 5th gear is possible only when the vehicle is stationary with the engine idling.

HINT:

- This test can be conducted when the vehicle speed is 30 mph (50 km/h) or less.
- The 4th to 5th up-shifting must be performed with the accelerator pedal released.
- The 5th to 4th down-shifting must be performed with the accelerator pedal released.
- Do not operate the accelerator pedal for at least 2 seconds after shifting and do not shift successively.
- The shift position directed by the ECM is shown in the DATA LIST/ SHIFT display on the intelligent tester.
- The shift solenoid valve SR and S1 are turned on/off normally when the shift lever is in the D position:

Gearshift controlled by ECM	1st	2nd	3rd	4th	5th
Shift solenoid valve SR	OFF	OFF	OFF	OFF	ON
Shift solenoid valve SL1	OFF	OFF	OFF	OFF	ON

1 CHECK ANY OTHER DTCS OUTPUT (IN ADDITION TO DTC P0771)


- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch to the ON position and push the intelligent tester main switch ON.
- (c) Select the items "DIAGNOSIS/ ENHANCED OBD II/ DTC INFO/ CURRENT CODES".
- (d) Read the DTCs using the intelligent tester.

Result:

Display (DTC Output)	Proceed to
Only "P0771" is output	A
P0771" and other DTCs	B

HINT:

If any codes besides "P0771" are output, perform troubleshooting for those DTCs first

B**GO TO DTC CHART****A****2 PERFORM ACTIVE TEST USING INTELLIGENT TESTER (LINE PRESS UP) (See page AT-79)****NG****REPLACE SHIFT SOLENOID VALVE SLT****OK****3 INSPECT SHIFT SOLENOID VALVE SR****Shift Solenoid Valve SR:**

A110988E05

- (a) Remove the shift solenoid valve SR.
- (b) Measure the resistance.

Standard resistance


Tester Connection	Specified Condition
Solenoid Connector (SR) - Solenoid Body (SR)	11 to 15 Ω at 20°C (68°F)

- (c) Connect the positive (+) lead to the terminal of the solenoid connector, and the negative (-) lead to the solenoid body.

OK:

The solenoid makes an operating noise

NG**REPLACE SHIFT SOLENOID VALVE SR****OK**

4 INSPECT SHIFT SOLENOID VALVE SL1**Shift Solenoid Valve SL1:**

D025466E24

- (a) Remove the shift solenoid valve SL1.
(b) Measure the resistance.

Standard resistance

Tester Connection	Specified Condition
1 - 2	5.0 to 5.6 Ω at 20°C (68°F)

- (c) Connect the positive (+) lead with a 21 W bulb to terminal 2 and the negative (-) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

OK:

The solenoid makes an operating noise.

NG**REPLACE SHIFT SOLENOID VALVE SL1****OK****5 INSPECT TRANSMISSION VALVE BODY ASSEMBLY (See chapter 2 in the problem symptoms table)****OK:**

There are no foreign objects on any valves and they operate smoothly.

NG**REPAIR OR REPLACE TRANSMISSION VALVE BODY ASSEMBLY****OK****REPAIR OR REPLACE AUTOMATIC TRANSMISSION ASSEMBLY**