

## DIAGNOSTIC TROUBLE CODE CHART

If a trouble code is displayed during the DTC check, check the circuit listed for the code in the table below (proceed to the page listed for that circuit).

### 1. Occupant Classification ECU

HINT:

When DTC B1650/32 is detected as a result of troubleshooting the Supplemental Restraint System, perform troubleshooting for the occupant classification system as shown in the chart below.

DTC No.	Detection Item	Trouble Area	Passenger Airbag ON/OFF Indicator (OFF Indicator)	See page
B1771	Passenger Side Buckle Switch Circuit Malfunction	1. Front seat inner belt assembly (Buckle switch RH) 2. No. 1 seat wire 3. Floor wire 4. Occupant classification ECU	ON	<a href="#">RS-370</a>
B1780	Front Occupant Classification Sensor LH Circuit Malfunction	1. Front seat with adjuster frame assembly RH (Occupant classification sensor front LH) 2. No. 1 seat wire 3. Occupant classification ECU	ON	<a href="#">RS-377</a>
B1781	Front Occupant Classification Sensor RH Circuit Malfunction	1. Front seat with adjuster frame assembly RH (Occupant classification sensor front RH) 2. No. 1 seat wire 3. Occupant classification ECU	ON	<a href="#">RS-385</a>
B1782	Rear Occupant Classification Sensor LH Circuit Malfunction	1. Front seat with adjuster frame assembly RH (Occupant classification sensor rear LH) 2. No. 1 seat wire 3. Occupant classification ECU	ON	<a href="#">RS-393</a>
B1783	Rear Occupant Classification Sensor RH Circuit Malfunction	1. Front seat with adjuster frame assembly RH (Occupant classification sensor rear RH) 2. No. 1 seat wire 3. Occupant classification ECU	ON	<a href="#">RS-401</a>
B1785	Front Occupant Classification Sensor LH Collision Detection	1. Front seat with adjuster frame assembly RH (Occupant classification sensor front LH) 2. Occupant classification ECU	ON	<a href="#">RS-409</a>
B1786	Front Occupant Classification Sensor RH Collision Detection	1. Front seat with adjuster frame assembly RH (Occupant classification sensor front RH) 2. Occupant classification ECU	ON	<a href="#">RS-413</a>
B1787	Rear Occupant Classification Sensor LH Collision Detection	1. Front seat with adjuster frame assembly RH (Occupant classification sensor rear LH) 2. Occupant classification ECU	ON	<a href="#">RS-417</a>
B1788	Rear Occupant Classification Sensor RH Collision Detection	1. Front seat with adjuster frame assembly RH (Occupant classification sensor rear RH) 2. Occupant classification ECU	ON	<a href="#">RS-421</a>
B1790	Center Airbag Sensor Assembly Communication Circuit Malfunction	1. Floor wire 2. No. 1 seat wire 3. Occupant classification ECU 4. Center airbag sensor assembly	ON	<a href="#">RS-425</a>
B1793	Occupant Classification Sensor Power Supply Circuit Malfunction	1. Front seat with adjuster frame assembly RH (Occupant classification sensors) 2. No. 1 seat wire 3. Occupant classification ECU	ON	<a href="#">RS-434</a>
B1794	Open in Occupant Classification ECU Battery Positive Line	1. Wire harness 2. Occupant classification ECU	ON	<a href="#">RS-441</a>
B1795	Occupant Classification ECU Malfunction	1. Occupant classification ECU	ON	<a href="#">RS-446</a>

DTC No.	Detection Item	Trouble Area	Passenger Airbag ON/ OFF Indicator (OFF Indicator)	See page
B1796	Sleep Operation Failure of Occupant Classification ECU	1. Occupant classification ECU	ON	<a href="#">RS-448</a>