

REMOVAL

CAUTION:

Some of these service operations affect the SRS airbag system. Read the precautionary notices concerning the SRS airbag system before servicing (w/ Front Seat Side Airbag) (See page [RS-1](#)).

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL


Wait for at least 90 seconds after disconnecting the cable to prevent the airbag from working (w/ Front Seat Side Airbag).

2. REMOVE SEAT TRACK COVER

HINT:


Follow the same procedures as for the opposite side.

- (a) Disengage the 2 claws and remove the seat track cover.



3. REMOVE FRONT SEAT ASSEMBLY

- (a) Disconnect the connector.
- (b) w/ Front Seat Side Airbag:
 - (1) Disconnect the connector.
- (c) Using a clip remover, remove the wire harness clamp.



- (d) Remove the 4 bolts and front seat.




DISASSEMBLY

CAUTION:

Wear protective gloves. Sharp surfaces on the front seat back spring and front seat with adjuster frame could cause injuries to your hands.

1. REMOVE FRONT SEAT HEADREST ASSEMBLY


- Disengage the lock button of the front seat headrest support and remove the front seat headrest.



2. REMOVE FRONT SEAT INNER BELT ASSEMBLY (See page SE-39)


3. REMOVE FRONT SEAT CUSHION INNER SHIELD

- Remove the screw.
- Disengage the claw and clip, and remove the front seat cushion shield inner.




4. REMOVE RECLINING ADJUSTER RELEASE HANDLE


- Using a screwdriver with its tip taped in protective tape, disengage the claw and remove the reclining adjuster release handle.



5. REMOVE FRONT SEAT CUSHION SHIELD

- Remove the screw.
- Disengage the 2 claws and clip, and remove the front seat cushion shield.






6. REMOVE RECLINING ADJUSTER RELEASE KNOB LH

- (a) Using a screwdriver with its tip taped in protective tape, disengage the claw and remove the reclining adjuster release knob.

7. REMOVE RECLINING ADJUSTER RELEASE KNOB RH


HINT:

Follow the same procedures as for the reclining adjuster release handle LH.




8. REMOVE FRONT SEAT BACK SHIELD LH

- (a) Remove the screw.
- (b) Disengage the 3 claws and remove the front seat back shield.




9. REMOVE FRONT SEAT BACK SHIELD RH


- (a) w/ Front Seat Side Airbag:
 - (1) Using a clip remover, remove the connector clamp.
 - (2) Remove the wire harness clamp.




- (3) Remove the screw.
- (4) Disengage the 3 claws and remove the front seat back shield.



- (5) Disengage the 4 claws and remove the front seat side air bag wire.




- (b) w/o Front Seat Side Airbag:
 (1) Remove the screw.
 (2) Disengage the 3 claws and remove the front seat back shield.




10. REMOVE FRONT SEAT BACK ASSEMBLY

- (a) Remove the 4 bolts and front seat back.



11. REMOVE FRONT SEAT BACK BOARD

- (a) Disengage the 2 claws and 2 clips, and remove the front seat back board.




12. REMOVE FRONT SEAT BACK LOCK SUB-ASSEMBLY LH

- (a) Remove the 2 bolts and front seat back lock.

13. REMOVE FRONT SEAT BACK LOCK SUB-ASSEMBLY RH

HINT:

Follow the same procedures as for the front seat back lock sub-assembly LH.


**14. REMOVE FRONT SEAT HINGE COVER LH**

- (a) Remove the seat hinge cover.


15. REMOVE FRONT SEAT HINGE COVER RH

HINT:

Follow the same procedures as for the seat hinge cover LH.

**16. REMOVE FRONT SEAT BACK LOCK HANDLE ROD**


- (a) Remove the front seat back lock handle rod.

**17. REMOVE FRONT SEAT HEADREST SUPPORT**


HINT:

Follow the same procedures as for the opposite side.


- (a) Disengage the 2 claws and remove the front seat headrest support.

**18. REMOVE FRONT SEAT BACK SPRING ASSEMBLY**


- (a) w/ Front Seat Side Airbag:
- (1) Remove the bolt and inner hook.
 - (2) Remove the 9 hog rings.
 - (3) Remove the hook tape.
 - (4) Remove the front seat back spring from the front seat back pad.
- (b) w/o Front Seat Side Airbag:
- (1) Remove the 10 hog rings.
 - (2) Remove the hook tape.
 - (3) Remove the front seat back spring from the front seat back pad.

**19. REMOVE FRONT SEAT BACK COVER**


- (a) Remove the 10 hog rings and front seat back cover.

**20. REMOVE FRONT SEAT CUSHION ASSEMBLY**


- (a) Remove the 4 hog rings.
 (b) Remove the front seat cushion cover from the front seat frame adjuster.



- (c) Disengage the 2 claws and 3 hooks, and remove the front seat cushion pad together with the front seat cushion cover.

**21. REMOVE FRONT SEAT CUSHION COVER**

- (a) Remove the 12 hog rings and front seat cushion cover.


**22. REMOVE RECLINING ADJUSTER INSIDE COVER LH**

- (a) Remove the screw and reclining adjuster inside cover.

23. REMOVE RECLINING ADJUSTER INSIDE COVER RH

HINT:

Follow the same procedures as for the reclining adjuster inside cover LH.


**24. REMOVE RECLINING ADJUSTER OUTSIDE COVER LH**

- (a) Remove the screw and reclining adjuster outside cover.


25. REMOVE RECLINING ADJUSTER OUTSIDE COVER RH

HINT:

Follow the same procedures as for the reclining adjuster outside cover LH.

**26. REMOVE OCCUPANT CLASSIFICATION ECU**

- (a) Disconnect the 2 connectors.
(b) Disengage the claw and remove the occupant classification ECU.

**27. REMOVE SEAT WIRE**

- (a) Disconnect the 4 connectors.
(b) Using a clip remover, remove the 3 wire harness clamps and connector clamp.