



# HEADLIGHT RELAY

## INSPECTION

### 1. INSPECT HEADLIGHT RELAY

- (a) Check the resistance.
  - (1) Using an ohmmeter, measure the resistance between the terminals.

**Standard**

Tester Connection	Specified Condition
3-5	10 kΩ or higher
3-5	Below 1 Ω (When battery voltage applied to terminals 1 and 2)

If the result is not as specified, replace the headlight relay.