


INSTALLATION

1. INSTALL NO.2 RADIATOR HOSE

2. INSTALL RADIATOR HOSE INLET

3. INSTALL RADIATOR ASSEMBLY

- (a) Install the radiator with the 4 bolts.
Torque: 18 N*m (184 kgf*cm, 13 ft.*lbf)
- (b) Connect the 2 oil cooler hoses (with automatic transmission).



4. INSTALL FAN SHROUD

- (a) Provisionally install the fan shroud together with the fan pulley.
- (b) Install the fan and generator V belt (see page [EM-5](#)).
- (c) Install the fan pulley with the 4 nuts.
Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)
- (d) Install the fan shroud with the 2 bolts.
Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)
- (e) Install the 2 cooler hoses into the clamp (with automatic transmission).
- (f) Connect the hose to the radiator reserve tank.

5. INSTALL RADIATOR SUPPORT TO FRAME SEAL LH

6. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)

7. ADD ENGINE COOLANT (See page [CO-3](#))

8. CHECK FOR ENGINE COOLANT LEAKAGE (See page [CO-4](#))