



EXTENSION HOUSING REAR OIL SEAL

REMOVAL

1. **REMOVE PROPELLER WITH/CENTER BEARING SHAFT ASSEMBLY** (See page [PR-27](#))
2. **DRAIN AUTOMATIC TRANSMISSION FLUID**
 - (a) Remove the drain plug, gasket and drain ATF.
 - (b) Install a new gasket and drain plug.
Torque: 28 N*m (285 kgf*cm, 21 ft.*lbf)
3. **REMOVE AUTOMATIC TRANSMISSION EXTENSION HOUSING OIL SEAL**
 - (a) Using SST, remove the oil seal.
SST 09308-00010



INSTALLATION

1. **INSTALL AUTOMATIC TRANSMISSION EXTENSION HOUSING OIL SEAL**
 - (a) Using SST and a hammer, carefully tap in a new oil seal until it is flush with the automatic transmission extension housing.
SST 09316-60011 (09316-00011, 09316-00051)
Oil seal depth from flat end:
5.4 to 5.8 mm (0.213 to 0.228 in.)
 - (b) Coat the oil seal lip with MP grease.
2. **INSTALL PROPELLER WITH/CENTER BEARING SHAFT ASSEMBLY** (See page [PR-32](#))
3. **ADD AUTOMATIC TRANSMISSION FLUID**
(See page [AT-135](#))