

AVC-LAN Circuit


DESCRIPTION

All audio system units that are connected to the AVC-LAN (communication bus) use it as the communication line by which they transmit switch signals.


When a +B short or GND short occurs in the AVC- LAN, the audio system fails to function normally, due to the discontinuation of communication.

In the AVC-LAN, the radio receiver assembly is the main communication center and has the correct resistance necessary for transmitting communication signals.

WIRING DIAGRAM



1 INSPECT RADIO RECEIVER ASSEMBLY





- (a) Disconnect the R1 radio receiver assembly connector.
- (b) Measure the resistance.

Tester Connection	Condition	Specified Condition
TX+ (R1-5) - TX (R1-15)	Always	60 to 80 Ω

NG REPLACE RADIO RECEIVER ASSEMBLY

OK

2**CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - STEREO COMPONENT AMPLIFIER)****Radio Receiver Assembly
Wire Harness View:****Stereo Component Amplifier Assembly
Wire Harness View:**

Y

I101944E04

- (a) Disconnect the R1 radio receiver assembly connector and S23 stereo component amplifier assembly connector.

- (b) Check the resistance.

Standard

Tester Connection	Specified Condition
TX+ (S23-8) - TX+ (R1-15)	Below 1 Ω
TX+ (S23-7) - TX- (R1-15)	Below 1 Ω
TX+ (R1-5) - Body ground	10 k Ω or higher
TX+ (R1-5) - Body ground	10 k Ω or higher

NG**REPAIR OR REPLACE HARNESS OR
CONNECTOR****OK****3****REPLACE STEREO COMPONENT AMPLIFIER ASSEMBLY****NG****REPLACE RADIO RECEIVER ASSEMBLY****OK****END****AV**