

INSTALLATION


1. INSTALL FRONT STABILIZER BAR

2. INSTALL FRONT STABILIZER LOWER BRACKET BUSH LH

- (a) Install the front stabilizer lower bracket bush.

HINT:

- Install the bush onto the inner side of the bush stopper on the stabilizer bar.
- Install the bush onto the stabilizer bar with its cut line facing to the front.



3. INSTALL FRONT STABILIZER LOWER BRACKET BUSH RH

HINT:

The installation procedure for the RH side is the same as that for the LH side.

4. INSTALL FRONT STABILIZER BRACKET NO. 1 LH


- (a) Install the front stabilizer bracket with the 2 bolts.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

5. INSTALL FRONT STABILIZER BRACKET NO. 1 RH

HINT:

The installation procedure for the RH side is the same as that for the LH side.



6. INSTALL FRONT STABILIZER LINK ASSEMBLY LH

- (a) Install the front stabilizer link LH with the 2 nuts, 2 cushions and 2 retainers.

Torque: Nut A


19 N*m (194 kgf*cm, 14 ft.*lbf)

Nut B

69 N*m (704 kgf*cm, 51 ft.*lbf)

HINT:

If the ball joint turns together with the nut, use a hexagon (6 mm) wrench to hold the stud.



7. INSTALL FRONT STABILIZER LINK ASSEMBLY RH

HINT:

The installation procedure for the RH side is the same as that for the LH side.

8. INSTALL FRONT WHEELS

Torque: 113 N*m (1,152 kgf*cm, 83 ft.*lbf)