



INSTALLATION

1. INSTALL REAR DIFFERENTIAL CARRIER ASSEMBLY

- Remove any dust and oil from the differential carrier assembly and the contact surface of the axle housing.
- Install the new rear differential carrier gasket and the differential carrier assembly with the 11 nuts and washers.
- Connect the differential lock actuator connector.
- Connect the rear differential lock actuator breather hose to the differential actuator assembly.

2. INSTALL REAR AXLE SHAFT WITH BACKING PLATE LH (See page [AH-33](#))

3. INSTALL REAR AXLE SHAFT WITH BACKING PLATE RH

HINT:

Install the RH side by following the same procedures as the LH side.

4. INSTALL NO.3 PARKING BRAKE CABLE ASSEMBLY (See page [PB-22](#))

5. INSTALL NO.2 PARKING BRAKE CABLE ASSEMBLY

HINT:

Install the RH side by following the same procedures as the LH side.

6. INSTALL REAR SPEED SENSOR LH (See page [BC-304](#))

7. INSTALL REAR SPEED SENSOR RH

HINT:

Install the RH side by following the same procedures as the LH side.

8. INSTALL PROPELLER SHAFT ASSEMBLY (for 2WD Drive Type, Regular Cab) (See page [PR-6](#))

9. INSTALL PROPELLER WITH CENTER BEARING SHAFT ASSEMBLY (for 2WD Drive Type, Except Regular Cab) (See page [PR-13](#))

10. INSTALL PROPELLER SHAFT ASSEMBLY (for 4WD Drive Type, Regular Cab) (See page [PR-19](#))

11. INSTALL PROPELLER WITH CENTER BEARING SHAFT ASSEMBLY (for 4WD Drive Type, Except Regular Cab) (See page [PR-32](#))

12. INSTALL REAR BRAKE SHOE (See page [BR-71](#))

13. INSTALL FRONT BRAKE SHOE (See page [BR-72](#))

14. CHECK REAR BRAKE DRUM INSTALLATION (See page [BR-73](#))

15. INSTALL REAR BRAKE DRUM SUB-ASSEMBLY (See page [BR-73](#))
16. ADJUST REAR DRUM BRAKE SHOE CLEARANCE (See page [BR-74](#))
17. FILL RESERVOIR WITH BRAKE FLUID (w/ VSC) (See page [BR-4](#))
18. FILL RESERVOIR WITH BRAKE FLUID (w/o VSC) (See page [BR-7](#))
19. BLEED MASTER CYLINDER (w/o VSC) (See page [BR-7](#))
20. BLEED BRAKE LINE (w/ VSC) (See page [BR-4](#))
21. BLEED BRAKE LINE (w/o VSC) (See page [BR-7](#))
22. CHECK FLUID LEVEL IN RESERVOIR (w/ VSC) (See page [BR-6](#))
23. CHECK FLUID LEVEL IN RESERVOIR (w/o VSC) (See page [BR-8](#))
24. CHECK FOR BRAKE FLUID LEAKAGE
25. ADD DIFFERENTIAL OIL (See page [DF-8](#))
26. INSPECT DIFFERENTIAL OIL (See page [DF-8](#))
27. INSPECT FOR DIFFERENTIAL OIL LEAKAGE
28. INSTALL REAR WHEEL
Torque: 113 N*m (1,152 kgf*cm, 83 in.*lbf)
29. INSPECT PARKING BRAKE PEDAL TRAVEL (for Automatic Transaxle) (See page [PB-1](#))
30. INSPECT PARKING BRAKE LEVER TRAVEL (for Manual Transaxle) (See page [PB-1](#))
31. ADJUST PARKING BRAKE PEDAL TRAVEL (for Automatic Transaxle) (See page [PB-2](#))
32. ADJUST PARKING BRAKE LEVER TRAVEL (for Manual Transaxle) (See page [PB-2](#))
33. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL
Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)
34. CHECK VSC SENSOR SIGNAL (w/ VSC)
HINT:
(See page [BC-103](#))
35. CHECK ABS SENSOR SIGNAL (w/o VSC)
HINT:
(See page [BC-7](#))