
WIPER AND WASHER SYSTEM

PRECAUTION

1. **PRECAUTION OF WASHER NOZZLE ADJUSTMENT**
 - (a) Do not clean or adjust the washer nozzle with sharp metal objects, such as safety pins because;
 - (1) the washer nozzle tip is made of resin and could be damaged.
 - (2) adjustment is not necessary because it has a spray type nozzle.
 - (b) If the washer nozzle is clogged with materials such as wax, remove the objects and clean the nozzle hole with a soft resin brush, etc.

PARTS LOCATION

