

INSTALLATION

1. INSTALL DUTY VACUUM SWITCHING VALVE

- (a) Connect the hose to the vacuum switching valve.
- (b) Install the vacuum switching valve with the bolt.
Torque: 9.0 N*m (92 kgf*cm, 80 in.*lbf)
- (c) Connect the vapor feed hose.
- (d) Connect the connector.

2. INSTALL V-BANK COVER (See page [ES-416](#))

3. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)