

FRONT DOOR COURTESY SWITCH

INSPECTION

1. INSPECT FRONT DOOR COURTESY SWITCH

- (a) Check the resistance.
 - (1) Measure the resistance using an ohmmeter, and check the results in accordance with the value(s) in the table below.

Standard

| Tester Connection | Condition | Specified Condition |
|-------------------|---------------------------------|-------------------------|
| 1-Switch body | ON (When shaft is pressed) | 10 k Ω or higher |
| 1-Switch body | OFF (When shaft is not pressed) | Below 1 Ω |

If the result is not as specified, replace the front door courtesy light switch assembly.