

REAR DOOR COURTESY SWITCH

INSPECTION

- 1. **INSPECT REAR DOOR COURTESY SWITCH**
 - (a) Check the resistance.
 - (1) Measure the resistance using an ohmmeter, and check the results in accordance with the value(s) in the table below.

Standard

Tester Connection	Condition	Specified Condition
1-Switch body	ON (When shaft is pressed)	10 kΩ or higher
1-Switch body	OFF (When shaft is not pressed)	Below 1 Ω

If the result is not as specified, replace the rear door courtesy light switch assembly.

