




## REMOVAL


1. **PRECAUTION**  
(See page [RS-1](#))
2. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**  
HINT:  
Wait for at least 90 seconds after disconnecting the cable to prevent the airbag from working.
3. **REMOVE CONSOLE UPPER REAR PANEL SUB-ASSEMBLY** (for Automatic Transmission on Separate Seat Type) (See page [IP-9](#))
4. **REMOVE CONSOLE UPPER REAR PANEL SUB-ASSEMBLY** (for Manual Transmission on Separate Seat Type) (See page [IP-9](#))
5. **REMOVE REAR CONSOLE BOX ASSEMBLY** (for Separate Seat Type) (See page [IP-10](#))
6. **REMOVE INSTRUMENT PANEL CUP HOLDER TRAY** (for Automatic Transmission on Separate Seat Type) (See page [IP-10](#))
7. **REMOVE FRONT CONSOLE BOX** (for Automatic Transmission on Separate Seat Type) (See page [IP-10](#))
8. **REMOVE FRONT CONSOLE BOX** (for Manual Transmission on Separate Seat Type) (See page [IP-11](#))
9. **REMOVE FRONT CONSOLE BOX** (for Automatic Transmission on Bench Seat Type) (See page [IP-11](#))
10. **REMOVE FRONT CONSOLE BOX** (for Manual Transmission on Bench Seat Type) (See page [IP-11](#))
11. **REMOVE CENTER AIRBAG SENSOR ASSEMBLY** (See page [RS-603](#))
12. **REMOVE VOLTAGE INVERTER ASSEMBLY** (w/ Voltage Inverter) (See page [AV-104](#))
13. **REMOVE PARKING BRAKE CABLE JOINT PROTECTOR** (for Bench Seat Type) (See page [PB-2](#))
14. **REMOVE REAR WHEEL**
15. **REMOVE REAR BRAKE DRUM SUB-ASSEMBLY** (See page [BR-68](#))
16. **REMOVE FRONT BRAKE SHOE** (See page [BR-68](#))
17. **REMOVE REAR BRAKE SHOE** (See page [BR-69](#))
18. **REMOVE PARKING BRAKE CABLE ASSEMBLY NO. 1** (for Automatic Transmission)
  - (a) Release the parking brake.





- (b) Disengage the claw A.
- (c) Remove the lock nut B, adjusting nut C and clip D and disconnect the parking brake cable from the parking brake control pedal.
- (d) Remove the 4 nuts A, 2 clamps B and 2 bolts C from the parking brake cable.




- (e) Remove the lock nut A, adjusting nut B and parking brake cable from the parking brake equalizer.
- 19. REMOVE PARKING BRAKE CABLE ASSEMBLY NO. 1 (for Manual Transmission)**
- (a) Release the parking brake lever.





- (b) Disengage the clip, remove the pin and separate the sleeve.
- (c) Disengage the clip and disconnect the parking brake cable from the parking brake lever.
- (d) Remove the 2 nuts A, 2 clamps B and 2 bolts C from the parking brake cable.




- (e) Remove the lock nut A, adjusting nut B and parking brake cable from the parking brake equalizer.


**20. REMOVE PARKING BRAKE CABLE ASSEMBLY NO.****3**

- (a) Remove the 2 bolts and disconnect the parking brake cable from the backing plate.
- (b) Remove the 4 bolts from the parking brake cable.






- (c) Disengage the clip and disconnect the parking brake cable from the parking brake equalizer.



PB



## INSTALLATION

1. **INSTALL PARKING BRAKE CABLE ASSEMBLY NO. 3**
  - (a) Install the parking brake cable with the clip onto the parking brake equalizer.
  - (b) Install the parking brake cable with the 4 bolts.  
**Torque: 13 N\*m (127 kgf\*cm, 9 ft.\*lbf)**