


GENERATOR (for BOSCH Made)

COMPONENTS




N*m (kgf*cm, ft*lbf) : Specified torque


● Non-reusable part

REMOVAL


1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE V-BANK COVER** (See page [ES-414](#))
3. **REMOVE RADIATOR SUPPORT TO FRAME SEAL LH** (See page [CO-15](#))
4. **REMOVE FAN SHROUD** (See page [CO-15](#))
5. **REMOVE GENERATOR ASSEMBLY**



- (a) Disconnect the wire harness.
 - (1) Remove the bolt and wire harness stay.
 - (2) Disconnect the connector from the generator assembly.
 - (3) Remove the terminal cap and nut.
 - (4) Disconnect the wire harness from terminal B.




- (b) Remove the 2 bolts, then separate the wire harness clamp bracket from the generator assembly.




- (c) Remove the 2 bolts, then remove the generator assembly.


DISASSEMBLY

1. **REMOVE REAR GENERATOR END COVER**
 - (a) Remove the 2 terminal covers by turning them counterclockwise.






- (b) Using a 15 mm socket wrench, remove the 2 nuts from the generator rear end cover.
- (c) Remove the screw, then remove the generator rear end cover.




2. REMOVE REGULATOR SUB-ASSEMBLY GENERATOR W/BRUSH

- (a) Remove the 3 screws, then remove the regulator generator with brush.




3. REMOVE STATOR SUB-ASSEMBLY GENERATOR W/ RECTIFIER

- (a) Remove the 4 screws.



- (b) Using a screwdriver, pry out the stator generator with rectifier.




4. REMOVE BEARING SET GENERATOR

5. REMOVE PULLEY SET GENERATOR


- (a) Clamp the swivel arm in a vise.

NOTICE:

Do not clamp the generator rotor in a vise.




- (b) Using a socket 24 AF and 8 mm bi-hexagon wrench, remove the nut and spring washer, then detach the pulley.



6. REMOVE GENERATOR ROTOR ASSEMBLY

- (a) Using a press, press out the generator rotor assembly and spacer ring.



INSPECTION

1. INSPECT GENERATOR ROTOR ASSEMBLY

- (a) Inspect the generator rotor assembly for an open circuit.

- (1) Using an ohmmeter, measure the resistance between the slip rings.

Standard:

1.8 to 2.8 Ω at 20°C(68°F)

If the result is not as specified, replace the generator rotor.


- (b) Inspect the generator rotor assembly for ground.

- (1) Using an ohmmeter, measure the resistance between the slip ring and generator rotor assembly.

Standard:

10 k Ω or higher

If the result is not as specified, replace the generator rotor.



- (c) Check the appearance.

- (1) Check that the slip rings are not rough or scored.

If rough or scored, replace the generator rotor.


- (2) Using vernier calipers, measure the slip ring diameter.

Standard diameter:

15.3 to 15.5 mm (0.602 to 0.610 in.)

Minimum diameter:

14.9 mm (0.587 in.)





If the diameter is less than the minimum, replace the generator rotor.

2. INSPECT STATOR SUB-ASSEMBLY GENERATOR WITH RECTIFIER

HINT:

For terminal positions of the stator generator, refer to the illustration below.



(a) Inspect the positive (+) rectifier.

HINT:

Inspect the positive terminal after pulling it up.

- (1) Using an ohmmeter, connect the positive (+) tester probe to the positive (+) terminal and the negative (-) tester probe to each rectifier terminal.
- (2) Measure the resistance between the positive (+) terminal and rectifier terminal.

Standard:

Below 1 Ω

If the result is not as specified, replace the stator generator.

- (3) Reverse the polarity of the tester probes and repeat step (1).
- (4) Measure the resistance between the positive (+) terminal and rectifier terminal.

Standard:

10 k Ω or higher

If the result is not as specified, replace the stator generator.

(b) Inspect the negative (-) rectifier.


- (1) Using an ohmmeter, connect the positive (+) tester probe to each negative (-) terminal and the negative (-) tester probe to each rectifier terminal.
- (2) Measure the resistance between the negative (-) terminal and rectifier terminal.

Standard:

10 k Ω or higher

If the result is not as specified, replace the stator generator.

- (3) Reverse the polarity of the tester probes and repeat step (1).



- (4) Measure the resistance between the negative (-) terminal and rectifier terminal.

Standard:

Below 1 Ω

If the result is not as specified, replace the stator generator.



- (c) Inspect the stator for an open circuit.

- (1) Using an ohmmeter, measure the resistance between the rectifier terminals.

Standard:

Below 1 Ω

If the result is not as specified, replace the stator generator.



3. INSPECT BRUSH

- (a) Using vernier calipers, measure the brush length.


Exposed length on new brush:

13.2 mm (0.520 in.)

Minimum exposed length:

6 mm (0.236 in.)

If the exposed length is less than the minimum, replace the voltage regulator and brush assembly.



REASSEMBLY


1. INSTALL GENERATOR ROTOR ASSEMBLY

- (a) Using SST and a press, press in the generator rotor assembly.

SST 09285-76010


NOTICE:

Avoid misalignment during pressing.



2. INSTALL PULLEY SET GENERATOR

- (a) Install the spacer ring.




- (b) Using a socket 24 AF and 8 mm bi-hexagon wrench, install the pulley with the spring washer and nut.

Torque: 65 N*m (663 kgf*cm, 48 ft.*lbf)

3. INSTALL BEARING SET GENERATOR


- (a) Align the 3 cutouts of the bearing set generator with the stator generator with rectifier.



4. INSTALL STATOR SUB-ASSEMBLY GENERATOR WITH RECTIFIER

- (a) Align the key of the drive end frame with the keyway of the stator sub-assembly generator with rectifier.
(b) Install the stator generator with rectifier with the 4 bolts.

Torque: 4.3 N*m (44 kgf*cm, 38 in.*lbf)





5. INSTALL REGULATOR SUB-ASSEMBLY GENERATOR WITH BRUSH


- (a) Attach the brushes and terminals to the rectifier end frame of the regulator generator with brush.
(b) Install the regulator generator with brush with the 3 screws.

HINT:

Install the screw B into the position shown in the illustration.




Torque: 2.5 N*m (25 kgf*cm, 22 in.*lbf) for screw A
1.2 N*m (12 kgf*cm, 11 in.*lbf) for screw B



6. INSTALL REAR GENERATOR END COVER

- (a) Install the generator rear end cover with the 2 nuts and screw.

Torque: 19 N*m (194 kgf*cm, 14 ft.*lbf) for nut A
12 N*m (122 kgf*cm, 9 ft.*lbf) for nut B
2.8 N*m (29 kgf*cm, 25 in.*lbf) for screw



- (b) Install the 2 terminal covers by turning them clockwise.