

# HOW TO PROCEED WITH TROUBLESHOOTING

HINT:  
\*: Use the intelligent tester.

1

VEHICLE BROUGHT TO WORKSHOP

NEXT

2

CUSTOMER PROBLEM ANALYSIS

NEXT

3

PROBLEM SYMPTOM CONFIRMATION

SYMPTOM DOES NOT OCCUR (Go to step 4)

SYMPTOM OCCURS (Go to step 5)

4

SYMPTOM SIMULATION

NEXT

5

CHECK CAN COMMUNICATION SYSTEM

(a) Check the battery voltage.  
Standard Voltage:  
11 to 14 V

NEXT

6

DTC CHECK\*

(a) Check for cruise control system DTC output.

DTCS BEEN STORED (Go to step 7)

NO DTC OUTPUT (Go to step 8)

7

DTC CHART

NEXT

**8** PROBLEM SYMPTOM TABLE

NEXT

**9** CIRCUIT INSPECTION\*

NEXT

**10** TERMINALS OF ECU

NEXT

**11** IDENTIFICATION OF PROBLEM

NEXT

**12** REPAIR OR REPLACE

NEXT

**13** CONFIRMATION TEST\*

NEXT

END