

---

## REASSEMBLY

1. **INSTALL FUEL PRESSURE REGULATOR ASSEMBLY**
  - (a) Install the new O-ring into the fuel pump case.
  - (b) Install the new O-ring onto the fuel pressure regulator.
2. **INSTALL FUEL PUMP FILTER**
3. **INSTALL FUEL PUMP ASSEMBLY**
4. **INSTALL NO. 1 FUEL SUB-TANK**
5. **INSTALL FUEL SENDER GAGE ASSEMBLY**

## INSTALLATION

1. INSTALL FUEL SUCTION WITH PUMP & GAGE TUBE ASSEMBLY (See page [FU-34](#))
2. INSTALL FUEL TANK MAIN TUBE AND FUEL TANK RETURN TUBE (See page [FU-35](#))
3. INSTALL FUEL TANK ASSEMBLY (See page [FU-35](#))
4. CONNECT FUEL TANK MAIN TUBE AND FUEL TANK RETURN TUBE (See page [FU-36](#))
5. ADD FUEL
6. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL  
Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)
7. CHECK FOR FUEL LEAKAGE (See page [FU-7](#))