



AIRBAG CUT-OFF SWITCH


COMPONENTS

**RS**

REMOVAL

1. **PRECAUTION**
(See page [RS-1](#))
2. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
3. **REMOVE INSTRUMENT PANEL UNDER TRAY** (for Pedal Type Parking Brake) (See page [IP-9](#))
4. **REMOVE INSTRUMENT PANEL HOLE COVER** (for Lever Type Parking Brake) (See page [IP-9](#))
5. **REMOVE AIR CONDITIONING CONTROL ASSEMBLY**
(See page [IP-12](#))
6. **REMOVE RADIO RECEIVER ASSEMBLY WITH BRACKET** (See page [AV-69](#))
7. **SEPARATE HOOD LOCK CONTROL LEVER SUB-ASSEMBLY** (See page [ED-3](#))
8. **REMOVE NO.1 LOWER INSTRUMENT PANEL FINISH PANEL** (See page [IP-12](#))
9. **REMOVE INSTRUMENT LOWER PANEL LH** (See page [IP-14](#))
10. **REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY** (See page [IP-12](#))
11. **REMOVE CENTER INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY** (See page [IP-13](#))
12. **REMOVE SWITCH BASE HOLE COVER**
 - (a) Disengage the 3 claws and remove the switch base hole cover.





13. REMOVE AIRBAG CUT OFF SWITCH

- (a) Disconnect the airbag cut off switch connector.
- (b) Remove the instrument cluster finish panel sub-assembly center while holding the 2 claws of the airbag cut off switch.

INSPECTION


1. INSPECT AIRBAG CUT OFF SWITCH

- (a) Check the resistance.
 - (1) Using an ohmmeter, measure the resistance between the terminals.

Standard :

Switch Connection	Tester Condition	Specified Condition
OFF	1 (MSW+) - 2 (MSW-)	80 to 120Ω
ON	1 (MSW+) - 2 (MSW-)	320 to 480Ω

If the result is not as specified, replace the air bag cut off switch.



INSTALLATION

1. INSTALL AIRBAG CUT-OFF SWITCH

- (a) Engage the 2 claws of the cut off switch with the instrument cluster finish panel sub-assembly center.
- (b) Attach the connector to the airbag cut off switch.

