



## VSC TRAC Warning Light Remains ON

### DESCRIPTION

When the skid control ECU stores DTCs, the VSC and TRAC functions are deactivated, the VSC TRAC warning light comes on in the combination meter.

### WIRING DIAGRAM





**NOTICE:**

**When replacing the master cylinder solenoid, perform zero point calibration (See page BC-99).**

1	CHECK DTC
---	-----------

(a) Check if DTCs for VSC are recorded.

Result	Proceed to
DTC not output	A
DTC output	B

B

## REPAIR CIRCUITS INDICATED BY OUTPUT DTCS

**A**

2	INSPECT SKID CONTROL ECU CONNECTOR
---	------------------------------------

(a) Check that the ECU connector is securely connected.

**OK:**

The connector is securely connected.

**NG****CONNECT CONNECTOR CORRECTLY****OK****3****INSPECT SKID CONTROL ECU TERMINAL VOLTAGE (IG1 TERMINAL)**

(a) When using intelligent tester:

- (1) Connect the intelligent tester to the DLC3.
- (2) Start the engine.
- (3) Select the DATA LIST mode on the intelligent tester.
- (4) Measure the voltage output from the ECU displayed on the intelligent tester.

Item	Measurement Item / Range (Display)	Normal Condition	Diagnostic Note
IG VOLTAGE	ECU power supply voltage: TOO LOW / NORMAL / TOO HIGH	TOO HIGH: 14 V or more NORMAL: 9.5 to 14V TOO LOW: Below 9.5 V	-

**OK:****"Normal" is displayed.**

(b) When not using intelligent tester:


- (1) Disconnect the skid control ECU connector.
- (2) Turn the ignition switch to the ON position.
- (3) Measure the voltage.

**Standard**

Tester Connection	Specified Condition
S1-46 (IG1) - Body ground	10 to 14 V

**BC**

- (4) Turn the ignition switch to OFF.
- (5) Reconnect the skid control ECU connector.

**Skid Control ECU  
(harness side connector):**


C121700E02

Result	Proceed to
OK (models with rear diff. lock)	A
OK (models without rear diff. lock)	B
NG	C

**B****Go to step 6****C****REPAIR OR REPLACE HARNESS OR  
CONNECTOR****A**

4

INSPECT REAR DIFFERENTIAL LOCK SWITCH



- (a) Remove the rear diff. lock switch.
- (b) Disconnect the rear diff. lock switch connector.
- (c) Measure the resistance.

Standard

Tester Connection	Switch Condition	Specified Condition
D5-3 - D5-4	Released	10 kΩ or higher
D5-3 - D5-4	Pushed in	Below 1 Ω

- (d) Reconnect the rear diff. lock switch connector.
- (e) Reinstall the rear diff. lock switch.


NG

REPLACE REAR DIFFERENTIAL LOCK SWITCH

OK

5

CHECK HARNESS AND CONNECTOR (4WD CONTROL ECU - REAR DIFFERENTIAL LOCK SWITCH)



- (a) Disconnect the 4WD control ECU connector.
- (b) Disconnect the rear diff. lock connector
- (c) Measure the resistance.

Standard (4WD)

Tester Connection	Specified Condition
F12-16 (R) - D5-4	Below 1 Ω
F12-16 (R) - Body ground	10 kΩ or higher

Standard (2WD)



Tester Connection	Specified Condition
F14-4 (R) - D5-4	Below 1 Ω
F14-4 (R) - Body ground	10 kΩ or higher

- (d) Reconnect the rear diff. lock connector.
- (e) Reconnect the 4WD control ECU connector.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

**6****CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - COMBINATION METER)****Combination Meter (harness side view)****Skid Control ECU (harness side connector)**

F049577E03

- (a) Disconnect the skid control ECU connector.
- (b) Disconnect the combination meter connector.
- (c) Measure the resistance.

**Standard**

Tester Connection	Specified Condition
C9-38 - S1-36 (VSCW)	Below 1 $\Omega$

- (d) Measure the resistance.

**Standard**

Tester Connection	Specified Condition
S1-36 (VSCW) - Body ground	10 k $\Omega$ or higher

- (e) Reconnect the combination meter connector.
- (f) Reconnect the skid control ECU connector.

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****7****INSPECT COMBINATION METER ASSEMBLY****BC**

- (a) Check the combination meter system (See page [ME-8](#)).

**OK:****Combination meter is normal.****NG****REPLACE COMBINATION METER ASSEMBLY****OK****REPLACE MASTER CYLINDER SOLENOID**