



All Doors cannot be Locked / Unlocked Simultaneously**DESCRIPTION**

The multiplex network body ECU activates the door lock motors with switch signals from the master switch, door control switch and driver/passenger side door key cylinder.

WIRING DIAGRAM



Continued from previous page



Y

B125004E02

1 INSPECT ALL DOORS LOCK/UNLOCK OPERATION

All the doors can be locked/unlocked simultaneously using the following items:

- Door control switch on the master switch (switch operation)
- Door control switch on the front passenger side (switch operation)
- Door key cylinder linked with driver and passenger side door lock (key operation)

If all the doors cannot be locked/unlocked simultaneously, proceed to the next step according to the malfunctioning part shown in the table below.

Result:

Malfunctioning Part	Proceed to
Driver side doors	A
Passenger side doors	B
All items are malfunctioning	C

B

Go to step 3

C

Go to step 14

DL

A

2

INSPECT DRIVER SIDE DOORS LOCK/UNLOCK OPERATION

Malfunctioning Part	Proceed to
Door control switch on master switch	A
Driver side door key cylinder	B
Door control switch on master switch and driver side door key cylinder	C

A

Go to step 4

B

Go to step 6

C

Go to step 9

3

INSPECT PASSENGER SIDE DOORS LOCK/UNLOCK OPERATION

Malfunctioning Part	Proceed to
Door control switch on passenger side switch	A
Passenger side door key cylinder	B
Door control switch on passenger side and passenger side door key cylinder	C

A

Go to step 16

B


Go to step 18

C


Go to step 21

4 INSPECT POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY (DOOR CONTROL SWITCH)

Component Side (Double Cab):



Component Side (Access Cab):



- (a) Remove the power window regulator master switch assembly.
- (b) Measure the resistance of the door control switch.

Standard (Double cab)

Tester Connection	Switch Condition	Specified Condition
1 (E) - 5 (L)	Lock	Below 1 Ω
1 (E) - 5 (L) 1 (E) - 8 (UL)	OFF	10 kΩ or higher
1 (E) - 8 (UL)	Unlock	Below 1 Ω

Standard (Access cab)

Tester Connection	Switch Condition	Specified Condition
1 (E) - 2 (L)	Lock	Below 1 Ω
1 (E) - 2 (L) 1 (E) - 5 (UL)	OFF	10 kΩ or higher
1 (E) - 5 (UL)	Unlock	Below 1 Ω

- (c) Reinstall the power window regulator master switch assembly.

NG

REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY

OK


5

CHECK HARNESS AND CONNECTOR (MASTER SWITCH (SWITCH) - DRIVER SIDE J/B AND BODY GROUND)

Wire Harness Side (Double Cab):

Power Window Regulator Master Switch


P9



Front View

Driver Side J/B

11




Front View

Wire Harness Side (Access Cab):

Power Window Regulator Master Switch


P9



Front View

Driver Side J/B

11



Front View

Y

B128474E01

(a) Disconnect the P9 power window regulator master switch connector.

(b) Disconnect the 11 driver side J/B connector.

(c) Measure the resistance.

Standard (Double cab)

Tester Connection	Specified Condition
P9-5 (L) - 11-18 (L1)	Below 1 Ω
P9-8 (UL) - 11-14 (UL1)	Below 1 Ω
P9-1 (E) - Body ground	Below 1 Ω
P9-5 (L) or 11-18 (L1) - Body ground	10 kΩ or higher
P9-8 (UL) or 11-14 (UL1) - Body ground	10 kΩ or higher

Standard (Access cab)

Tester Connection	Specified Condition
P9-2 (L) - 11-18 (L1)	Below 1 Ω
P9-5 (UL) - 11-14 (UL1)	Below 1 Ω
P9-1 (E) - Body ground	Below 1 Ω
P9-2 (L) or 11-18 (L1) - Body ground	10 kΩ or higher
P9-5 (UL) or 11-14 (UL1) - Body ground	10 kΩ or higher

(d) Reconnect the power window regulator master switch connector.

(e) Reconnect the driver side J/B connector.


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK

DL

6 INSPECT FRONT DOOR LOCK ASSEMBLY LH (DOOR LOCK MOTOR)**Component Side:**

T

B065427E16

- (a) Apply battery voltage to the door lock and check operation of the door lock motor.

NOTICE:


Do not apply battery voltage to any terminals except terminals 1 and 4.

OK

Terminal No	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock

NG

REPLACE FRONT DOOR LOCK ASSEMBLY LH

OK**7 INSPECT FRONT DOOR LOCK ASSEMBLY LH (DOOR LOCK AND UNLOCK SWITCH AND POSITION SWITCH)****Component Side:**

T

B065428E06

- (a) Measure the resistance of the door lock and unlock switch and position switch.

Standard (Door lock and unlock switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 9	Lock	Below 1 Ω
7 - 9, 7 - 10	OFF	10 k Ω or higher
7 - 10	Unlock	Below 1 Ω

Standard (Position switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 8	Lock	10 k Ω or higher
7 - 8	Unlock	Below 1 Ω


NG

REPLACE FRONT DOOR LOCK ASSEMBLY LH

OK

8

CHECK HARNESS AND CONNECTOR (FRONT DOOR LOCK LH - ECU, DRIVER SIDE J/B AND BODY GROUND)



- (a) Disconnect the D19 front door lock connector.
- (b) Disconnect the B5 multiplex network body ECU connector.
- (c) Disconnect the 1H and 1I driver side J/B connectors.
- (d) Measure the resistance.

Standard

Tester Connection	Specified Condition
D19-4 - 1H-24 (ACT+)	Below 1 Ω
D19-1 - B5-3 (ACTD)	Below 1 Ω
D19-9 - 1I-17 (L2)	Below 1 Ω
D19-10 - B5-23 (UL3)	Below 1 Ω
D19-8 - B5-20 (LSWD)	Below 1 Ω
D19-7 - Body ground	Below 1 Ω
D19-4 or 1H-24 (ACT+) - Body ground	10 kΩ or higher
D19-1 or B5-3 (ACTD) - Body ground	10 kΩ or higher
D19-9 or 1I-17 (L2) - Body ground	10 kΩ or higher
D19-10 or B5-23 (UL3) - Body ground	10 kΩ or higher
D19-8 or B5-20 (LSWD) - Body ground	10 kΩ or higher

- (e) Reconnect the front door lock connector.
- (f) Reconnect the multiplex network body ECU connector.
- (g) Reconnect the driver side J/B connectors.

NG


REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK (MULTIPLEX NETWORK BODY ECU)

9 INSPECT FRONT DOOR LOCK ASSEMBLY LH (DOOR LOCK MOTOR)

Component Side:



T

B065427E16

- (a) Apply battery voltage to the door lock and check operation of the door lock motor.

NOTICE:

Do not apply battery voltage to any terminals except terminals 1 and 4
OK


Terminal No	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock

NG

REPLACE FRONT DOOR LOCK ASSEMBLY LH

OK**10 INSPECT FRONT DOOR LOCK ASSEMBLY LH (DOOR LOCK AND UNLOCK SWITCH AND POSITION SWITCH)**

Component Side:



T

B065428E06

- (a) Measure the resistance of the door lock and unlock switch and position switch.

Standard (Door lock and unlock switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 9	Lock	Below 1 Ω
7 - 9 7 - 10	OFF	10 k Ω or higher
7 - 10	Unlock	Below 1 Ω

Standard (Position switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 8	Lock	10 k Ω or higher
7 - 8	Unlock	Below 1 Ω

NG


REPLACE FRONT DOOR LOCK ASSEMBLY LH

OK

11 CHECK HARNESS AND CONNECTOR (FRONT DOOR LOCK LH - ECU, DRIVER SIDE J/B AND BODY GROUND)


Wire Harness Side:

Front Door Lock Assembly LH




Front View

Multiplex Network Body ECU




Front View

Driver Side J/B



Driver Side J/B



Front View

T B088348E01

- (a) Disconnect the D19 front door lock connector.
- (b) Disconnect the B5 multiplex network body ECU connector.
- (c) Disconnect the 1H and 1I driver side J/B connectors.
- (d) Measure the resistance of the wire harness side connectors.

Standard

Tester Connection	Specified Condition
D19-4 - 1H-24 (ACT+)	Below 1 Ω
D19-1 - B5-3 (ACTD)	Below 1 Ω
D19-9 - 1I-17 (L2)	Below 1 Ω
D19-10 - B5-23 (UL3)	Below 1 Ω
D19-8 - B5-20 (LSWD)	Below 1 Ω
D19-7 - Body ground	Below 1 Ω
D19-4 or 1H-24 (ACT+) - Body ground	10 kΩ or higher
D19-1 or B5-3 (ACTD) - Body ground	10 kΩ or higher
D19-9 or 1I-17 (L2) - Body ground	10 kΩ or higher
D19-10 or B5-23 (UL3) - Body ground	10 kΩ or higher
D19-8 or B5-20 (LSWD) - Body ground	10 kΩ or higher



- (e) Reconnect the front door lock connector.
- (f) Reconnect the multiplex network body ECU connector.
- (g) Reconnect the driver side J/B connectors.

NG REPAIR OR REPLACE HARNESS OR CONNECTOR



OK

12 INSPECT POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY (DOOR CONTROL SWITCH)

Component Side (Double Cab):



Component Side (Access Cab):



Y

B128473E01

- (a) Remove the power window regulator master switch assembly.
- (b) Measure the resistance of the door control switch.

Standard (Double cab)

Tester Connection	Switch Condition	Specified Condition
1 (E) - 5 (L)	Lock	Below 1 Ω
1 (E) - 5 (L) 1 (E) - 8 (UL)	OFF	10 kΩ or higher
1 (E) - 8 (UL)	Unlock	Below 1 Ω

Standard (Access cab)

Tester Connection	Switch Condition	Specified Condition
1 (E) - 2 (L)	Lock	Below 1 Ω
1 (E) - 2 (L) 1 (E) - 5 (UL)	OFF	10 kΩ or higher
1 (E) - 5 (UL)	Unlock	Below 1 Ω

- (c) Reinstall the power window regulator master switch assembly.

NG

REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY

OK

DL


13

CHECK HARNESS AND CONNECTOR (MASTER SWITCH (SWITCH) - DRIVER SIDE J/B AND BODY GROUND)

Wire Harness Side (Double Cab):

Power Window Regulator Master Switch


P9



Front View

Driver Side J/B

11




Front View

Wire Harness Side (Access Cab):

Power Window Regulator Master Switch


P9



Front View

Driver Side J/B

11



Front View

Y

B128474E01

(a) Disconnect the P9 power window regulator master switch connector.

(b) Disconnect the 11 driver side J/B connector.

(c) Measure the resistance.

Standard (Double cab)

Tester Connection	Specified Condition
P9-5 (L) - 11-18 (L1)	Below 1 Ω
P9-8 (UL) - 11-14 (UL1)	Below 1 Ω
P9-1 (E) - Body ground	Below 1 Ω
P9-5 (L) or 11-18 (L1) - Body ground	10 kΩ or higher
P9-8 (UL) or 11-14 (UL1) - Body ground	10 kΩ or higher

Standard (Access cab)

Tester Connection	Specified Condition
P9-2 (L) - 11-18 (L1)	Below 1 Ω
P9-5 (UL) - 11-14 (UL1)	Below 1 Ω
P9-1 (E) - Body ground	Below 1 Ω
P9-2 (L) or 11-18 (L1) - Body ground	10 kΩ or higher
P9-5 (UL) or 11-14 (UL1) - Body ground	10 kΩ or higher

(d) Reconnect the power window regulator master switch connector.

(e) Reconnect the driver side J/B connector.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK

DL

14 INSPECT FUSE (DR LCK, J/B, ECU-B, ALT)


- Remove the DR LCK fuse from the driver side J/B.
- Remove the J/B, ECU-B and ALT fuses from the engine room R/B.
- Measure the resistance of the fuse.

Standard:**Below 1 Ω**

- Reinstall the DR LCK fuse.
- Reinstall the J/B, ECU-B and ALT fuses.

NG**REPLACE FUSE****OK****15 CHECK HARNESS AND CONNECTOR (DRIVER SIDE J/B ASSEMBLY - BODY GROUND)**

- Disconnect the 1A, 1C, and 1H driver side J/B connectors.
- Measure the voltage and resistance.

Wire Harness Side:

Y


B125003E01

Standard

Tester Connection	Specified Condition
1A-6 (ALTB) - Body ground	10 to 14 V
1H-18 (GND) - Body ground	Below 1 Ω
1C-16 (ECUB) - Body ground	10 to 14 V

- Reconnect the driver side J/B connectors.

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****REPLACE DRIVER SIDE JUNCTION BLOCK**



16 INSPECT DOOR CONTROL SWITCH ASSEMBLY

- (a) Remove the door control switch (passenger side).
 (b) Measure the resistance of the door control switch.

Standard

Tester Connection	Switch Condition	Specified Condition
3 (E) - 6 (L)	Lock	Below 1 Ω
3 (E) - 5 (UL) 3 (E) - 6 (L)	OFF	10 k Ω or higher
3 (E) - 5 (UL)	Unlock	Below 1 Ω

- (c) Reinstall the door control switch.

NG**REPLACE DOOR CONTROL SWITCH ASSEMBLY****OK****17 CHECK HARNESS AND CONNECTOR (DOOR CONTROL SWITCH - DRIVER SIDE J/B AND BODY GROUND)****Wire Harness Side:**

- (a) Disconnect the D23 door control switch connector.
 (b) Disconnect the 11 driver side J/B connector.
 (c) Measure the resistance.

Standard


Tester Connection	Specified Condition
D23-6 (L) - 11-7 (L1)	Below 1 Ω
D23-5 (UL) - 11-3 (UL1)	Below 1 Ω
D23-3 (E) - Body ground	Below 1 Ω
D23-6 (L) or 11-7 (L1) - Body ground	10 k Ω or higher
D23-5 (UL) or 11-3 (UL1) - Body ground	10 k Ω or higher

- (d) Reconnect the door control switch connector.
 (e) Reconnect the driver side J/B connector.

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****REPLACE DRIVER SIDE JUNCTION BLOCK**

18 INSPECT FRONT DOOR LOCK ASSEMBLY RH (DOOR LOCK MOTOR)

Component Side:



T

B065429E16

- (a) Apply battery voltage to the door lock and check operation of the door lock motor.

NOTICE:

Do not apply battery voltage to any terminals except terminals 1 and 4.

OK


Terminal No	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock

NG

REPLACE FRONT DOOR LOCK ASSEMBLY RH

OK**19 INSPECT FRONT DOOR LOWER FRAME BRACKET GARNISH RH (DOOR LOCK AND UNLOCK SWITCH AND POSITION SWITCH)**

Component Side:



T

B065430E14

- (a) Measure the resistance of the door lock and unlock switch and position switch.

Standard (Door lock and unlock switch)

Tester Connection	Door Lock Condition	Specified Condition
6 - 8	Lock	Below 1 Ω
5 - 8, 6 - 8	OFF	10 k Ω or higher
5 - 8	Unlock	Below 1 Ω

Standard (Position switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 8	Lock	10 k Ω or higher
7 - 8	Unlock	Below 1 Ω

NG

REPLACE FRONT DOOR LOCK ASSEMBLY RH

OK

20

CHECK HARNESS AND CONNECTOR (FRONT DOOR LOCK RH - ECU, DRIVER SIDE J/B AND BODY GROUND)

Wire Harness Side:

Front Door Lock Assembly RH

Front View

Multiplex Network Body ECU

Front View

Driver Side J/B

Driver Side J/B

Front View

T

B088348E02

- (a) Disconnect the D20 front door lock connector.
- (b) Disconnect the B5 multiplex network body ECU connector.
- (c) Disconnect the 1H and 1I driver side J/B connectors.
- (d) Measure the resistance.

Standard

Tester Connection	Specified Condition
D20-4 - 1H-23 (ACT+)	Below 1 Ω
D20-1 - 1H-5 (ACT-)	Below 1 Ω
D20-6 - 1I-4 (L2)	Below 1 Ω
D20-5 - 1I-19 (UL2)	Below 1 Ω
D20-7 - B5-11 (LSWP)	Below 1 Ω
D20-8 - Body ground	Below 1 Ω
D20-4 or 1H-23 (ACT+) - Body ground	10 kΩ or higher
D20-1 or 1H-5 (ACT-) - Body ground	10 kΩ or higher
D20-6 or 1I-4 (L2) - Body ground	10 kΩ or higher
D20-5 or 1I-19 (UL2) - Body ground	10 kΩ or higher
D20-7 or B5-11 (LSWP) - Body ground	10 kΩ or higher

- (e) Reconnect the front door lock connector.
- (f) Reconnect the multiplex network body ECU connector.
- (g) Reconnect the driver side J/B connectors.

NG


REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE DRIVER SIDE JUNCTION BLOCK (MULTIPLEX NETWORK BODY ECU)

21 INSPECT FRONT DOOR LOCK ASSEMBLY RH (DOOR LOCK MOTOR)

Component Side:



T

B065429E16

- (a) Apply battery voltage to the door lock and check operation of the door lock motor.

NOTICE:

Do not apply battery voltage to any terminals except terminals 1 and 4.

OK

Terminal No	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock


NG

REPLACE FRONT DOOR LOCK ASSEMBLY RH

OK

22 INSPECT FRONT DOOR LOCK ASSEMBLY RH (DOOR LOCK AND UNLOCK SWITCH AND POSITION SWITCH)

Component Side:



T

B065430E14

- (a) Measure the resistance of the door lock and unlock switch and position switch.

Standard (Door lock and unlock switch)

Tester Connection	Door Lock Condition	Specified Condition
6 - 8	Lock	Below 1 Ω
5 - 8, 6 - 8	OFF	10 k Ω or higher
5 - 8	Unlock	Below 1 Ω

Standard (Position switch)

Tester Connection	Door Lock Condition	Specified Condition
7 - 8	Lock	10 k Ω or higher
7 - 8	Unlock	Below 1 Ω

NG

REPLACE FRONT DOOR LOCK ASSEMBLY RH

OK

23

CHECK HARNESS AND CONNECTOR (FRONT DOOR LOCK RH - ECU, DRIVER SIDE J/B AND BODY GROUND)

Wire Harness Side:

Front Door Lock Assembly LH

Front View

Multiplex Network Body ECU

Front View

Driver Side J/B

Driver Side J/B

Front View

T

B088348E03

- (a) Disconnect the D20 front door lock connector.
- (b) Disconnect the B5 multiplex network body ECU connector.
- (c) Disconnect the 1H and 1I driver side J/B connectors.
- (d) Measure the resistance.

Standard


Tester Connection	Specified Condition
D20-4 - 1H-23 (ACT+)	Below 1 Ω
D20-1 - 1H-5 (ACT-)	Below 1 Ω
D20-6 - 1I-4 (L2)	Below 1 Ω
D20-5 - 1I-19 (UL2)	Below 1 Ω
D20-7 - B5-11 (LSWP)	Below 1 Ω
D20-8 - Body ground	Below 1 Ω
D20-4 or 1H-23 (ACT+) - Body ground	10 kΩ or higher
D20-1 or 1H-5 (ACT-) - Body ground	10 kΩ or higher
D20-6 or 1I-4 (L2) - Body ground	10 kΩ or higher
D20-5 or 1I-19 (UL2) - Body ground	10 kΩ or higher
D20-7 or B5-11 (LSWP) - Body ground	10 kΩ or higher

- (e) Reconnect the front door lock connector.
- (f) Reconnect the multiplex network body ECU connector.
- (g) Reconnect the driver side J/B connectors.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



24 INSPECT DOOR CONTROL SWITCH ASSEMBLY

- (a) Remove the door control switch (passenger side).
 (b) Measure the resistance of the door control switch.

Standard

Tester Connection	Switch Condition	Specified Condition
3 (E) - 6 (L)	Lock	Below 1 Ω
3 (E) - 5 (UL) 3 (E) - 6 (L)	OFF	10 k Ω or higher
3 (E) - 5 (UL)	Unlock	Below 1 Ω

- (c) Reinstall the door control switch.

NG**REPLACE DOOR CONTROL SWITCH ASSEMBLY****OK****25 CHECK HARNESS AND CONNECTOR (DOOR CONTROL SWITCH - DRIVER SIDE J/B AND BODY GROUND)****Wire Harness Side:**

- (a) Disconnect the D23 door control switch connector.
 (b) Disconnect the 1I driver side J/B connector.
 (c) Measure the resistance.

Standard

Tester Connection	Specified Condition
D23-6 (L) - 1I-7 (L1)	Below 1 Ω
D23-5 (UL) - 1I-3 (UL1)	Below 1 Ω
D23-3 (E) - Body ground	Below 1 Ω
D23-6 (L) or 1I-7 (L1) - Body ground	10 k Ω or higher
D23-5 (UL) or 1I-3 (UL1) - Body ground	10 k Ω or higher

- (d) Reconnect the door control switch connector.
 (e) Reconnect the driver side J/B connector.

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****REPLACE DRIVER SIDE JUNCTION BLOCK**