

SYSTEM DESCRIPTION

1. KEY REMAINDER WARNING SYSTEM DESCRIPTION

- (a) When the driver side door is open with the ignition switch in the ACC or LOCK position, this system sounds a buzzer to warn the driver that the ignition key has not been removed.

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

Use this procedure to troubleshoot the key reminder warning system.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS AND SYMPTOM CHECK

NEXT

3 BATTERY VOLTAGE INSPECTION

- (a) Check the battery voltage.

Standard Voltage:

11 to 14 V

If the voltage is below 11 V, recharge the battery before proceeding.

NEXT

4 PROBLEM SYMPTOMS TABLE

- (a) If the fault is not listed on the problem symptoms table, proceed to A.
- (b) If the fault is listed on the problem symptoms table, proceed to B.

B

Go to step 6

A

5 OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) On-vehicle inspection (See page [DL-61](#)).
- (b) Terminals of ECU (See page [DL-60](#)).

NEXT

6 ADJUSTMENT, REPAIR OR REPLACEMENT

NEXT

7	CONFIRMATION TEST
---	-------------------

NEXT

END
