



TOWING TAIL RELAY

INSPECTION

1. INSPECT TOWING TAIL RELAY

- (a) Check the resistance.
 - (1) Using an ohmmeter, measure the resistance between the terminals.

Standard

Tester Connection	Specified Condition
3-5	10 k Ω or higher
3-5	Below 1 Ω (When battery voltage applied to terminals 1 and 2)

If the result is not as specified, replace the towing tail relay.