

## INSTALLATION

### 1. INSTALL GENERATOR ASSEMBLY

- (a) Install the generator assembly with the 2 bolts.  
**Torque: 43 N\*m (438 kgf\*cm, 32 ft.\*lbf)**
- (b) Install the wire harness clamp bracket with the 2 bolts.  
**Torque: 8.0 N\*m (82 kgf\*cm, 71 in.\*lbf)**
- (c) Connect the wire harness.
  - (1) Connect the wire harness to terminal B and install the nut.  
**Torque: 9.8 N\*m (100 kgf\*cm, 7.0 ft.\*lbf)**
  - (2) Connect the connector to the generator assembly.
  - (3) Install the wire harness stay with the bolt.  
**Torque: 8.0 N\*m (82 kgf\*cm, 71 in.\*lbf)**

### 2. INSTALL FAN SHROUD (See page [CO-20](#))

### 3. INSTALL RADIATOR SUPPORT TO FRAME SEAL LH

### 4. INSTALL V-BANK COVER (See page [ES-416](#))

### 5. CONNECT CABLE TO NEGATIVE TERMINAL Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)