


REMOVAL


1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **DRAIN ENGINE COOLANT** (See page [CO-3](#))
3. **REMOVE RADIATOR SUPPORT TO FRAME SEAL LH**

- (a) Disengage the 9 clips, then remove the radiator support to frame seal.




4. **REMOVE FAN SHROUD**

- (a) Disconnect the hose from the radiator reserve tank.




- (b) Remove the 2 cooler hoses from the clamp (with automatic transmission).
- (c) Remove the 4 nuts from the fan pulley.
- (d) Remove the fan and generator V belt (see page [EM-5](#)).
- (e) Remove the 2 bolts from the fan shroud.
- (f) Remove the fan pulley and fan shroud.




5. **REMOVE RADIATOR ASSEMBLY**


- (a) Disconnect the 2 radiator hoses.
- (b) Remove the 4 bolts, then remove the radiator.



- (c) Disconnect the 2 oil cooler hoses (with automatic transmission).



6. REMOVE RADIATOR HOSE INLET



7. REMOVE NO.2 RADIATOR HOSE

