



HEATED OXYGEN SENSOR

REMOVAL

- 1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
- 2. REMOVE HEATED OXYGEN SENSOR
 - (a) Disconnect the 2 heated oxygen sensor connectors.
 - (b) Remove the 2 heated oxygen sensors from the exhaust pipe.



INSPECTION

- 1. INSPECT HEATED OXYGEN SENSOR
 - (a) Check the resistance. (Bank 1 Sensor 2)
 - (1) Using an ohmmeter, measure the resistance between the terminals.
- Standard**

Tester Connection	Specified Condition
1 (HT) - 2 (+B)	11 to 16 Ω at 20°C (68°F)
1 (HT) - 4 (E)	10 kΩ or higher

If the result is not as specified, replace the heated oxygen sensor.


INSTALLATION

1. INSTALL HEATED OXYGEN SENSOR

- (a) Using SST, install the 2 heated oxygen sensors onto the exhaust pipe.

SST 09224-00010

Torque: 44 N*m (449 kgf*cm, 33 ft.*lbf)



- (b) Connect the 2 heated oxygen sensor connectors.

2. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)

3. CHECK FOR EXHAUST GAS LEAKAGE