



HAZARD WARNING SWITCH

INSPECTION

1. INSPECT HAZARD WARNING SWITCH

- (a) Check the resistance.
- (1) Measure the resistance using an ohmmeter, and check the results in accordance with the value(s) in the table below.

Standard

Tester Connection	Condition	Specified Condition
7-9	OFF	10 kΩ or higher
7-9	ON	Below 1 Ω
10-11	Illumination circuit	Below 1 Ω

If the result is not as specified, replace the hazard warning signal switch assembly.

- (b) Check the illumination operation.
- (1) (1) Connect the battery positive (+) lead to terminal 11 and the battery negative (-) lead to terminal 10, then check that the illumination comes on.

Standard:

Illumination comes on.

If the illumination does not come on, replace the bulb.