

DTC	B1794	Open in Occupant Classification ECU Battery Positive Line
------------	--------------	--

DESCRIPTION


DTC B1794 is set when a malfunction is detected in the occupant classification ECU.

DTC No.	DTC Detections Conditions	Trouble Areas
B1794	<ul style="list-style-type: none">• Occupant classification ECU circuit malfunction• Occupant classification ECU malfunction• The occupant classification ECU receives a short circuit to ground signal in the passenger side buckle switch circuit for 2 seconds	<ul style="list-style-type: none">• Wire harness• Occupant classification ECU

HINT:

- When DTC B1650/32 is detected as a result of troubleshooting the supplemental restraint system, perform troubleshooting for DTC B1794 of the occupant classification system.
- Use the intelligent tester to check for DTCs of the occupant classification ECU, otherwise the DTCs cannot be read.

WIRING DIAGRAM



RS

1 CHECK DTC

- Turn the ignition switch to the ON position.
- Clear any DTCs stored in the memory (See page [RS-365](#)).

HINT:

- First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.
 - Use the intelligent tester to clear the DTCs of the occupant classification ECU, otherwise the DTCs cannot be cleared.
- (c) Turn the ignition switch to the LOCK position, and wait for at least 10 seconds.
- (d) Turn the ignition switch to the ON position.
- (e) Using the intelligent tester, check for DTCs of the occupant classification ECU (See page [RS-365](#)).

OK:

DTC B1794 is not output.

HINT:

DTCs other than B1794 may be output at this time, but they are not related to this check.

OK**USE SIMULATION METHOD TO CHECK**NG**2****CHECK CONNECTION OF CONNECTORS**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the center airbag sensor assembly and the occupant classification ECU.

OK:

The connectors are properly connected.


NG**CONNECT CONNECTORS**OK**3****CHECK CONNECTORS**

- (a) Check that the connectors (on the occupant classification ECU side) are not damaged (See page [IN-34](#)).

OK:

The connectors are not deformed or damaged.

NG**REPAIR OR REPLACE WIRE HARNESS**OK

4 CHECK WIRE HARNESS (SOURCE VOLTAGE)

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the O5 connector from the occupant classification ECU.
- Connect the negative (-) terminal cable to the battery.
- Turn the ignition switch to the ON position.
- Measure the voltage and resistance.

Standard resistance

Tester Connection	Condition	Specified Condition
O5-3 (GND) - Body ground	Always	Below 1 Ω

Standard voltage

Tester Connection	Condition	Specified Condition
O5-1 (+B) - Body ground	Ignition switch ON	10 to 14 V
O5-7 (IG) - Body ground	Ignition switch ON	10 to 14 V

NG**REPAIR OR REPLACE WIRE HARNESS OR BATTERY****OK****5 CHECK DTC**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Connect the connectors to the occupant classification ECU.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Clear any DTCs stored in the memory (See page [RS-365](#)).

HINT:

- First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.
 - Use the intelligent tester to clear the DTCs of the occupant classification ECU, otherwise the DTCs cannot be cleared.
- Turn the ignition switch to the LOCK position, and wait for at least 10 seconds.
 - Turn the ignition switch to the ON position.
 - Using the intelligent tester, check for DTCs of the occupant classification ECU (See page [RS-365](#)).

OK:**DTC B1794 is not output.**

HINT:

DTCs other than B1794 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

6 REPLACE OCCUPANT CLASSIFICATION ECU

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (See page [RS-631](#)).

HINT:

Perform the inspection using parts from a normal vehicle when possible.

NEXT

7 PERFORM ZERO POINT CALIBRATION

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the ON position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-357](#)).

OK:

COMPLETED is displayed on the tester.

NEXT

8 PERFORM SENSITIVITY CHECK

- (a) Using the intelligent tester, perform the sensitivity check (See page [RS-357](#)).

Standard :

27 to 33 kg (59.52 to 72.75 lb)

RS

NEXT

END