

DTC	B1771	Passenger Side Buckle Switch Circuit Malfunction
------------	--------------	---

DESCRIPTION

The passenger side buckle switch circuit consists of the occupant classification ECU and the front seat inner belt assembly RH.

DTC B1771 is recorded when a malfunction is detected in the passenger side buckle switch circuit.


Troubleshoot DTC B1771 first when DTCs B1771 and B1795 are output simultaneously.

DTC No.	DTC Detecting Condition	Trouble Area
B1771	<ul style="list-style-type: none"> Occupant classification ECU detects line short circuit signal, open circuit signal, short circuit to ground signal or short circuit to B+ signal in the passenger side buckle switch circuit for 2 seconds Passenger side buckle switch malfunction Occupant classification ECU malfunction 	<ul style="list-style-type: none"> No .1 seat wire Floor wire Front seat inner belt assembly RH (Buckle switch RH) Occupant classification ECU

HINT:

- When DTC B1650/32 is detected as a result of troubleshooting the supplemental restraint system, perform troubleshooting for DTC B1771 of the occupant classification system.
- Use the intelligent tester to check for DTCs of the occupant classification ECU, otherwise the DTC cannot be read.

WIRING DIAGRAM



HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front passenger seat installation bolts to see the under surface of the seat cushion.
- In the above case, hold the seat so that it does not tip over. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat up only for as long as necessary.

RS

1

CHECK DTC

- Turn the ignition switch to the on position.
 - Clear the DTCs stored in the memory (See page [RS-365](#)).
- HINT:
First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.
- Turn the ignition switch to the lock position.
 - Turn the ignition switch to the on position.
 - Check the DTCs (See page [RS-365](#)).

OK:

DTC B1771 is not output.

HINT:

Codes other than DTC B1771 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

2

CHECK CONNECTION OF CONNECTORS

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the occupant classification ECU and the front seat inner belt assembly RH.

OK:

The connectors are properly connected.

NG

CONNECT CONNECTORS

OK

3

CHECK CONNECTORS

- (a) Check that the connectors (on the occupant classification ECU side and buckle switch RH side) are not damaged (See page [IN-34](#)).


OK:

The connectors are not deformed or damaged.

NG

REPAIR OR REPLACE WIRE HARNESS


OK

4 CHECK NO. 1 SEAT WIRE (TO B+)

- Disconnect the connectors from the occupant classification ECU and the front seat inner belt assembly RH.
- Connect the negative (-) terminal cable to the battery.
- Turn the ignition switch to the on position.
- Measure the voltage.

Standard voltage

Tester connection	Condition	Specified condition
O5-9 (BSW) - Body ground	Ignition switch on	Below 1 V
O5-5 (BGND) - Body ground	Ignition switch on	Below 1 V

NG**REPAIR OR REPLACE NO. 1 SEAT WIRE****OK****5 CHECK NO. 1 SEAT WIRE (FOR OPEN)**

- Turn the ignition switch to the lock position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Using a service wire, connect J11-2 and J11-1 of connector C.

NOTICE:

Do not forcibly insert a service wire into the terminals of the connector when connecting.


- Measure the resistance.

Standard resistance

Tester connection	Condition	Specified condition
O5-9 (BSW) - O5-5 (BGND)	Always	Below 1 Ω

NG**REPAIR OR REPLACE NO. 1 SEAT WIRE****OK**

6 CHECK NO. 1 SEAT WIRE (FOR SHORT)



- (a) Disconnect the service wire from connector C.
(b) Measure the resistance.

Standard resistance


Tester connection	Condition	Specified condition
O5-9 (BSW) - O5-5 (BGND)	Always	1 MΩ or higher

NG

REPAIR OR REPLACE NO. 1 SEAT WIRE

OK

7 CHECK NO. 1 SEAT WIRE (TO GROUND)



- (a) Measure the resistance.
Standard resistance

Tester connection	Condition	Specified condition
O5-9 (BSW) - Body ground	Always	1 MΩ or higher
O5-5 (BGND) - Body ground	Always	1 MΩ or higher

NG

REPAIR OR REPLACE NO. 1 SEAT WIRE

OK

RS

8

CHECK DTC

- (a) Connect the connectors to the occupant classification ECU and the front seat inner belt assembly RH.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the on position.
- (d) Clear the DTCs stored in the memory (See page [RS-365](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (e) Turn the ignition switch to the lock position.
- (f) Turn the ignition switch to the on position.
- (g) Check the DTCs (See page [RS-365](#)).

OK:

DTC B1771 is not output.

HINT:

Codes other than DTC B1771 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

9

REPLACE FRONT SEAT INNER BELT ASSEMBLY RH

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the front seat inner belt assembly RH (See page [SB-8](#)).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

- (d) Connect the negative (-) terminal cable to the battery.
- (e) Turn the ignition switch to the on position.
- (f) Clear the DTCs stored in the memory (See page [RS-365](#)).

HINT:

First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.

- (g) Turn the ignition switch to the lock position.
- (h) Turn the ignition switch to the on position.
- (i) Check the DTCs (See page [RS-365](#)).

OK:

DTC B1771 is not output.

HINT:

Codes other than DTC B1771 may be output at this time, but they are not related to this check.

OK

END

NG

10 REPLACE OCCUPANT CLASSIFICATION ECU

- (a) Turn the ignition switch to the lock position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (See page [RS-631](#)).

NEXT

11 PERFORM ZERO POINT CALIBRATION

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the on position.
- (d) Using the intelligent tester, perform the zero point calibration (See page [RS-357](#)).

OK:

COMPLETED is displayed on the tester.

NEXT

12 PERFORM SENSITIVITY CHECK

- (a) Using the intelligent tester, perform the sensitivity check (See page [RS-357](#)).

Standard values:

27 to 33 kg (59.52 to 72.75 lb)

NEXT

END