

## DISASSEMBLY

### 1. REMOVE CLUTCH RELEASE CYLINDER KIT


- (a) Remove the boot from the cylinder body.
- (b) Remove the push rod from the cylinder body.
- (c) Using compressed air, remove the piston together with the spring from the cylinder.

**NOTICE:**

**Be careful not to damage the inside of the cylinder body.**

- (d) Remove the bleeder plug cap from the bleeder plug.

### 2. REMOVE RELEASE CYLINDER BLEEDER PLUG

**CL**


## REASSEMBLY

1. **INSTALL RELEASE CYLINDER BLEEDER PLUG**  
Torque: 11 N\*m (110 kgf\*cm, 8.0 ft.\*lbf)
2. **INSTALL CLUTCH RELEASE CYLINDER KIT**
  - (a) Install the bleeder plug cap onto the bleeder plug.
  - (b) Install the spring onto the cylinder body.
  - (c) Apply lithium soap base glycol grease to the portions shown in the illustration.
  - (d) Install the piston onto the cylinder body.


**NOTICE:**

**Be careful not to damage the inside of the cylinder body.**

- (e) Install the push rod into the cylinder body.
- (f) Install the boot onto the cylinder body.



CL00672



F050800

## INSTALLATION

1. **INSTALL CLUTCH RELEASE CYLINDER ASSEMBLY**
  - (a) Install the clutch release cylinder with the 2 bolts.  
Torque: 12 N\*m (120 kgf\*cm, 8.7 ft.\*lbf)

2. **CONNECT CLUTCH RELEASE CYLINDER TO FLEXIBLE HOSE TUBE**

- (a) Using SST, connect the flexible hose tube.  
**SST 09023-00101**  
Torque: 15 N\*m (155 kgf\*cm, 11 ft.\*lbf)
- (b) Install the clutch line bracket.  
Torque: 12 N\*m (120 kgf\*cm, 8.7 ft.\*lbf)


3. **BLEED CLUTCH PIPE LINE**

- (a) Fill the brake reservoir tank with brake fluid and bleed the clutch system.  
Torque: 11 N\*m (110 kgf\*cm, 8.0 ft.\*lbf)

4. **CHECK FOR CLUTCH FLUID LEAKAGE**

5. **INSTALL NO. 1 CLUTCH HOUSING COVER**

- (a) Install the clutch housing cover No. 1 with the 3 bolts.  
Torque: 12 N\*m (120 kgf\*cm, 8.7 ft.\*lbf)



F050796