



# **Relocate non-root aggregates and NAS data LIFs from node2 to node3**

## **ONTAP Systems**

Paula Carrigan, Amanda Stroman, Barb Einarsen  
May 10, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-systems/upgrade-arl-auto-app/relocating\\_non-root\\_aggregates\\_and\\_nas\\_data\\_lifs\\_from\\_node2\\_to\\_node3.html](https://docs.netapp.com/us-en/ontap-systems/upgrade-arl-auto-app/relocating_non-root_aggregates_and_nas_data_lifs_from_node2_to_node3.html) on May 12, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

Relocate non-root aggregates and NAS data LIFs from node2 to node3 ..... 1

# Relocate non-root aggregates and NAS data LIFs from node2 to node3

Before you can replace node2 with node4, you must relocate the non-root aggregates that are owned by node2 to node3.

### Before you begin

After the post-checks are completed from the previous stage, the resource release for node2 starts automatically. The non-root aggregates and non-SAN data LIFs are migrated from node2 to node3.

### About this task

Remote LIFs handle traffic to SAN LUNs during the upgrade procedure. Moving SAN LIFs is not necessary for cluster or service health during the upgrade.

After the aggregates and LIFs are migrated, the operation is paused for verification purposes. At this stage, you must verify whether or not all the non-root aggregates and non-SAN data LIFs are migrated to node3.



The home owner for the aggregates and LIFs are not modified; only the current owner is modified.

### Steps

1. Verify that all the non-root aggregates are online and their state on node3 by using the following command:

```
storage aggregate show -node node3 -state online -root false
```

The following example shows that the non-root aggregates on node2 are online:

```
cluster::> storage aggregate show -node node3 state online -root false

Aggregate      Size      Available  Used%   State   #Vols  Nodes
RAID           Status
-----
aggr_1         744.9GB   744.8GB    0%      online  5      node2
raid_dp        normal
aggr_2         825.0GB   825.0GB    0%      online  1      node2
raid_dp        normal
2 entries were displayed.
```

If the aggregates have gone offline or become foreign on node3, bring them online by using the following command on node3, once for each aggregate:

```
storage aggregate online -aggregate <aggr_name>
```

2. Verify that all the volumes are online on node3 by using the following command on node3 and examining its output:

```
volume show -node node3 -state offline
```

If any volumes are offline on node3, bring them online by using the following command on node3, once for each volume:

```
volume online -vserver <vserver-name> -volume <volume-name>
```

The <vserver-name> to use with this command is found in the output of the previous `volume show` command.

3. Verify that the LIFs have been moved to the correct ports and have a status of `up`. If any LIFs are down, set the administrative status of the LIFs to `up` by entering the following command, once for each LIF:

```
network interface modify -vserver <vserver_name> - lif <LIF_name> -home-node <nodename> - status-admin up
```

4. If the ports currently hosting data LIFs will not exist on the new hardware, remove them from the broadcast domain by using the following command:

```
network port broadcast-domain remove-ports
```

5. Verify that there are no data LIFs remaining on node2 by using the following command and examining the output:

```
network interface show - curr-node <node2> -role data
```

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.