

The function submits a request to the SDRAM server for a block write

The SDRAM server inturn calls the function write_row for every row in the block to be written

The function write_row is target specific and should be configured based on the target used

The function allows the user to start the write from any row and any column offset