

- The function submits a request to the SDRAM server for a block read
- The SDRAM server inturn calls the function `read_row` for every row in the block to be read
- The function `read_row` is target specific and should be configured based on the target used
- The function allows the user to start the read from any row and any column offset