

Arduino Pin	Loco Connector	Function
11 Slave	11	Speed Output
12 Slave	9	Direction Output
A0 Master	--	Read Pot Voltage
2,3	--	COM Link
12 Master	—	Direction Input
8 BOTH	—	Master/Slave Selection
—	10 to 12	10k Resistor