

## **Resetting the Brother toner and drum counters**

### **Toner counter reset**

1. Open the cover.
2. Press the “back” and “go” buttons together, then quickly press the “back” button again.
3. The display should show something like “TNR...”; press the down arrow until the display shows “TNR-HC”.
4. Press the down arrow to reset.
5. Close the cover.

### **Drum counter reset**

1. Press OK and the up arrow at the same time.
2. The display should say “Drum”.
3. Press OK.
4. Press the down arrow to reset.