

Resetting the Brother toner and drum counters

Toner counter reset

1. Open the cover; remove the drum unit then replace it; wait 10 seconds with cover still open.
2. Press the “back” and “go” buttons together, then quickly press the “back” button again.
3. The display should show something like “TNR...”; press the down arrow until the display shows “TNR-HC”. Press OK.
4. Press the down arrow to reset.
5. Close the cover.

Drum counter reset

1. Press OK and the up arrow at the same time.
2. The display should say “Drum”.
3. Press OK.
4. Press the down arrow to reset.