

User Guide: Switch-Adapted Water Gun

1. Overview

This water gun is adapted to work with accessibility switches via a 3.5mm jack.

2. Parts

- Electric Shark Water Gun
- 3D Printed Stand
- 3.5mm Mono Jack (included)
- External Switch (pre-attached)

3. Battery Installation

- Remove all factory screws to split the water gun in half.
- Battery compartment is inside the handle, behind the trigger.
- Insert **2 AA batteries**, matching polarity.
- Close the gun and reinsert screws.

4. Usage

- Plug a 3.5mm switch into the jack.
- Press the switch to spray.
- Release to stop.

5. Tips

- Do not submerge.
- Keep the jack and switch dry.
- Remove batteries if storing.