

Overview

This water gun has been adapted for accessibility and can be activated using a 3.5mm external switch.



Parts / Included Components

This water gun comes with:

- **Shark Water Gun** – The main toy, changed so it works with a switch
- **3D Printed Stand** – Helps hold the gun upright when not in use
- **3.5mm Jack (built-in)** – Where you plug in the switch

Features

- Works with a button switch
- Uses a standard 3.5mm plug
- Just add batteries and plug it in to use

Usage

- **Putting in Batteries:** Use a screwdriver to open the toy. The battery compartment is inside the handle. Insert 2 AA batteries, then screw it closed again.
- **Using the Gun:** Plug in the switch and press the button to spray
- **Storing It:** Take the batteries out if you're not using it for a while



To replace the batteries, begin by unscrewing the screws that secure both halves of the toy's outer shell. Once opened, you'll find the battery compartment located in the handle, just below the trigger. Rotate the old batteries out and insert the new ones as indicated.



Care and Cleaning

- Wipe the water gun with a damp cloth
- Don't put it in water
- Keep the switch and plug dry
- Store it somewhere cool and out of the sun