

Overview

This water gun has been adapted for accessibility and can be activated using a 3.5mm external switch.



© 2025 by Devinn Chi & Cat Martins & Noel Raehl

This work is licensed under the CC BY SA 4.0 License: <http://creativecommons.org/licenses/by-sa/4.0>

Files available at https://github.com/davinci73/Design_Sprint_3_Devinn-Cat-Noel/tree/main

Parts / Included Components

This water gun comes with:

- **Shark Water Gun** – The main toy, changed so it works with a switch
- **3D Printed Stand** – Helps hold the gun upright when not in use
- **3.5mm Jack (built-in)** – Where you plug in the switch

Features

- Works with a button switch
- Uses a standard 3.5mm plug
- Just add batteries and plug it in to use

Usage

- **Putting in Batteries:** Use a screwdriver to open the toy. The battery compartment is inside the handle. Insert 2 AA batteries, then screw it closed again.
- **Using the Gun:** Plug in the switch and press the button to spray
- **Storing It:** Take the batteries out if you're not using it for a while

Care and Cleaning

- Wipe the water gun with a damp cloth
- Don't put it in water
- Keep the switch and plug dry
- Store it somewhere cool and out of the sun



© 2025 by Devinn Chi & Cat Martins & Noel Raehl

This work is licensed under the CC BY SA 4.0 License: <http://creativecommons.org/licenses/by-sa/4.0>

Files available at https://github.com/davinci73/Design_Sprint_3_Devinn-Cat-Noel/tree/main