

Rhythm Pattern Programming	
❶	With the sequencer stopped, set the MODE selector to PATTERN CLEAR.
❷	Use the STEP buttons to select the Rhythm Pattern memory location you wish to program.
❸	Press the BASIC VARIATION button to select Variation A or Variation B.
❹	Press the CLEAR button.
❺	Set the MODE selector to 1st PART.
❻	Start the sequencer by pressing the START/STOP button.
❼	While pressing the SHIFT/WRITE-NEXT key, press the CLEAR button to choose the PRE-SCALE.
❽	While pressing the CLEAR button, press a STEP button to set the desired pattern length (1-16)*.
❾	Choose an instrument using the INSTRUMENT/TRACK selector buttons.
❿	Press the STEP buttons to program the instrument on the desired steps.
⓫	Program the other instrument sounds and ACCENT by repeating ❾ and ❿.
⓬	Press the START/STOP button when programming has been completed.

\*In the case of programming 16 steps setting the pattern length is unnecessary.

Track Compose	
❶	Set the MODE selector to COMPOSE
❷	Choose the Track with the INSTRUMENT/TRACK selector buttons.
❸	Press the CLEAR button.
❹	Use the STEP buttons to select the first Rhythm Pattern of the Track.
❺	Press the BASIC VARIATION button to select Variation A or Variation B.
❻	Press the START/STOP button to start the sequencer.
❼	Press the SHIFT-WRITE/NEXT key to advance to the next measure.
❽	Use the STEP buttons to select a different Rhythm Pattern, if desired. Press the SHIFT-WRITE/NEXT key to save the Rhythm Pattern and advance to the next measure.
❾	At the last measure of the composition, stop the sequencer by pressing the START/STOP button.
Track Play	
❶	Set the MODE selector to PLAY.
❷	Choose the Track to play using the INSTRUMENT/TRACK selector buttons.
❸	Press the BASIC VARIATION button to select Variation A or Variation B.
❹	Start the sequencer by pressing the START/STOP button.

Manual Play	
❶	Set the MODE selector to MANUAL PLAY.
❷	Use STEP buttons 1-12 to select the Basic Rhythm Pattern you want to play.
❸	Press the BASIC-VARIATION button to select the Variation you want to play, A or B.
❹	Start the sequencer by pressing the START/STOP button.
Intro	
❶	Use STEP buttons 13 - 16 to select the Intro Rhythm Pattern you want to play.
❷	Press the I/F - VAR button to select the Intro variation.
❸	Press the TAP button to activate the Intro.
❹	Start the sequencer by pressing the START/STOP button.
Fill In (MANUAL)	
❶	Set the AUTO FILL IN selector to MAN.
❷	Use STEP buttons 13 - 16 to select the Fill In Rhythm Pattern you want to play.
❸	Press the I/F - VAR button to select the Fill In variation.
❹	Press the TAP button when you want the Fill In Rhythm Pattern to play instead of the BASIC RHYTHM.
Fill In (AUTOMATIC)	
❶	Choose the Fill In count using the AUTO FILL IN selector (16, 12, 8, 4, or 2 measures).
❷	Use STEP buttons 13 - 16 to select the Fill In Rhythm Pattern you want to play.
❸	Press the I/F - VAR button to select the Fill In variation.
❹	Press the START/STOP button to start the sequencer.