




**US Army Corps
of Engineers®**

Hydrologic Engineering Center

HEC-RAS

River Analysis System



HEC-RAS User's Manual

Version 6.3

Exported - January 2023

Table of Contents

1 FOREWORD	18
FOREWORD.....	18
2 INTRODUCTION TO HEC-RAS	20
GENERAL PHILOSOPHY OF THE MODELING SYSTEM	20
OVERVIEW OF PROGRAM CAPABILITIES	20
User Interface	20
River Analysis Components	21
Data Storage and Management.....	22
Graphics, Inundation Mapping, and Reporting	22
HEC-RAS Documentation.....	22
OVERVIEW OF THIS MANUAL.....	23
3 INSTALLING HEC-RAS	24
IMPORTANT	24
INSTALLATION PROCEDURE	24
To install the software onto your hard disk, do the following:.....	24
UNINSTALL PROCEDURE	25
4 WORKING WITH HEC-RAS	26
STARTING HEC-RAS.....	26
STEPS IN DEVELOPING A HYDRAULIC MODEL WITH HEC-RAS	28
Starting a New Project	29
Entering Geometric Data	29
Entering Flow Data and Boundary Conditions	32
Performing Hydraulic Computations.....	33
Viewing and Printing Results.....	34
GETTING AND USING HELP	38
5 WORKING WITH PROJECTS	39
UNDERSTANDING PROJECTS	39
ELEMENTS OF A PROJECT	40
Plan Files.....	40

Run Files	40
Output Files	40
Geometry Files	41
Steady Flow Data Files.....	41
Unsteady Flow Data Files.....	41
Quasi-Unsteady Flow Data Files.....	41
Sediment Data Files	42
Water Quality Data Files.....	42
Hydraulic Design Data Files	42
CREATING, OPENING, SAVING, RENAMING, AND DELETING PROJECTS.....	43
PROJECT OPTIONS	44
6 ENTERING AND EDITING GEOMETRIC DATA	45
DEVELOPING THE RIVER SYSTEM SCHEMATIC.....	46
Adding Tributaries into an Existing Reach	48
Editing the Schematic.....	48
Interacting with the Schematic	50
Background Map Layers	53
CROSS SECTION DATA	54
Entering Data.....	54
Editing Data	56
Options	57
Plotting	64
STREAM JUNCTIONS.....	64
Entering Junction Data	64
Selection a Modeling Approach.....	65
BRIDGES AND CULVERTS	66
Cross Section Locations.....	67
Contraction and Expansion Losses	69
Bridge Hydraulic Computations.....	70
Low Flow Computations.....	70
Pressure Flow Computations	71
Weir Flow Computations	71
Combination Flow.....	71

Entering and Editing Bridge Data	71
Bridge Design Editor	84
Culvert Hydraulic Computations.....	86
Entering and Editing Culvert Data.....	87
Bridge and Culvert Options	91
Bridge and Culvert View Features	93
MULTIPLE BRIDGE/CULVERT OPENINGS	94
Entering Multiple Opening Data	94
Defining the Openings	96
Multiple Opening Calculations	98
INLINE STRUCTURES (DAMS, WEIRS AND GATED SPILLWAYS)	98
Entering and Editing Inline Structure Data.....	98
Weir/Embankment Editor.....	100
Gated Spillway Editor	102
Geometric Properties of the Gates	104
Gate Flow Coefficients	104
Coefficients for Weir Flow over the Gate Sill.....	105
User Defined Gate Curves	106
Culverts.....	108
Outlet Rating Curves	108
Outlet Time Series.....	108
LATERAL STRUCTURES (WEIRS, GATED SPILLWAYS, CULVERTS, AND DIVERSION RATING CURVES)	109
Entering and Editing Lateral Structure Data	109
Weir/Embankment Editor.....	114
Gated Spillway Editor	117
Culvert Editor	118
Diversion Rating Curve Editor	119
Outlet Time Series.....	120
Linear Routing Option.....	120
STORAGE AREAS.....	121
2D FLOW AREAS.....	124
Draw a Polygon Boundary for the 2D Flow Area.....	124

Adding Break Lines inside of the 2D Flow Area.....	125
Creating the 2D Flow Area Computational Mesh.....	126
Break Lines	131
Hand Based Mesh Editing Tools	131
STORAGE AREA AND 2D FLOW AREA CONNECTIONS	133
Weir Embankment Editor	135
Culvert Data Editor.....	135
Gate Data Editor	138
Diversion Rating Curve.....	139
Outlet Time Series.....	140
Linear Routing Option.....	140
2D FLOW AREA AND STORAGE AREA EXTERNAL BOUNDARY CONDITIONS.....	141
PUMP STATIONS.....	141
CROSS SECTION INTERPOLATION.....	148
RIVER ICE	155
Entering and Editing Ice Data	155
Entering Ice Data at a Cross Section	155
Entering Ice Data Through a Table.....	157
Entering Ice Data at Bridges	158
Setting Tolerances for Ice Jam Calculations	159
VIEWING AND EDITING DATA THROUGH TABLES	160
Manning's n or k values.....	160
Reach Lengths	161
Contraction and Expansion Coefficients (Steady Flow).....	162
Contraction and Expansion Coefficients (Unsteady Flow)	163
Minor Losses	164
Bank Stations	164
Levees	165
Ice Cover	165
Names	165
River and Reach Names	165
River Stationing.....	165
Node Names	166

Node Descriptions.....	167
Junctions.....	167
Storage Areas	167
Storage Area Connections	167
Pump Stations.....	168
Picture File Associations	168
Ineffective Flow Area Elevations	168
Bridge Width Table.....	168
Weir and Gate Coefficient Table	169
HTAB Internal Boundaries Table	170
Linear Routing Coefficients	171
Preissmann Slots on Lidded XS's	172
Manning's n by Land Classification	173
IMPORTING GEOMETRIC DATA	174
Supported File Formats	175
GIS Format.....	175
USACE Survey Data Format	175
HEC-2 Data Format	175
HEC-RAS Format.....	175
UNET Geometric Data Format	175
MIKE11 Cross-Section Data	176
CSV (Comma Separate Value) Format	176
Geometric Data Importer.....	176
River Reach Stream Lines	177
Cross Section and IB Nodes.....	179
Match River Stations to Existing Geometry	180
Round Selected River Stations.....	180
Create River Stations	180
Storage Areas and Connections	181
GEOMETRIC DATA TOOLS	181
Graphical Cross Section Editor.....	182
Bank Station Tools.....	183
Persistent Scale.....	184
Compare Geometry Files	184
Merge Cross Sections	185

Channel Bank Stations	186
Reverse Stationing Data	186
Cross Section Points Filter	187
Fixed Sediment Elevations	189
Pilot Channels	191
Ineffective Areas - Set to Permanent Mode	193
Ineffective Areas – Fix Overlapping	194
Ineffective Areas – Convert Multiple Blocks to Single “Normal” Ineffective	194
Manning’s n Set Channel to Single Value.....	194
Vertical Datum Adjustment	194
Reach Connectivity	194
Reach Order for Computations	194
Reach Order – Find Loops.....	195
Flow Roughness Factors	195
GEOMETRIC DATA OPTIONS	197
Main Channel Manning's n Value Compositing	198
Hydrologic Unsteady Routing	198
GEOREFERENCING AN HEC-RAS MODEL	200
GIS Tools in HEC-RAS	201
Tables	201
GIS Cut Lines.....	204
Scale Cut Lines to Reach Lines	205
GIS Coordinate Operations.....	205
Plot GIS Profile Reach Bounds.....	206
EXAMPLE OF GEOREFERENCING AN HEC-RAS MODEL	207
Creating the River Network using HEC-GeoRAS	207
Creating the River Network using HEC-RAS.....	210
Importing the Stream Centerline	211
Storage Areas and Connections	214
Cross Sections	216
ATTACHING AND VIEWING PICTURES.....	221
SAVING THE GEOMETRIC DATA.....	223
7 PERFORMING A STEADY FLOW ANALYSIS	224

ENTERING AND EDITING STEADY FLOW DATA	224
Entering Steady Flow Data	224
Steady Flow Data Options	225
Saving the Steady Flow Data	230
Importing Data from the HEC Data Storage System (HEC-DSS)	230
Importing Flows from an Existing Output Profile	232
PERFORMING STEADY FLOW CALCULATIONS.....	233
Simulation Options	233

8 PERFORMING A 1D UNSTEADY FLOW ANALYSIS239

ENTERING AND EDITING UNSTEADY FLOW DATA	239
Unsteady Flow Data	239
Boundary Conditions	240
Flow Hydrograph	241
Stage Hydrograph	243
Stage and Flow Hydrograph	243
Rating Curve	243
Normal Depth	244
Lateral Inflow Hydrograph	245
Uniform Lateral Inflow Hydrograph	245
Groundwater Interflow	245
Time Series of Gate Openings	245
Elevation Controlled Gate	246
Navigation Dam.....	247
Internal Boundary Stage and/or Flow Hydrograph.....	247
"Rules" Editor	249
Precipitation.....	249
Initial Conditions	249
Meteorological Data	251
Unsteady Flow Data Options	252
Observed Data	252
Observed Stage and Flow Time Series Data	252
High Water Marks	256
Observed Rating Curves.....	256
Saving the Unsteady Flow Data.....	257

PERFORMING UNSTEADY FLOW CALCULATIONS	257
Defining a Plan	258
Selecting Programs to Run	259
Geometric Preprocessor	259
Cross Section Property Tables	259
Hydraulic Structure Property Tables	260
Viewing the Preprocessor Hydraulic Properties Tables	261
Unsteady Flow Simulation	262
Post-Processor	263
Simulation Time Window	264
Unsteady Flow Computation Settings	264
Unsteady Flow Simulation Options	266
Saving the Plan Information.....	289
Starting the Computations	289
CALIBRATION OF UNSTEADY FLOW MODELS.....	290
Observed Hydrologic Data.....	291
River and Floodplain Geometry	293
Roughness Coefficients	294
River and Floodplain Storage	298
Hydraulic Structure Coefficients	300
Tools Available in HEC-RAS to aid in Model Calibration	300
Steps To Follow in the Calibration Process	301
General Trends When Adjusting Model Parameters.....	301
Calibration Suggestions and Warnings.....	302
MODEL ACCURACY, STABILITY, AND SENSITIVITY	303
Model Accuracy	303
Model Stability	303
Model Sensitivity	319
FINDING AND FIXING MODEL STABILITY PROBLEMS	320
Utilizing the Profile Plot.....	322
Computational Level Output for Debugging	322
Detailed Log Output for Debugging	323
PERFORMING A DAM OR LEVEE BREACH ANALYSIS WITH HEC-RAS	327

User Enter Breach Data.....	328
Simplified Physical Breaching.....	331
DL Breach	334
DLBreach Data and Parameterization in HEC-RAS.....	335
Transport Parameters.....	344
DL Breach Acknowledgements and References	354
USING HEC-RAS TO COMPUTE UNGAGED LATERAL INFLOWS.....	355
Observed Stage and Flow Data	355
Lateral Inflow Computations.....	357
Computations and Output	360
9 VIEWING RESULTS.....	362
CROSS SECTIONS, PROFILES, AND RATING CURVES.....	362
Viewing Graphics on the Screen	362
Graphical Plot Options.....	365
Plotting Velocity Distribution Output	367
Plotting Other Variables in Profile.....	368
Plotting One Variable versus Another	369
Sending Graphics to the Printer or Plotter	370
Sending Graphics to the Windows Clipboard	370
3D PERSPECTIVE PLOTS	371
Pre-processing Results for 3D Viewing.....	373
3D Viewer	373
Menu and Options.....	374
Controls	375
Particle Tracing	377
Toolbar	378
Min map	379
Speed/Position Information.....	381
How To Use the 3D Viewer	381
Movement.....	381
Changing View/Rotation	382
Changing Elevation	382
Mouse Lock/Unlock.....	382
Flight Plans/Paths	382

Flight Plan Toolbar.....	385
BREACH HYDROGRAPH PLOT	385
STAGE AND FLOW HYDROGRAPHS	387
TABULAR OUTPUT.....	388
Detailed Output Tables.....	388
Detailed Output Table Options	392
Profile Summary Tables	393
User Defined Output Tables	395
Sending Tables to the Printer.....	396
Sending Tables to the Windows Clipboard.....	397
VIEWING RESULTS FROM THE RIVER SYSTEM SCHEMATIC	397
VIEWING COMPUTATIONAL LEVEL OUTPUT FOR UNSTEADY FLOW	398
VIEWING ICE INFORMATION.....	400
Graphical Ice Information.....	400
Tabular Ice Information	402
VIEWING DATA CONTAINED IN AN HEC-DSS FILE	403
EXPORTING RESULTS TO HEC-DSS	405
INUNDATION MAPPING WITH HEC-RAS MAPPER.....	408
10 PERFORMING A FLOODPLAIN ENCROACHMENT ANALYSIS	410
OVERVIEW	410
ENTERING FLOODPLAIN ENCROACHMENT DATA	411
PERFORMING THE FLOODPLAIN ENCROACHMENT ANALYSIS.....	414
VIEWING THE FLOODPLAIN ENCROACHMENT RESULTS.....	414
FLOODWAY ENCROACHMENTS WITH UNSTEADY FLOW	419
11 HYDRAULIC DESIGN (HD) CALCULATORS	421
COMPUTING SCOUR AT BRIDGES.....	422
General Modeling Guidelines	422
Entering Bridge Scour Data	423
Entering Contraction Scour Data	424
Entering Pier Scour Data.....	427
Entering Abutment Scour Data	430
Computing Total Bridge Scour.....	432
RIPRAP AND SCOUR CALCULATOR.....	434

Introduction and Conceptual Approach	435
Riprap Calculator: Sizing Rock Gradation.....	435
Scour Calculator: Computing Launchable Volume	435
Introduction and Conceptual Approach	435
Riprap Calculator: Sizing Rock Gradation.....	437
Step 1: Calculate Hydraulics and Select Profile.....	440
Step 2: Identify Design and Upstream Reference XSs	445
Step 3a: Define Manual Input Variables	449
Step 3b: Select Riprap Coefficient Parameters	454
Step 4: Compute the d30 of the Stable Rock Size	456
Step 5: Select Gradation to Compute Thickness	460
Rock Size and Weight Specifications	470
Limitation: Why Doesn't the Riprap and Scour Calculator use 2D Results?.....	471
Maricopa Method	471
Scour Calculator: Computing Launchable Volume	481
Step 1: Compute Hydraulics	482
Step 2: Identify Design and Reference Cross Sections	483
Step 3: Define Manual Input Variables	485
Step 4: Select the Appropriate Equations.....	486
Step 5: Compute Ensemble Scour Results.....	490
Step 6: Visualizing Scour Results.....	491
Step 7: Select a Reasonable Scour Depth Based on Calculations, Regional Geology, and Engineering Judgement	494
Ongoing Work and Wish List.....	494
Acknowledgement	495
Scour References	495
Appendix A: Example Calculations.....	496
Riprap Examples	496
Scour Examples.....	499
UNIFORM FLOW COMPUTATIONS	501
Solving for Slope, Discharge, or W/S Elevation	502
Solving for Bottom Width	503
Applying Uniform Flow Data to the Geometry File.....	505
Saving Uniform Flow Data	506
STABLE CHANNEL DESIGN FUNCTIONS.....	506

General Modeling Guidelines	506
General Command Buttons.....	506
Stable Channel Design	507
Copeland Method.....	508
Regime Method	512
Tractive Force Method	513
SEDIMENT TRANSPORT CAPACITY	514
SEDIMENT RATING CURVE ANALYSIS TOOL	520
Sediment Rating Curve Challenges and Best Practices	521
Opening the Sediment Rating Curve Analysis Tool.....	523
Funding and Support.....	523
Importing Sediment Data	523
Downloading Data From USGS.....	524
Converting Between Flow and Concentration.....	528
Clipboard Import.....	528
Importing Data Files.....	529
Bias Correction	533
Where Does The Bias Come From?.....	533
Bias Correction Functions	535
Bias Correction Results.....	535
References	537
Piecewise Linear Regression	537
Piecewise Regression Approach.....	538
Constraining the Inflection Point Range.....	539
Stationarity.....	543
The Stationarity Slide Bar	543
Temporal Averaging and Autocorrelation	546
Temporal Averaging.....	548
Setting the Temporal Averaging Threshold.....	549
Plotting Original and Averaged Points.....	550
Hysteresis Visualization	551
Analytical and Tabular Rating Curve Results.....	553
Regression Results (Analytical Results)	554
Generating a Tabular Rating Curve (Tabular Results).....	556
Gradation Trend Analysis	559

Suspended Load Gradation Trends	560
Viewing Suspended Load Gradations	561
12 TROUBLESHOOTING WITH HEC-RAS.....	563
BUILT IN DATA CHECKING.....	563
Checking the Data as it is Entered	563
Data Checking before Computations are Performed	564
ERRORS, WARNINGS, AND NOTES	564
STEADY FLOW LOG OUTPUT	566
UNSTEADY FLOW LOG OUTPUT	567
VIEWING THE LOG FILE	568
REVIEWING AND DEBUGGING THE NORMAL OUTPUT	568
Viewing Graphics	568
Viewing Tabular Output.....	569
The Occurrence of Critical Depth	569
COMPUTATIONS DO NOT RUN TO COMPLETION	569
13 PERFORMING CHANNEL DESIGN/MODIFICATIONS	571
GENERAL MODELING GUIDELINES	571
THE CHANNEL MODIFICATION (ORIGINAL) OPTIONS.....	571
Entering Channel Modification Data	572
Performing the Channel Modifications	575
THE CHANNEL DESIGN/MODIFICATION TOOL OPTIONS.....	576
Entering Channel Modification Data	576
Alternatives	577
Template Design	579
Modify a Range of XS.....	582
Performing the Channel Modifications	584
COMPARING EXISTING AND MODIFIED CONDITIONS	587
14 ADVANCED FEATURES FOR UNSTEADY FLOW ROUTING	590
MIXED FLOW REGIME.....	590
DAM BREAK ANALYSIS	594
Entering Dam Break Data	596
User Enter Breach Data.....	598
Simplified Physical Breaching	602

Breach Growth Shape	605
Estimating Dam Break Parameters	606
Breach Parameter Calculator	607
HEC-RAS Output for Dam Break Analyses.....	608
LEVEE OVERTOPPING AND BREACHING.....	610
MODELING PUMP STATIONS	617
NAVIGATION DAMS	623
Pool Only Control.....	625
Hinge Point Only Control.....	627
Hinge Point and Minimum Pool Operations.....	629
Hinge Point and Minimum and Maximum Pool Control	631
MODELING PRESSURIZED PIPE FLOW.....	633
USER DEFINED RULES FOR HYDRAULIC STRUCTURES AND PUMPS	636
Entering Rule Operations	638
Rule Sets	639
Operation Rules.....	639
Operation Types.....	640
Comment.....	640
New Variable	641
Get Simulation Value	643
Set Operational Parameter (for hydraulic structures)	647
Set Operational Parameter (for pumping stations)	651
Branch (If/Else):.....	654
AUTOMATED CALIBRATION OF MANNING’S N VALUES FOR UNSTEADY FLOW	678
Using the Automated Calibration Feature	681
Calibration Parameters.....	685
15 REFERENCES	689
16 HEC-RAS DATA EXCHANGE	694
SPATIAL DATA FORMAT	694
Records.....	694
Keywords.....	695
Values.....	695
Data Groups.....	695

Comments	695
SPATIAL DATA FORMAT	696
RAS GIS IMPORT FILE (RASIMPORT.SDF)	696
Header	696
River Network.....	697
Cross Sections0	698
Additional Cross Section Properties	699
Bridge_Culverts.....	700
Inline Structures.....	701
Lateral Structures	702
Storage Areas0	703
Storage Area Connections	704
RAS GIS EXPORT FILE (RASEXPORT.SDF)	704
Water Surface Bounding Polygon	706
IMPORT/EXPORT GUIDELINES.....	707
Defining the River Network.....	707
Defining Cross Sections	707
Water Surface Export Data Rules.....	707
SAMPLE RAS GIS IMPORT FILE	707
SAMPLE RAS GIS EXPORT FILE.....	713
17 HEC-RAS OUTPUT VARIABLES.....	719
HYDRAULIC OUTPUT VARIABLES.....	719
SEDIMENT TRANSPORT OUTPUT VARIABLES	724
18 IMPORTING HEC-2 DATA	727
WHAT YOU SHOULD KNOW FIRST	727
STEPS FOR IMPORTING HEC-2 DATA.....	728
REPRODUCING HEC-2 RESULTS	729
19 TERMS AND CONDITIONS OF USE	731

Welcome to the River Analysis System