

Firmware is required for this device: <http://accessrunner.sourceforge.net/>

While it is capable of managing/maintaining the ADSL connection without the module loaded, the device will sometimes stop responding after unloading the driver and it is necessary to unplug/remove power to the device to fix this.

Note: support for cxacru-cf.bin has been removed. It was not loaded correctly so it had no effect on the device configuration. Fixing it could have stopped existing devices working when an invalid configuration is supplied.

There is a script cxacru-cf.py to convert an existing file to the sysfs form.

Detected devices will appear as ATM devices named "cxacru". In /sys/class/atm/ these are directories named cxacruN where N is the device number. A symlink named device points to the USB interface device's directory which contains several sysfs attribute files for retrieving device statistics:

- * adsl_controller_version

- * adsl_headend

- * adsl_headend_environment
Information about the remote headend.

- * adsl_config

Configuration writing interface.

Write parameters in hexadecimal format <index>=<value>, separated by whitespace, e.g.:

"1=0 a=5"

Up to 7 parameters at a time will be sent and the modem will restart the ADSL connection when any value is set. These are logged for future reference.

- * downstream_attenuation (dB)

- * downstream_bits_per_frame

- * downstream_rate (kbps)

- * downstream_snr_margin (dB)

Downstream stats.

- * upstream_attenuation (dB)

- * upstream_bits_per_frame

- * upstream_rate (kbps)

- * upstream_snr_margin (dB)

- * transmitter_power (dBm/Hz)

Upstream stats.

- * downstream_crc_errors

- * downstream_fec_errors

- * downstream_hec_errors

- * upstream_crc_errors

- * upstream_fec_errors

- * upstream_hec_errors

Error counts.

- * line_startable

Indicates that ADSL support on the device is/can be enabled, see adsl_start.

```
* line_status
    "initialising"
    "down"
    "attempting to activate"
    "training"
    "channel analysis"
    "exchange"
    "waiting"
    "up"
```

Changes between "down" and "attempting to activate"
if there is no signal.

```
* link_status
    "not connected"
    "connected"
    "lost"
```

```
* mac_address
```

```
* modulation
    "" (when not connected)
    "ANSI T1.413"
    "ITU-T G.992.1 (G.DMT)"
    "ITU-T G.992.2 (G.LITE)"
```

```
* startup_attempts
    Count of total attempts to initialise ADSL.
```

To enable/disable ADSL, the following can be written to the adsl_state file:

```
"start"
"stop"
"restart" (stops, waits 1.5s, then starts)
"poll" (used to resume status polling if it was disabled due to failure)
```

Changes in adsl/line state are reported via kernel log messages:

```
[4942145.150704] ATM dev 0: ADSL state: running
[4942243.663766] ATM dev 0: ADSL line: down
[4942249.665075] ATM dev 0: ADSL line: attempting to activate
[4942253.654954] ATM dev 0: ADSL line: training
[4942255.666387] ATM dev 0: ADSL line: channel analysis
[4942259.656262] ATM dev 0: ADSL line: exchange
[2635357.696901] ATM dev 0: ADSL line: up (8128 kb/s down | 832 kb/s up)
```