
U S E R M A N U A L F O R MBTCHAR

NAME

mbtchar.ko - BT char driver which works with Marvell stack

FOR DRIVER BUILD

For X86 platform:
Modify ".config" to set "CONFIG_X86=y" or make X86
For Moorestown platform:
Modify ".config" to set "CONFIG_MOORESTOWN=y" or make MOORESTOWN
For PXA9XX platfrom:
Modify ".config" to set "CONFIG_PXA9XX=y" or make PXA9XX [2.6.25]
For PXA955 platfrom:
Modify ".config" to set "CONFIG_PXA955=y" or make PXA955
For PXA950 platfrom:
Modify ".config" to set "CONFIG_PXA950=y" or make PXA950
For PXA920 platfrom:
Modify ".config" to set "CONFIG_PXA920=y" or make PXA920 [2.6.32]

make clean
make build
The binary can be found in ../bin_mbtchar directory.

FOR DRIVER INSTALL

insmod mbtchar.ko
The driver should be loaded before BT driver (w/ char support).