

Model name	Description
ALC880	
3stack	3-jack in back and a headphone out
3stack-digout	3-jack in back, a HP out and a SPDIF out
5stack	5-jack in back, 2-jack in front
5stack-digout	5-jack in back, 2-jack in front, a SPDIF out
6stack	6-jack in back, 2-jack in front
6stack-digout	6-jack with a SPDIF out
w810	3-jack
z71v	3-jack (HP shared SPDIF)
asus	3-jack (ASUS Mobo)
asus-wlv	ASUS W1V
asus-dig	ASUS with SPDIF out
asus-dig2	ASUS with SPDIF out (using GPIO2)
uniwill	3-jack
fujitsu	Fujitsu Laptops (Pi1536)
F1734	2-jack
lg	LG laptop (m1 express dual)
lg-lw	LG LW20/LW25 laptop
tcl	TCL S700
clevo	Clevo laptops (m520G, m665n)
medion	Medion Rim 2150
test	for testing/debugging purpose, almost all controls can be adjusted. Appearing only when compiled with \$CONFIG_SND_DEBUG=y
auto	auto-config reading BIOS (default)
ALC260	
hp	HP machines
hp-3013	HP machines (3013-variant)
hp-dc7600	HP DC7600
fujitsu	Fujitsu S7020
acer	Acer TravelMate
will	Will laptops (PB V7900)
replacer	Replacer 672V
favorit100	Maxdata Favorit 100XS
basic	fixed pin assignment (old default model)
test	for testing/debugging purpose, almost all controls can be adjusted. Appearing only when compiled with \$CONFIG_SND_DEBUG=y
auto	auto-config reading BIOS (default)
ALC262	
fujitsu	Fujitsu Laptop
hp-bpc	HP xw4400/6400/8400/9400 laptops
hp-bpc-d7000	HP BPC D7000
hp-tc-t5735	HP Thin Client T5735
hp-rp5700	HP RP5700
benq	Benq ED8
benq-t31	Benq T31
hippo	Hippo (ATI) with jack detection, Sony UX-90s
hippo_1	Hippo (Benq) with jack detection

HD-Audio-Models.txt

sony-assamd	Sony ASSAMD
toshiba-s06	Toshiba S06
toshiba-rx1	Toshiba RX1
tyan	Tyan Thunder n6650W (S2915-E)
ultra	Samsung Q1 Ultra Vista model
lenovo-3000	Lenovo 3000 y410
nec	NEC Versa S9100
basic	fixed pin assignment w/o SPDIF
auto	auto-config reading BIOS (default)

ALC267/268

quanta-ill	Quanta IL1 mini-notebook
3stack	3-stack model
toshiba	Toshiba A205
acer	Acer laptops
acer-dmic	Acer laptops with digital-mic
acer-aspire	Acer Aspire One
dell	Dell OEM laptops (Vostro 1200)
zepto	Zepto laptops
test	for testing/debugging purpose, almost all controls can adjusted. Appearing only when compiled with \$CONFIG_SND_DEBUG=y
auto	auto-config reading BIOS (default)

ALC269

basic	Basic preset
quanta	Quanta FL1
eeepc-p703	ASUS Eeepc P703 P900A
eeepc-p901	ASUS Eeepc P901 S101
fujitsu	FSC Amilo
lifebook	Fujitsu Lifebook S6420
auto	auto-config reading BIOS (default)

ALC662/663/272

3stack-dig	3-stack (2-channel) with SPDIF
3stack-6ch	3-stack (6-channel)
3stack-6ch-dig	3-stack (6-channel) with SPDIF
6stack-dig	6-stack with SPDIF
lenovo-101e	Lenovo laptop
eeepc-p701	ASUS Eeepc P701
eeepc-ep20	ASUS Eeepc EP20
ecs	ECS/Foxconn mobo
m51va	ASUS M51VA
g71v	ASUS G71V
h13	ASUS H13
g50v	ASUS G50V
asus-model	ASUS
asus-mode2	ASUS
asus-mode3	ASUS
asus-mode4	ASUS
asus-mode5	ASUS
asus-mode6	ASUS
dell	Dell with ALC272

dell-zm1 Dell ZM1 with ALC272
 samsung-nc10 Samsung NC10 mini notebook
 auto auto-config reading BIOS (default)

ALC882/883/885/888/889

```
=====
3stack-dig      3-jack with SPDIF I/O
6stack-dig      6-jack digital with SPDIF I/O
arima           Arima W820Di1
targa           Targa T8, MSI-1049 T8
asus-a7j        ASUS A7J
asus-a7m        ASUS A7M
macpro          MacPro support
mb5             Macbook 5,1
macmini3        Macmini 3,1
mba21           Macbook Air 2,1
mbp3            Macbook Pro rev3
imac24          iMac 24' with jack detection
imac91          iMac 9,1
w2jc           ASUS W2JC
3stack-2ch-dig  3-jack with SPDIF I/O (ALC883)
alc883-6stack-dig 6-jack digital with SPDIF I/O (ALC883)
3stack-6ch      3-jack 6-channel
3stack-6ch-dig  3-jack 6-channel with SPDIF I/O
6stack-dig-demo 6-jack digital for Intel demo board
acer            Acer laptops (Travelmate 3012WTMi, Aspire 5600, etc)
acer-aspire     Acer Aspire 9810
acer-aspire-4930g Acer Aspire 4930G
acer-aspire-6530g Acer Aspire 6530G
acer-aspire-7730g Acer Aspire 7730G
acer-aspire-8930g Acer Aspire 8930G
medion          Medion Laptops
medion-md2      Medion MD2
targa-dig       Targa/MSI
targa-2ch-dig   Targa/MSI with 2-channel
targa-8ch-dig   Targa/MSI with 8-channel (MSI GX620)
laptop-eapd     3-jack with SPDIF I/O and EAPD (Clevo M540JE, M550JE)
lenovo-101e     Lenovo 101E
lenovo-nb0763   Lenovo NB0763
lenovo-ms7195-dig Lenovo MS7195
lenovo-sky      Lenovo Sky
haier-w66       Haier W66
3stack-hp       HP machines with 3stack (Lucknow, Samba boards)
6stack-dell     Dell machines with 6stack (Inspiron 530)
mitac           Mitac 8252D
clevo-m540r     Clevo M540R (6ch + digital)
clevo-m720      Clevo M720 laptop series
fujitsu-pi2515  Fujitsu AMILO Pi2515
fujitsu-xa3530  Fujitsu AMILO XA3530
3stack-6ch-intel Intel DG33* boards
intel-alc889a   Intel IbexPeak with ALC889A
intel-x58       Intel DX58 with ALC889
asus-p5q        ASUS P5Q-EM boards
mb31            MacBook 3,1
sony-vaio-tt    Sony VAI0 TT
auto           auto-config reading BIOS (default)
```

ALC861/660

=====

3stack	3-jack
3stack-dig	3-jack with SPDIF I/O
6stack-dig	6-jack with SPDIF I/O
3stack-660	3-jack (for ALC660)
uniwill-m31	Uniwill M31 laptop
toshiba	Toshiba laptop support
asus	Asus laptop support
asus-laptop	ASUS F2/F3 laptops
auto	auto-config reading BIOS (default)

ALC861VD/660VD

=====

3stack	3-jack
3stack-dig	3-jack with SPDIF OUT
6stack-dig	6-jack with SPDIF OUT
3stack-660	3-jack (for ALC660VD)
3stack-660-digout	3-jack with SPDIF OUT (for ALC660VD)
lenovo	Lenovo 3000 C200
dallas	Dallas laptops
hp	HP TX1000
asus-v1s	ASUS V1Sn
auto	auto-config reading BIOS (default)

CMI9880

=====

minimal	3-jack in back
min_fp	3-jack in back, 2-jack in front
full	6-jack in back, 2-jack in front
full_dig	6-jack in back, 2-jack in front, SPDIF I/O
allout	5-jack in back, 2-jack in front, SPDIF out
auto	auto-config reading BIOS (default)

AD1882 / AD1882A

=====

3stack	3-stack mode (default)
6stack	6-stack mode

AD1884A / AD1883 / AD1984A / AD1984B

=====

desktop	3-stack desktop (default)
laptop	laptop with HP jack sensing
mobile	mobile devices with HP jack sensing
thinkpad	Lenovo Thinkpad X300
touchsmart	HP Touchsmart

AD1884

=====

N/A

AD1981

=====

basic	3-jack (default)
hp	HP nx6320

HD-Audio-Models.txt

thinkpad Lenovo Thinkpad T60/X60/Z60
toshiba Toshiba U205

AD1983

=====

N/A

AD1984

=====

basic default configuration
thinkpad Lenovo Thinkpad T61/X61
dell_desktop Dell T3400

AD1986A

=====

6stack 6-jack, separate surrounds (default)
3stack 3-stack, shared surrounds
laptop 2-channel only (FSC V2060, Samsung M50)
laptop-eapd 2-channel with EAPD (ASUS A6J)
laptop-automute 2-channel with EAPD and HP-automute (Lenovo N100)
ultra 2-channel with EAPD (Samsung Ultra tablet PC)
samsung 2-channel with EAPD (Samsung R65)
samsung-p50 2-channel with HP-automute (Samsung P50)

AD1988/AD1988B/AD1989A/AD1989B

=====

6stack 6-jack
6stack-dig ditto with SPDIF
3stack 3-jack
3stack-dig ditto with SPDIF
laptop 3-jack with hp-jack automute
laptop-dig ditto with SPDIF
auto auto-config reading BIOS (default)

Conexant 5045

=====

laptop-hpsense Laptop with HP sense (old model laptop)
laptop-micsense Laptop with Mic sense (old model fujitsu)
laptop-hpmicsense Laptop with HP and Mic senses
benq Benq R55E
laptop-hp530 HP 530 laptop
test for testing/debugging purpose, almost all controls
 can be adjusted. Appearing only when compiled with
 \$CONFIG_SND_DEBUG=y

Conexant 5047

=====

laptop Basic Laptop config
laptop-hp Laptop config for some HP models (subdevice 30A5)
laptop-eapd Laptop config with EAPD support
test for testing/debugging purpose, almost all controls
 can be adjusted. Appearing only when compiled with
 \$CONFIG_SND_DEBUG=y

Conexant 5051

HD-Audio-Models.txt

laptop	Basic Laptop config (default)
hp	HP Spartan laptop
hp-dv6736	HP dv6736
hp-f700	HP Compaq Presario F700
lenovo-x200	Lenovo X200 laptop
toshiba	Toshiba Satellite M300

Conexant 5066

laptop	Basic Laptop config (default)
hp-laptop	HP laptops, e g G60
dell-laptop	Dell laptops
olpc-xo-1_5	OLPC XO 1.5
ideapad	Lenovo IdeaPad U150

STAC9200

ref	Reference board
oqo	OQO Model 2
dell-d21	Dell (unknown)
dell-d22	Dell (unknown)
dell-d23	Dell (unknown)
dell-m21	Dell Inspiron 630m, Dell Inspiron 640m
dell-m22	Dell Latitude D620, Dell Latitude D820
dell-m23	Dell XPS M1710, Dell Precision M90
dell-m24	Dell Latitude 120L
dell-m25	Dell Inspiron E1505n
dell-m26	Dell Inspiron 1501
dell-m27	Dell Inspiron E1705/9400
gateway-m4	Gateway laptops with EAPD control
gateway-m4-2	Gateway laptops with EAPD control
panasonic	Panasonic CF-74
auto	BIOS setup (default)

STAC9205/9254

ref	Reference board
dell-m42	Dell (unknown)
dell-m43	Dell Precision
dell-m44	Dell Inspiron
eapd	Keep EAPD on (e.g. Gateway T1616)
auto	BIOS setup (default)

STAC9220/9221

ref	Reference board
3stack	D945 3stack
5stack	D945 5stack + SPDIF
intel-mac-v1	Intel Mac Type 1
intel-mac-v2	Intel Mac Type 2
intel-mac-v3	Intel Mac Type 3
intel-mac-v4	Intel Mac Type 4
intel-mac-v5	Intel Mac Type 5
intel-mac-auto	Intel Mac (detect type according to subsystem id)
macmini	Intel Mac Mini (equivalent with type 3)
macbook	Intel Mac Book (eq. type 5)

HD-Audio-Models.txt

```
macbook-pro-v1 Intel Mac Book Pro 1st generation (eq. type 3)
macbook-pro Intel Mac Book Pro 2nd generation (eq. type 3)
imac-intel Intel iMac (eq. type 2)
imac-intel-20 Intel iMac (newer version) (eq. type 3)
ecs202 ECS/PC chips
dell-d81 Dell (unknown)
dell-d82 Dell (unknown)
dell-m81 Dell (unknown)
dell-m82 Dell XPS M1210
auto BIOS setup (default)
```

STAC9202/9250/9251

```
=====
ref Reference board, base config
m1 Some Gateway MX series laptops (NX560XL)
m1-2 Some Gateway MX series laptops (MX6453)
m2 Some Gateway MX series laptops (M255)
m2-2 Some Gateway MX series laptops
m3 Some Gateway MX series laptops
m5 Some Gateway MX series laptops (MP6954)
m6 Some Gateway NX series laptops
auto BIOS setup (default)
```

STAC9227/9228/9229/927x

```
=====
ref Reference board
ref-no-jd Reference board without HP/Mic jack detection
3stack D965 3stack
5stack D965 5stack + SPDIF
5stack-no-fp D965 5stack without front panel
dell-3stack Dell Dimension E520
dell-bios Fixes with Dell BIOS setup
volknob Fixes with volume-knob widget 0x24
auto BIOS setup (default)
```

STAC92HD71B*

```
=====
ref Reference board
dell-m4-1 Dell desktops
dell-m4-2 Dell desktops
dell-m4-3 Dell desktops
hp-m4 HP mini 1000
hp-dv5 HP dv series
hp-hdx HP HDX series
hp-dv4-1222nr HP dv4-1222nr (with LED support)
auto BIOS setup (default)
```

STAC92HD73*

```
=====
ref Reference board
no-jd BIOS setup but without jack-detection
intel Intel DG45* mobos
dell-m6-amic Dell desktops/laptops with analog mics
dell-m6-dmic Dell desktops/laptops with digital mics
dell-m6 Dell desktops/laptops with both type of mics
dell-eq Dell desktops/laptops
```

HD-Audio-Models.txt

alienware Alienware M17x
auto BIOS setup (default)

STAC92HD83*

ref Reference board
mic-ref Reference board with power management for ports
dell-s14 Dell laptop
hp HP laptops with (inverted) mute-LED
auto BIOS setup (default)

STAC9872

vaio VAIO laptop without SPDIF
auto BIOS setup (default)

Cirrus Logic CS4206/4207

mbp55 MacBook Pro 5, 5
imac27 iMac 27 Inch
auto BIOS setup (default)